

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bosch](#) /

› [Bosch MMBV622M VitaPower Series 8 Vacuum Blender Instruction Manual](#)

Bosch MMBV622M

Bosch MMBV622M VitaPower Series 8 Vacuum Blender

Instruction Manual

1. INTRODUCTION

Thank you for choosing the Bosch MMBV622M VitaPower Series 8 Vacuum Blender. This appliance is designed to provide exceptional blending results while preserving the freshness and nutrients of your ingredients through innovative vacuum technology. To ensure safe and efficient operation, please read this instruction manual thoroughly before first use and keep it for future reference.

This manual covers important information regarding the product's features, setup, operation, maintenance, and troubleshooting. Adhering to these guidelines will help you achieve optimal performance and extend the lifespan of your blender.

2. PRODUCT OVERVIEW

The Bosch MMBV622M VitaPower Series 8 is a high-performance vacuum blender featuring a robust 1000 W motor and a durable design. Its primary advantage is the vacuum blending function, which minimizes oxidation, preserving vitamins, nutrients, and the natural color and taste of your ingredients.

Key Features:

- Vacuum Blending:** Processes ingredients with minimal oxygen exposure, preserving Vitamin C and other active nutrients longer than conventional blending.
- Powerful Motor:** Equipped with a 1000 W motor, reaching speeds up to 37,000 RPM for superior blending performance.
- Intuitive Controls:** Features an 'Auto' program for vacuum and smoothie blending, variable speed control, Pulse function, Ice Crush, and a dedicated cleaning program.
- Vacuum Storage System:** Includes special vacuum accessories, such as a vacuum storage box, to keep food and drinks fresh up to twice as long.
- High-Quality Construction:** Premium aluminum housing ensures durability and a sleek design.

- **Shatterproof Tritan™ Jug:** A robust 1.5-liter blending jug designed for safety and longevity.
- **Removable 6-Blade Stainless Steel Knife:** For efficient blending and easy cleaning.

Components:

- Blender Base with Control Panel
- 1.5 Liter Tritan™ Blending Jug with Lid
- Removable 6-Blade Stainless Steel Knife Unit
- 0.75 Liter Vacuum Freshness Storage Box



Figure 2.1: Bosch MMBV622M Blender with key dimensions and 1000 Watt motor highlighted. The blender has a 1.5-liter capacity. Dimensions shown are 164mm, 92mm, 195mm, and 438mm.

Bruchsicherer Tritan™ Becher



Herausnehm-
bares 6-Klingen
Edelstahlmesser



Vakuum-Box (0,75l)

Figure 2.2: Key components of the Bosch MMBV622M, including the shatterproof Tritan™ jug, the removable 6-blade stainless steel knife, and the 0.75-liter vacuum storage box.



Figure 2.3: The control panel features 'Auto' for automatic vacuum mixing, 'Vacuum' for vacuuming the box, and a rotary dial for Pulse, Ice, and Clean functions, along with variable speed control.

3. SETUP

3.1 Unpacking

1. Carefully remove all components from the packaging.
2. Remove any packaging materials, stickers, or protective films.
3. Check that all parts are present and undamaged.

3.2 Initial Cleaning

Before first use, clean all parts that will come into contact with food:

- Wash the blending jug, lid, and blade unit in warm soapy water. Rinse thoroughly and dry.
- Wipe the blender base with a damp cloth. Do not immerse the base in water.

3.3 Assembly

1. Place the blender base on a clean, stable, and dry surface.
2. Insert the blade unit into the blending jug. Ensure it is securely seated.
3. Place the blending jug onto the motor base. Turn it clockwise until it locks into position. The blender will not operate if the jug is not correctly secured.
4. Place the lid onto the blending jug and ensure it is properly sealed.

4. OPERATING INSTRUCTIONS

4.1 General Blending

1. Ensure the blender is assembled correctly and plugged into a power outlet.
2. Add your ingredients to the blending jug. Do not exceed the 'Max' fill line.
3. Secure the lid firmly.
4. Turn the rotary dial to your desired speed setting or select a program (e.g., Pulse, Ice).
5. After blending, turn the dial to '0' and unplug the appliance.

4.2 Vacuum Blending

The vacuum function removes air from the jug before blending, reducing oxidation and preserving nutrients, color, and taste.

1. Add ingredients to the jug and secure the lid.
2. Press the **Auto** button for an automatic vacuum and blending cycle, or press the **Vacuum** button to only vacuum the jug.
3. If you selected 'Vacuum' only, once the vacuum process is complete, turn the dial to your desired speed to begin blending.
4. The blender will automatically stop when the program is finished. Turn the dial to '0' and unplug.



Figure 4.1: Initiating the vacuum function by pressing the 'Vacuum' button for quick and easy air removal.

weniger gleichmäßige kraftvollerer
Blasen Konsistenz Geschmack



Figure 4.2: Visual comparison demonstrating the benefits of vacuum blending: fewer bubbles, more even consistency, and enhanced flavor.



Figure 4.3: The vacuum function actively removes air, helping ingredients stay fresh for up to twice as long.

4.3 Using the Vacuum Storage Box

The included vacuum storage box allows you to preserve food and drinks for extended periods.

1. Fill the vacuum box with your desired food or liquid.
2. Place the lid securely on the box.
3. Connect the vacuum hose (if applicable, or place the box on the blender base if it has an integrated vacuum port) and press the **Vacuum** button on the blender.
4. Once the vacuum process is complete, you can set the date on the lid's indicator to track freshness.
5. Store the vacuum-sealed box in the refrigerator or freezer.



1. Füllen



2. Vakuumieren



3. Einstellen
des Datums



4. Einfrieren

Figure 4.4: Steps for using the vacuum storage box: 1. Fill the box, 2. Vacuum seal it using the blender, 3. Set the date on the lid, and 4. Store it to maintain freshness.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your Bosch MMBV622M blender.

5.1 Cleaning Program

For quick and easy cleaning of the blending jug:

1. Fill the jug with warm water and a drop of dish soap.
2. Secure the lid.
3. Select the **Clean** program on the rotary dial.
4. After the program finishes, rinse the jug thoroughly.

5.2 Manual Cleaning

- **Blender Base:** Wipe with a damp cloth. Do not use abrasive cleaners or immerse in water.
- **Blending Jug, Lid, and Blade Unit:** These parts can be washed by hand with warm soapy water and a brush. Rinse and dry thoroughly.
- **Vacuum Storage Box:** The vacuum storage box is dishwasher safe.



Figure 5.1: The vacuum storage box is suitable for cleaning in a dishwasher.

6. TROUBLESHOOTING

If you encounter any issues with your Bosch MMBV622M blender, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not start.	Not plugged in; Jug not correctly assembled; Lid not secured.	Ensure power cord is plugged in; Re-seat the jug until it locks; Ensure lid is firmly closed.

Problem	Possible Cause	Solution
Vacuum function not working.	Lid not sealed properly; Vacuum valve blocked.	Check that the lid is fully sealed; Clean the vacuum valve on the lid.
Poor blending results.	Too much or too little liquid; Ingredients too large; Overfilling.	Adjust liquid content; Cut ingredients into smaller pieces; Do not exceed 'Max' fill line.
Blender is excessively loud.	Hard ingredients (e.g., ice); Jug not seated correctly.	This blender operates at 83 dB, which is normal for its power. Ensure jug is seated correctly. If noise is unusual or accompanied by smoke, discontinue use and contact support.

7. SPECIFICATIONS

Technical details for the Bosch MMBV622M VitaPower Series 8 Vacuum Blender:

- **Brand:** Bosch
- **Model Number:** MMBV622M
- **Color:** Aluminum/Black
- **Product Dimensions (L x W x H):** 19.5 x 19.1 x 43.8 cm
- **Weight:** 7.6 Kilograms
- **Capacity:** 1.5 Liters
- **Power:** 1000 Watts
- **Voltage:** 240 Volts
- **Material:** Aluminum, Plastic
- **Number of Speeds:** 4 (variable speed control)
- **Noise Level:** 83 Decibels
- **Motor Speed:** Up to 37,000 RPM
- **Included Components:** Vacuum Blender, 0.75 L Vacuum Freshness Storage Box
- **Recommended Use:** Smoothies
- **Power Source:** Corded Electric
- **Country of Origin:** Portugal

8. WARRANTY AND SUPPORT

Bosch products are manufactured to high-quality standards. In the unlikely event of a defect, please refer to your

purchase documentation for warranty terms and conditions.

- **Spare Parts Availability:** Spare parts are generally available for 1 year from the date of purchase.
- For technical assistance, repairs, or to order spare parts, please contact your local Bosch service center or authorized dealer.
- Always provide the model number (MMBV622M) and serial number (if applicable) when contacting support.

© 2026 Bosch. All rights reserved.