

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ornin](#) /
- › [Ornin T112 Trimline Corded Telephone User Manual](#)

Ornin T112

Ornin T112 Trimline Corded Telephone User Manual

Model: T112 | Brand: Ornin

1. INTRODUCTION

Thank you for purchasing the Ornin T112 Trimline Corded Telephone. This manual provides detailed instructions for setting up, operating, and maintaining your new telephone. Please read this manual thoroughly before use to ensure proper functionality and to maximize your experience.

Package Contents:

- Ornin T112 Trimline Corded Telephone Unit
- Coiled Handset Cord
- Telephone Line Cord (RJ11)
- Wall Mount Hook/Bracket (pre-installed or included)

2. PRODUCT OVERVIEW

Familiarize yourself with the components of your Ornin T112 telephone.



Figure 2.1: Main view of the Ornin T112 Trimline Corded Telephone, highlighting the display and primary controls.



Figure 2.2: View of the Ornin T112 Trimline Corded Telephone, showing the keypad and the base unit.

Dimensions:



Figure 2.3: Dimensions of the Ornin T112 Trimline Corded Telephone. Approximately 21 cm (8.26 inches) in length, 6.5 cm (2.56 inches) in width, and 6 cm (2.36 inches) in depth. The wall mount hook extends approximately 7.8 cm (3 inches).

3. SETUP

3.1 Connecting the Telephone

1. Connect one end of the coiled handset cord to the handset and the other end to the jack on the side of the telephone base unit.
2. Connect one end of the telephone line cord (RJ11) to the jack labeled 'LINE' or 'TEL' on the back of the telephone base unit.
3. Connect the other end of the telephone line cord to your wall telephone jack.

3.2 Desktop or Wall Mount Installation

The Ornin T112 is designed for both desktop use and wall mounting.

Desktop Use:

Simply place the telephone on a flat, stable surface. Ensure the cords are not tangled or obstructing movement.



Figure 3.1: Ornin T112 in a typical desktop setup.

Wall Mount Use:

This telephone includes a specific wall mount hook/bracket. Do not attempt to use standard wall-mounted panels as they may not be compatible. Use the integrated hook on the back of the phone for secure wall mounting.

1. Locate the keyhole slots on the back of the telephone unit (refer to Figure 2.3).
2. Install two screws (not included) into your wall, spaced to align with the keyhole slots. Ensure the screws are securely anchored and protrude slightly.
3. Align the keyhole slots on the back of the phone with the installed screws and slide the phone downwards to secure it.
4. Ensure the phone is firmly attached to the wall before use.



Figure 3.2: Ornin T112 securely mounted on a wall.

4. OPERATING INSTRUCTIONS

4.1 Basic Functions

Making a Call:

1. Lift the handset.
2. Listen for a dial tone.
3. Dial the desired telephone number using the keypad.
4. To end the call, replace the handset on the base unit.

Answering a Call:

When the phone rings, simply lift the handset to answer the call. Replace the handset to end the call.

Redial Function:

To redial the last number called, lift the handset and press the **REDIAL** button.

Mute Function:

During a call, press the **MUTE** button to temporarily silence your microphone. The other party will not hear you. Press **MUTE** again to resume the conversation.

4.2 Advanced Features

Caller ID (FSK/DTMF):

This telephone automatically detects and displays incoming caller ID information (FSK and DTMF formats). The display will show the caller's number. Note: The display format for caller ID may vary and might not include dashes or spaces between number segments.

Memory Functions:

- **Outgoing Call Storage:** The phone can store up to 16 groups of outgoing call numbers.
- **Incoming Call Storage:** The phone can store up to 6 groups of incoming call numbers, with dynamic storage for up to 53 groups of 8-digit incoming calls.
- **Quick Dial (M1/M2):** Use the M1 and M2 buttons for quick dialing of frequently used numbers. Refer to the specific instructions for setting these memory locations.
- **Single Key Memory:** Stores up to 72 groups of 12-bit numbers.
- **Double Key Memory:** Stores up to 10 groups of 12-bit numbers.

Blacklist Function:

You can set up to 5 groups of 16-bit blacklist numbers. When a call comes from a blacklisted number, the telephone will automatically hang up.

VIP Numbers:

Up to 11 caller IDs can be designated as VIP numbers. These numbers are protected from accidental deletion.

Local Code and Outgoing Code:

The phone supports a 5-digit local code and a single outgoing code for specific dialing requirements.

5. MAINTENANCE

5.1 Cleaning:

To clean your telephone, wipe it with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the surface. Ensure the phone is disconnected from the telephone line before cleaning.

5.2 Storage:

If you plan to store the telephone for an extended period, disconnect it from the telephone line and store it in a cool, dry place away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

If you experience issues with your telephone, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No dial tone.	Telephone line not connected properly or line issue.	Ensure the telephone line cord is securely connected to both the phone and the wall jack. Test with another phone if possible.
Cannot hear caller / Caller cannot hear me.	Handset cord loose or Mute function activated.	Check that the coiled handset cord is securely connected. If during a call, press the MUTE button to deactivate it.
Caller ID not displaying or displaying incorrectly.	Caller ID service not active or display format.	Ensure you have Caller ID service from your telephone provider. The display format may show numbers without dashes or spaces.
Phone does not ring.	Ringer volume set to low or off.	Adjust the ringer volume switch (HI/LO) on the side or back of the phone.

7. SPECIFICATIONS

Feature	Detail
Model Number	T112
Brand	Ornin
Color	Black
Phone Type	Corded
Power Source	Corded Electric
Material	Plastic
Keypad Type	Single Keypad
Caller ID Support	FSK and DTMF (Automatic Detection)
Memory	Outgoing: Max 16 groups; Incoming: Max 6 groups (53 groups dynamic); M1/M2 Quick Dial; 72 groups 12-bit single key; 10 groups 12-bit double key
Blacklist	Up to 5 groups of 16-bit numbers
VIP Numbers	Up to 11 caller IDs (deletion protected)
Product Weight	308 grams
Product Dimensions (Approx.)	Length: 21 cm (8.26 in), Width: 6.5 cm (2.56 in), Depth: 6 cm (2.36 in)

8. WARRANTY AND SUPPORT

8.1 Warranty Information:

Please refer to the warranty card included with your purchase for specific warranty terms and conditions. Keep your proof of purchase for any warranty claims.

8.2 Customer Support:

For technical assistance or customer service inquiries, please contact your retailer or the manufacturer's support channels as indicated on the product packaging or official website.