

[Manuals.plus](#) /

› [Sunnyglade](#) /

› Sunnyglade 4-Piece 200LB Square Patio Umbrella Base Instruction Manual

Sunnyglade B07KXPP3VX

Sunnyglade 4-Piece 200LB Square Patio Umbrella Base Instruction Manual

Model: B07KXPP3VX

INTRODUCTION

Thank you for choosing the Sunnyglade 4-Piece 200LB Square Patio Umbrella Base. This manual provides essential information for the safe and proper assembly, operation, and maintenance of your umbrella base. Please read these instructions carefully before use and retain them for future reference.

SAFETY INFORMATION

- Always ensure the umbrella base is fully filled with sand or water to achieve maximum stability before inserting an umbrella.
- Do not use the umbrella base on uneven surfaces. Ensure it is placed on a flat, stable ground.
- In strong winds or severe weather conditions, close and secure your patio umbrella, or remove it from the base to prevent damage or injury.
- Keep children and pets away from the umbrella base during assembly and when an umbrella is in use.
- Regularly inspect the base for any signs of wear or damage. Do not use if damaged.
- This base is designed for cantilever offset patio umbrellas with a cross bar base (cross bar base not included).

PACKAGE CONTENTS

Verify that all components are present before beginning assembly.

- 4 x Square Base Plates (Black, High Density Polyethylene)
- 4 x Fill Caps (pre-installed on plates)
- Necessary connecting hardware (e.g., screws, washers)



Image: A side view of the four individual square base plates stacked, illustrating their compact design before assembly.

Note: A cross bar base for your umbrella is required and is not included with this product.

SETUP INSTRUCTIONS

Step 1: Prepare the Location

Choose a flat, stable surface for your patio umbrella. Ensure there is enough space for the umbrella to open and close without obstruction.

Step 2: Position the Cross Bar Base

Place your cantilever umbrella's cross bar base (not included) in the desired location.

Handle design



Image: A hand demonstrates placing one of the square base plates onto a standard cross bar umbrella base.

Step 3: Place the Base Plates

Carefully place each of the four square base plates onto the arms of the cross bar base. Ensure they fit securely and are aligned around the central pole receiver.



Image: An overhead view showing the four square base plates correctly positioned on a cross bar base, surrounding the central pole receiver.

Step 4: Fill the Base Plates

Unscrew the fill cap on each plate. Fill each plate with either water or sand. For maximum stability, it is recommended to fill with sand, which provides approximately 200 pounds of total weight when all four plates are filled. Ensure each plate is completely filled.



Image: A close-up of one square base plate, highlighting the circular fill cap for adding water or sand.

After filling, securely screw the fill caps back onto each plate to prevent leakage.

Step 5: Secure the Umbrella Pole

Insert your umbrella pole into the central receiver of the cross bar base. Tighten any securing knobs or bolts on your umbrella's cross base to hold the pole firmly in place.



Image: The fully assembled 4-piece base with the central pole receiver visible, indicating readiness for an umbrella pole.

OPERATING INSTRUCTIONS

Filling and Emptying

The base plates are designed with easy-to-access fill spouts. To fill, unscrew the cap and pour water or sand into the opening. To empty, unscrew the cap and tilt the plate to drain water or pour out sand. For sand, a funnel may be helpful.

Placement

Always place the umbrella base on a level, stable surface. Ensure the weight is evenly distributed across all four plates for optimal stability.

MAINTENANCE

- **Cleaning:** Clean the base plates with mild soap and water. Avoid abrasive cleaners that may damage the HDPE plastic.
- **Inspection:** Periodically check the fill caps to ensure they are tightly sealed. Inspect the plates for any cracks or damage, especially after severe weather.

- **Storage:** During winter months or extended periods of non-use, it is recommended to empty the plates (especially if filled with water to prevent freezing and cracking) and store them in a dry, protected area. The plates feature a handle design on the bottom for easier transport when empty.



Image: The underside of a base plate, illustrating the recessed handle for easy carrying.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Umbrella base is unstable.	Plates not fully filled; uneven surface; umbrella too large for base weight.	Ensure all plates are completely filled with sand or water. Move to a level surface. Confirm umbrella size is appropriate for a 200LB base.
Water leakage from plates.	Fill caps not tightened; crack in plate.	Tighten fill caps securely. Inspect plates for damage; if cracked, replace the affected plate.

Problem	Possible Cause	Solution
Difficulty filling with sand.	Small opening; sand clumping.	Use a funnel to aid filling. Ensure sand is dry and free of clumps.

SPECIFICATIONS

Brand	Sunnyglade
Model Number	B07KXPP3VX
Material	High Density Polyethylene (HDPE)
Color	Black
Plate Dimensions (each)	20"D x 4.7"W x 20"H (50.8cm D x 11.9cm W x 50.8cm H)
Total Fill Weight Capacity	Up to 200 lbs (when filled with sand)
Features	Waterproof, Weather Resistant, UV Protection Coating, Easy-to-fill Spout, Handle Design
Assembly Required	Yes
Compatibility	Suitable for cantilever offset patio umbrellas with a cross bar base (cross bar base not included)

WARRANTY AND SUPPORT

Sunnyglade products are manufactured to high-quality standards. For specific warranty information or technical support, please refer to the documentation included with your purchase or contact Sunnyglade customer service directly. Contact information can typically be found on the product packaging or the manufacturer's official website. Please have your model number (B07KXPP3VX) and purchase date available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question