RIVA RWF01

RIVA Audio Tabletop Multiroom Digital Music System RWF01 User Manual

Model: RWF01

Introduction

This manual provides essential instructions for the setup, operation, maintenance, and troubleshooting of your RIVA Audio Tabletop Multiroom Digital Music System, model RWF01. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your listening experience.



Image: RIVA Audio Tabletop Multiroom Digital Music System RWF01. This image displays the front view of the RWF01 speaker, showcasing its compact design and speaker grille.

Package Contents

Before proceeding with the setup, ensure all components are present in the package:

- RIVA Audio Tabletop Multiroom Digital Music System (RWF01)
- Power Adapter
- Quick Start Guide (this manual serves as a comprehensive guide)

Setup

1. Power Connection

1. Place the RWF01 system on a stable, flat surface.

2. Connect the power adapter to the DC input port on the back of the RWF01.
3. Plug the power adapter into a standard AC power outlet. The system will power on automatically.

2. Initial Network Configuration (Wi-Fi)

The RWF01 supports Wi-Fi connectivity for multiroom audio and streaming services.

1. Download the RIVA Audio app from your device's app store (iOS or Android).
2. Open the RIVA Audio app and follow the on-screen instructions to add your RWF01 system.
3. The app will guide you through connecting the RWF01 to your home Wi-Fi network.
4. Ensure your smartphone or tablet is connected to the same Wi-Fi network you intend to use for the RWF01.

3. Bluetooth Pairing

For direct audio streaming from a Bluetooth-enabled device:

1. Press and hold the Bluetooth button on the RWF01 until the Bluetooth indicator light begins to flash.
2. On your smartphone or tablet, navigate to the Bluetooth settings.
3. Select "RIVA RWF01" from the list of available devices.
4. Once paired, the Bluetooth indicator light on the RWF01 will glow solid.

Operating Instructions

Controls Overview

The RWF01 can be controlled via the RIVA Audio app, voice commands (with Google Assistant), or the physical buttons on the unit.

- **Power Button:** Press to turn on/off.
- **Volume Up/Down:** Adjusts audio output level.
- **Play/Pause:** Controls media playback.
- **Source Button:** Cycles through input sources (Wi-Fi, Bluetooth, Aux).
- **Bluetooth Button:** Initiates Bluetooth pairing mode.

Streaming Music

The RWF01 supports various streaming methods:

- **Wi-Fi Streaming:** Use the RIVA Audio app or compatible services like Spotify Connect, AirPlay, or Chromecast built-in to stream audio over your Wi-Fi network. This allows for high-resolution audio playback up to 24-bit/192kHz.
- **Bluetooth Streaming:** Connect your device via Bluetooth as described in the Setup section.
- **Auxiliary Input:** Connect an external audio source using a 3.5mm audio cable (not included) to the AUX input port.

Multiroom Audio

To create a multiroom audio system, add multiple RIVA Audio devices to the RIVA Audio app. You can group speakers to play the same music in different rooms or play different music on each speaker.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your RIVA RWF01 system.

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the unit. Do not use liquid cleaners or abrasive materials.

- **Placement:** Avoid placing the unit in direct sunlight, near heat sources, or in areas with high humidity. Ensure adequate ventilation around the speaker.
- **Storage:** If storing the unit for an extended period, disconnect it from power and store it in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
No power	Power cable not connected; power outlet not active.	Ensure power cable is securely connected to the unit and a working power outlet.
Cannot connect via Bluetooth	Device not in pairing mode; RWF01 already paired with another device; interference.	◦ Ensure RWF01 is in Bluetooth pairing mode (flashing light). ◦ Disconnect RWF01 from any previously paired devices. ◦ Move Bluetooth devices closer to each other. ◦ Restart both the RWF01 and your Bluetooth device.
No sound from Wi-Fi streaming	RWF01 not connected to Wi-Fi; app not configured correctly; network issues.	◦ Verify RWF01 is connected to your Wi-Fi network via the RIVA Audio app. ◦ Check your router and internet connection. ◦ Ensure the correct input source is selected on the RWF01 or in the app.
Sound distortion	Volume too high; audio source quality; interference.	◦ Reduce the volume on both the RWF01 and the audio source. ◦ Try a different audio source or streaming service. ◦ Ensure no strong electromagnetic interference sources are nearby.

Specifications

Feature	Detail
Model	RWF01
Brand	RIVA
Speaker Type	Multi Room
Connectivity Technology	Bluetooth, Wi-Fi
Audio Output Mode	Stereo
Speaker Maximum Output Power	200 Watts

Feature	Detail
Control Method	Voice (with Google Assistant), App, Physical Buttons
Power Source	AC
Product Dimensions	14.37 x 7.87 x 7 inches
Item Weight	16.7 pounds
UPC	090952232642

Warranty and Support

This product is a Certified Refurbished item and comes with a minimum 90-day warranty. For warranty claims or technical support, please refer to the Amazon Renewed Guarantee policy or contact the seller directly.
For further assistance, you may also visit the official RIVA Audio website or consult their support resources.

© 2024 RIVA Audio. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question