

[Manuals.plus](#) /

› [FASTSNAIL](#) /

› FastSnail Charging Dock for Nintendo Switch & OLED Model Joy-Con Controllers (Model TNS-875) - Instruction Manual

FASTSNAIL TNS-875

FastSnail Charging Dock for Nintendo Switch & OLED Model Joy-Con Controllers

Model: TNS-875 | Brand: FASTSNAIL

1. INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your FastSnail Charging Dock. This device is designed to efficiently charge up to four Nintendo Switch or Nintendo Switch OLED Model Joy-Con controllers simultaneously.



Figure 1: FastSnail Charging Dock with Joy-Cons and USB cable.

2. WHAT'S IN THE BOX

- 1 x FastSnail Joy-Con Charge Dock
- 1 x 3FT Charging Cable (USB Type-C)

3. FEATURES

- **4-Controller Charging:** Charges up to four Joy-Con controllers simultaneously.
- **LED Indicators:** Individual lampposts indicate the charging status for each Joy-Con (Red for charging, Green for fully charged/empty slot).
- **Fast Charging:** Designed for efficient power delivery.

- **Compact Design:** Lightweight and portable, serving as both a charging station and a storage stand.
- **Safety Protections:** Includes over-charging, over-temperature, short-circuit, and over-voltage protection.
- **Multiple Power Supply Options:** Can be powered via AC adapter, USB hub, or directly from the Nintendo Switch console.



Figure 2: LED indicators for charging status (Red: Charging, Green: Fully Charged/Empty).

SAFE AND CHARGING PROTECTION

No need to remove joycons when fully charged



Figure 3: Built-in safety protections of the charging dock.

4. SETUP INSTRUCTIONS

1. **Connect Power:** Connect the provided USB Type-C charging cable to the port on the back of the FastSnail Charging Dock.
2. **Power Source:** Plug the other end of the USB cable into a suitable power source. This can be a USB port on your Nintendo Switch dock, a USB hub, or an AC adapter (not included).
3. **Verify Power:** Once connected, the LED lampposts on the dock will illuminate green, indicating that the dock is powered on and ready to charge.

MULTIPLE POWER SUPPLY WAYS



Figure 4: Connecting the charging dock to a power source.

5. OPERATING INSTRUCTIONS

1. **Insert Joy-Cons:** Gently slide your Nintendo Switch Joy-Con controllers into the available slots on the charging dock. Ensure they are fully seated to establish a proper connection.
2. **Monitor Charging Status:** The individual LED lampposts will change color to indicate the charging status:
 - **Red:** The Joy-Con is currently charging.
 - **Green:** The Joy-Con is fully charged, or the slot is empty.
3. **Remove Joy-Cons:** Once the LED indicator turns green, your Joy-Con controllers are fully charged and ready for use. Simply slide them out of the dock.

STORAGE 4 JOYCON SIMULTANEOUSLY

Save space and always be ready for your game!



Figure 5: Inserting Joy-Cons into the charging dock.

6. MAINTENANCE

- Keep the charging dock clean and free from dust. Use a soft, dry cloth for cleaning.
- Avoid exposing the device to water or excessive moisture.
- Do not attempt to disassemble or repair the unit yourself. Contact customer support if issues arise.

7. TROUBLESHOOTING

- **Controllers not charging:**
 - Ensure the charging cable is securely connected to both the dock and the power source.
 - Verify the power source is active.
 - Make sure the Joy-Cons are fully inserted into the charging slots.
 - Try using a different USB port or power adapter.
- **LED indicators not working:**
 - Check the power connection as described above.

- If the issue persists, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	TNS-875
Compatible Devices	Nintendo Switch, Nintendo Switch OLED Joy-Con Controllers
Connector Type	USB Type C
Input Voltage	5 Volts
Amperage	2000 Milliamps
Total USB Ports	1
Item Weight	5.3 ounces
Package Dimensions	5.87 x 3.58 x 2.05 inches

9. WARRANTY AND SUPPORT

FastSnail products are designed for reliability and performance. For any questions, technical support, or warranty inquiries, please refer to the contact information provided with your product packaging or visit the official FastSnail website. Please retain your proof of purchase for warranty claims.