

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Eglo](#) /

› **EGLO TOCOPILLA Wall Lamp Instruction Manual (Model 97916)**

Eglo 97916

EGLO TOCOPILLA Wall Lamp Instruction Manual (Model 97916)

Your guide to safe installation, operation, and maintenance.

1. IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before installation and use. Keep this manual for future reference.

- Always disconnect the power supply at the main fuse or circuit breaker before installation, maintenance, or changing the light bulb.
- This product is rated IP20, meaning it is protected against solid objects over 12.5mm but has no protection against water. It is intended for indoor use only.
- If you are unsure about the installation process, consult a qualified electrician.
- Do not exceed the maximum wattage specified for the light bulb.
- Ensure all connections are secure and correctly installed to prevent electrical hazards.

2. PRODUCT OVERVIEW

The EGLO TOCOPILLA wall lamp (Model 97916) features a modern design with a wooden frame and a white metal bulb holder. It is designed for wall mounting and includes an integrated switch on its cable for convenient operation.





Image: Front view of the EGLO TOCOPILLA wall lamp, showcasing its wooden arm and white bulb holder with a vintage-style LED bulb.

Dimensions

mm / inch



Image: Technical drawing illustrating the dimensions of the EGLO TOCOPILLA wall lamp. Height (H) is 275 mm (10.83 inches), Length (L) is 60 mm (2.36 inches), and Arm depth (A) is 180 mm (7.08 inches).

Dimensions: 6 x 18 x 27.5 cm (Length x Width x Height)

Weight: 515 g

Material: Alloy Steel, Wood

Color: Brown (wood), White (bulb holder)

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 1 x EGLO TOCOPILLA Wall Lamp Unit (Model 97916)

- 1 x Integrated Switch (on cable)
- Mounting Hardware (screws, wall plugs)
- Instruction Manual

Note: The light bulb is not included and must be purchased separately.

4. SETUP AND INSTALLATION

Follow these steps to safely install your EGLO TOCOPILLA wall lamp:

1. **Prepare the Installation Area:** Choose a suitable indoor wall location. Ensure there are no hidden electrical wires or pipes in the drilling area.
2. **Mark Drilling Points:** Hold the lamp unit against the wall at the desired height and use a pencil to mark the positions for the mounting screws.
3. **Drill Holes:** Using an appropriate drill bit for your wall type, drill holes at the marked positions. Insert the provided wall plugs flush with the wall surface.
4. **Mount the Lamp:** Align the lamp's mounting holes with the drilled holes. Insert the screws through the lamp and into the wall plugs. Tighten the screws securely, but do not overtighten.
5. **Install the Light Bulb:** Carefully screw an E27 base light bulb into the lamp holder. Ensure the bulb's wattage does not exceed 10W.
6. **Connect to Power:** Plug the lamp's power cord into a standard electrical outlet.




Image: Diagram showing the installation steps for the EGLO TOCOPILLA wall lamp, including mounting to the wall with screws and connecting the power cord to an outlet.

5. OPERATING INSTRUCTIONS

To operate your EGLO TOCOPILLA wall lamp:

- Ensure the lamp is properly installed and plugged into a functioning electrical outlet.
- Use the integrated switch located on the power cable to turn the lamp ON or OFF.
- The lamp supports E27 base bulbs. LED bulbs are recommended for energy efficiency and longevity.
- Dimmability depends on the type of E27 bulb used. If you wish to use a dimmable function, ensure

your chosen bulb is dimmable.

6. MAINTENANCE AND CARE

Proper care will ensure the longevity and appearance of your lamp:

- **Cleaning:** Disconnect the lamp from the power supply before cleaning. Wipe the lamp with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:** Always disconnect the power supply before replacing the light bulb. Allow the old bulb to cool completely before removing it. Screw in the new E27 bulb, ensuring it does not exceed the maximum wattage of 10W.

7. TROUBLESHOOTING

If you encounter issues with your lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power to the outlet. Bulb is faulty or loose. Switch is off.	Check the power outlet with another device. Ensure the bulb is screwed in tightly. Replace the bulb if necessary. Ensure the integrated switch is in the 'ON' position.
Bulb flickers.	Loose bulb connection. Faulty bulb. Incompatible dimmer (if applicable).	Tighten the bulb. Replace the bulb. Ensure the bulb is compatible with any dimmer switch in use.

8. SPECIFICATIONS

Feature	Specification
Brand	Eglo
Model Number	97916
Product Dimensions	6 x 18 x 27.5 cm
Product Weight	515 g
Material	Alloy Steel, Wood
Color	Brown (wood), White (bulb holder)
Voltage	240 Volts
Bulb Type	E27 (LED recommended)
Max. Bulb Wattage	10W
IP Rating	IP20 (Indoor use only)
Special Feature	Integrated cable switch, Dimmable (with compatible bulb)

9. WARRANTY AND SUPPORT

EGLO products are manufactured to high-quality standards. For information regarding warranty terms and conditions, please refer to the official EGLO website or contact your retailer.

For technical support or further assistance, please visit the [Eglo Brand Store](#) or contact EGLO customer service directly.