



Manuals.plus /

› Samsung /

› Samsung Microwave Grease Filter Instruction Manual

## Samsung 670267

# Samsung Microwave Grease Filter Instruction Manual


Model: 670267

Applicable to models: ME21M706BAS, ME21M706BAS/AA, MMV1153BAB, MMV1153BAS, MMV1153BAW, and other compatible Samsung microwave ovens.

## 1. PRODUCT OVERVIEW

---

This document provides essential information for the proper installation, maintenance, and care of your OEM Samsung Microwave Grease Filter. This filter is designed to capture grease particles from the air during cooking, helping to maintain the cleanliness and efficiency of your microwave oven's ventilation system.



An image showing the rectangular metallic mesh of the Samsung OEM Microwave Grease Filter. The filter features a fine mesh screen within a sturdy metal frame, designed to trap grease effectively.

## 2. INSTALLATION (SETUP)

---

The grease filter is typically located on the underside of the microwave oven. Refer to your specific microwave oven's user manual for exact filter location and removal/installation instructions, as designs may vary slightly.

### General Installation Steps:

1. **Safety First:** Disconnect power to the microwave oven at the circuit breaker before proceeding with installation or removal.
2. **Locate Filter Slots:** Identify the filter slots on the underside of your microwave. There are usually one or two filters.
3. **Remove Old Filter (if applicable):** If replacing an old filter, gently push the old filter towards the back of the microwave and pull down to release it from the front tabs.
4. **Insert New Filter:** Insert the new grease filter by pushing it up into the filter slots. Ensure the rear edge of the filter is fully seated in the slot.
5. **Secure Filter:** Push the front edge of the filter up until it snaps securely into place. It should sit flush with the microwave's underside.
6. **Restore Power:** Reconnect power to the microwave oven.

Ensure the filter is installed correctly to prevent it from falling during microwave operation and to ensure proper ventilation.

## 3. OPERATION AND PURPOSE

---

The grease filter operates passively as part of your microwave oven's ventilation system. When the microwave's

exhaust fan is running (e.g., during cooking or when manually activated), air containing cooking odors and grease particles is drawn through the filter. The metallic mesh traps these grease particles, preventing them from accumulating within the exhaust ductwork and on internal components of the microwave.

A clean and properly installed grease filter is essential for:

- Maintaining efficient air circulation and odor removal.
- Protecting internal microwave components from grease buildup.
- Reducing fire hazards associated with excessive grease accumulation.

## 4. MAINTENANCE

---

Regular cleaning of the grease filter is crucial for optimal performance and longevity of your microwave oven. Depending on cooking frequency, filters should be cleaned monthly or more often if cooking greasy foods.

### Cleaning Instructions:

1. **Safety First:** Disconnect power to the microwave oven at the circuit breaker.
2. **Remove Filter:** Carefully remove the grease filter as described in the "Installation" section.
3. **Wash Filter:** Wash the filter in hot water using a mild detergent. You can also wash it in a dishwasher. Avoid using abrasive cleaners or scrub brushes that could damage the mesh.
4. **Rinse and Dry:** Rinse thoroughly with clean water and allow the filter to air dry completely before reinstallation. Ensure no water drips from the filter.
5. **Reinstall Filter:** Reinstall the dry filter into the microwave oven, ensuring it is securely in place.
6. **Restore Power:** Reconnect power to the microwave oven.

If the filter becomes excessively clogged or damaged and cannot be cleaned effectively, it should be replaced with a genuine OEM Samsung part.

## 5. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Filter does not fit or is loose.	Incorrect filter model or improper installation.	Verify the filter model number (670267) matches your microwave's requirements. Ensure the filter is inserted correctly into the slots and snapped into place.
Microwave fan seems less effective.	Clogged grease filter.	Clean the grease filter thoroughly. If cleaning does not restore performance, replace the filter.
Grease dripping from microwave underside.	Filter is saturated or missing.	Clean or replace the grease filter. Ensure the filter is properly installed.

If issues persist after troubleshooting, consult a qualified service technician or refer to your microwave oven's main user manual.

## 6. SPECIFICATIONS

---

- **Brand:** Samsung
- **Model Number:** 670267
- **Item Weight:** 3.2 ounces
- **Package Dimensions:** 13.98 x 7.87 x 1.54 inches
- **Part Number:** 670267
- **Special Features:** Ergonomic (referring to ease of handling for installation/removal)
- **Compatible Devices:** SMH9151B/XAA, SMH8165ST/XAA, ME18H704SFS/AA, ME21M706BAS/AA, and many other Samsung microwave models. (A full list is available in the product details or your microwave's manual).

## 7. WARRANTY INFORMATION

---

Specific warranty details for this OEM Samsung Microwave Grease Filter are typically provided with the original purchase or can be found on the official Samsung website or by contacting Samsung customer support. Please retain your proof of purchase for warranty claims.

## 8. CUSTOMER SUPPORT

---

For further assistance, technical support, or to inquire about replacement parts, please visit the official Samsung support website or contact their customer service hotline. Contact information can usually be found in your microwave oven's main user manual or on the Samsung official website.

You can also visit the Samsung Store on Amazon for more product information and support resources.