

PRITECH PBP-154

PRITECH PBP-154 Ultra-Slim Wired Spanish Keyboard User Manual

Model: PBP-154

1. INTRODUCTION

Thank you for choosing the PRITECH PBP-154 Ultra-Slim Wired Spanish Keyboard. This manual provides essential information for setting up, operating, and maintaining your new keyboard. Please read it carefully to ensure optimal performance and longevity of your device.

2. PRODUCT OVERVIEW

2.1 Key Features

- **Ultra-Slim Design:** Compact dimensions (288 x 122 x 22 mm) for space-saving and portability.
- **Durable Keys:** Designed to withstand over 10 million keystrokes.
- **Anti-Liquid Design:** Features a short-circuit prevention system to protect against accidental spills. *Note: This keyboard is not waterproof. Refer to Maintenance for spill handling.*
- **Wired USB Connection:** Ensures stable and fast response, eliminating the need for batteries.
- **Spanish Layout:** Includes the 'Ñ' key and other specific characters for Spanish language input.
- **Plug and Play:** No software installation required; simply connect to a USB port to begin use.
- **Ergonomic Inclination:** Features a slight 5-degree tilt for comfortable typing.

2.2 Package Contents

- 1 x PRITECH PBP-154 Wired Spanish Keyboard

2.3 Product Views



Figure 1: Top view of the PRITECH PBP-154 keyboard, showing the full Spanish layout and attached USB cable.




Figure 2: Side view illustrating the keyboard's ultra-slim profile and ergonomic 5-degree typing inclination.

3. SETUP INSTRUCTIONS

1. **Unpack the Keyboard:** Carefully remove the keyboard from its packaging.
2. **Connect to USB Port:** Locate an available USB port on your computer (desktop, laptop, or compatible device). Insert the USB connector of the keyboard firmly into the USB port.
3. **Automatic Recognition:** Your operating system (e.g., Windows) should automatically detect

and install the necessary drivers for the keyboard. This process typically takes a few seconds.

4. **Begin Use:** Once recognized, the keyboard is ready for immediate use. No additional software or configuration is required.

4. OPERATING INSTRUCTIONS

The PRITECH PBP-154 keyboard features a standard Spanish QWERTY layout with 78 keys, including function keys (F1-F12) and dedicated keys for common operations.

- **Standard Typing:** Use the alphanumeric keys for text input.
- **Function Keys (F1-F12):** These keys perform various system functions, which may vary depending on your operating system and active applications.
- **Special Characters:** Access special characters by using the Shift key in combination with other keys. For example, to type the 'Ñ' character, simply press the dedicated 'Ñ' key.
- **Caps Lock:** Press the "Bloq Mayús" key to toggle uppercase letters. An indicator light (if present on your system) will show its status.
- **Navigation Keys:** Utilize the arrow keys, Home, End, Page Up (Re Pág), and Page Down (Av Pág) for document navigation.



Figure 3: Detail of the 'Ñ' key, highlighting the Spanish keyboard layout feature.

5. MAINTENANCE

5.1 Cleaning

- **Disconnect:** Always disconnect the keyboard from your computer before cleaning.
- **Surface Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the surface of the keyboard. Avoid harsh chemicals or abrasive materials.
- **Between Keys:** Use compressed air to remove dust and debris from between the keys. A soft brush can also be used.
- **Drying:** Ensure the keyboard is completely dry before reconnecting it to your computer.

5.2 Handling Liquids

While the keyboard features an anti-liquid design to prevent short-circuits, it is **not waterproof**. In case of accidental liquid spills:

1. **Immediately Disconnect:** Unplug the keyboard from your computer.
2. **Wipe Excess Liquid:** Gently wipe away any visible liquid from the surface.
3. **Dry Thoroughly:** Use a hairdryer on a cool setting or place the keyboard in a well-ventilated area to dry completely. Allow sufficient time for all moisture to evaporate before attempting to use it again.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard not responding	Loose USB connection, faulty USB port, driver issue.	<ul style="list-style-type: none">• Ensure the USB cable is securely plugged into the computer.• Try connecting the keyboard to a different USB port.• Restart your computer.• Check your operating system's device manager for keyboard driver status.
Keys are not typing correctly or are sticky	Debris under keys, liquid damage.	<ul style="list-style-type: none">• Clean the keyboard as described in the Maintenance section.• If liquid damage is suspected, follow the liquid handling procedure.
Keyboard moves excessively during use	Uneven surface, lack of grip.	<ul style="list-style-type: none">• Ensure the keyboard is placed on a flat, stable surface.• Consider using a non-slip mat underneath the keyboard.

7. SPECIFICATIONS



Figure 4: Dimensions of the PRITECH PBP-154 keyboard.

Brand	PRITECH
Model	PBP-154
Color	Black
Connectivity Technology	Wired USB
Number of Keys	78
Keyboard Layout	Spanish (QWERTY)
Dimensions (L x W x H)	288 x 122 x 22 mm (approx. 29.6 x 14.2 x 3 cm package dimensions)
Weight	300 g
Compatible Operating Systems	Windows (and generally compatible with other OS supporting USB keyboards)
Batteries Required	No

8. SAFETY INFORMATION

- Do not expose the keyboard to excessive moisture or immerse it in water.
- Avoid extreme temperatures.
- Keep out of reach of children.
- Do not attempt to disassemble or repair the keyboard yourself. This may void any warranty.
- Use only with compatible devices and USB ports.







9. WARRANTY AND SUPPORT

PRITECH products are designed for reliability and performance. For specific warranty details, please refer to the warranty card included with your purchase or contact your retailer. If you encounter any issues not covered in the troubleshooting section, please contact PRITECH customer support through their official website or the contact information provided with your product.

For further assistance, you may visit the [PRITECH brand page on Amazon.es](#).

© 2023 PRITECH. All rights reserved.

Related Documents - PBP-154

	<p>PRITECH RSM-1505 Rechargeable Men's Grooming Set - Instruction Manual</p> <p>User manual for the PRITECH RSM-1505 rechargeable men's grooming set, covering introduction, product structure, charging, usage, cleaning, maintenance, and warranty information.</p>
	<p>PRITECH RSM-1928C Body Hair Trimmer: User Manual & Features</p> <p>Comprehensive user manual for the PRITECH RSM-1928C Body Hair Trimmer. Learn about its features, technical specifications, charging, cleaning, blade replacement, and guard comb installation. Includes IPX6 waterproof design and USB charging.</p>
	<p>PRITECH LD-8001 Lady Shaver User Manual and Instructions</p> <p>Comprehensive user manual for the PRITECH LD-8001 Lady Shaver, detailing features, specifications, charging, usage, maintenance, and warranty information.</p>
	<p>PRITECH BCM-1138 Electric Callus Remover User Manual</p> <p>User manual for the PRITECH BCM-1138 Electric Callus Remover, detailing product features, usage instructions, charging, cleaning, safety warnings, and warranty information.</p>
	<p>PRITECH RSM-1577 Electric Shaver User Manual</p> <p>User manual for the PRITECH RSM-1577 electric shaver, covering features, charging, usage, cleaning, maintenance, and warranty information.</p>
	<p>PRITECH TA-2413 Hair Straightener User Manual and Instructions</p> <p>Comprehensive user manual for the PRITECH TA-2413 Hair Straightener, covering specifications, safety precautions, operating instructions, troubleshooting, and warranty information.</p>

