

[manuals.plus](#) /› [Anker](#) /› [Anker AK-A2523011 PowerWave Evo Stand Wireless Charger User Manual](#)

Anker AK-A2523011

Anker AK-A2523011 PowerWave Evo Stand Wireless Charger User Manual

Model: AK-A2523011

1. INTRODUCTION

The Anker PowerWave Evo Stand is a high-speed wireless charging stand designed for Qi-compatible devices. It supports both horizontal and vertical charging orientations, offering convenience for various uses. This manual provides instructions for the safe and efficient use of your PowerWave Evo Stand.

Key Features:

- Universal Fast Charging: Delivers optimal charging speeds for compatible devices.
- Case Compatibility: Charges through phone cases up to 5mm thick.
- Flexible Charging: Supports both horizontal and vertical device placement.
- Intelligent Power Delivery: Automatically detects your device to provide 5W, 7.5W (for iPhone 8/8 Plus/X), or 10W (for Samsung).



Image 1.1: Anker PowerWave Evo Stand, Quick Charge 3.0 wall charger, and Micro USB cable.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- 1x Anker PowerWave Evo Stand
- 1x Quick Charge 3.0 Wall Charger
- 1x 3 ft Micro USB Cable

3. SETUP INSTRUCTIONS

1. Connect the Micro USB cable to the input port on the PowerWave Evo Stand.
2. Plug the other end of the Micro USB cable into the Quick Charge 3.0 wall charger.
3. Insert the Quick Charge 3.0 wall charger into a power outlet. The indicator light on the stand will briefly illuminate, indicating it is ready for use.

4. OPERATING INSTRUCTIONS

To charge your device:

1. Ensure the PowerWave Evo Stand is properly connected to a power source as described in the Setup section.
2. Place your Qi-compatible smartphone directly onto the charging surface of the stand. The phone can be placed in either a vertical (portrait) or horizontal (landscape) orientation.
3. The indicator light on the stand will turn blue to confirm that charging has begun. If the light flashes blue, a

foreign object may be detected, or the device is not properly aligned.

4. For optimal charging, ensure your phone is centered on the stand's charging coil.




Image 4.1: Device placement for charging in portrait and landscape modes.

Case Compatibility

The PowerWave Evo Stand is designed to charge through most phone cases up to 5mm thick. However, certain materials and attachments can interfere with wireless charging.

- Remove any metal attachments, magnets, grips, stands, or credit cards from the back of your phone case before placing it on the charger.
- Thicker cases (over 5mm) may prevent charging.

Case Friendly



Magnetic or metal attachments and other foreign objects will interfere with charging.

Image 4.2: Case compatibility guidelines for wireless charging.

5. SAFETY INFORMATION

To ensure safe operation and prevent damage to the device or personal injury, please observe the following:

- **Foreign Object Detection (FOD):** The charger is equipped with technology to detect misplaced metal objects. If a foreign object is detected, the charging process will halt to ensure safety.
- **Overcurrent Protection:** This feature prevents damage to both the charger and connected devices from power surges.
- **Certified Safe:** The device complies with FCC and CE certifications, ensuring protection from harmful radiation and adherence to safety standards.
- Do not expose the device to extreme temperatures, direct sunlight, or wet conditions.
- Do not disassemble or attempt to repair the device. Contact customer support for assistance.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)

This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

6. TROUBLESHOOTING

- **Device not charging:**

- Ensure the PowerWave Evo Stand is properly connected to the Quick Charge 3.0 wall charger and a working power outlet.
- Verify that your phone is Qi-compatible.
- Remove any metal objects, magnets, credit cards, or thick cases (over 5mm) from your phone or phone case.
- Re-position your phone on the charging stand to ensure proper alignment with the charging coil.
- Try using a different power outlet.

- **Charging is slow:**

- Ensure you are using the included Quick Charge 3.0 wall charger and Micro USB cable, as other chargers may not provide sufficient power for fast wireless charging.
- Confirm your phone supports fast wireless charging.
- Remove any phone cases that might be impeding charging efficiency.

- **Indicator light flashing blue:**

- This indicates a foreign object has been detected or the phone is not correctly placed. Remove the phone, check for any foreign objects on the stand or phone, and re-position the phone.

7. SPECIFICATIONS

Model	AK-A2523011
Input	12V = 1.5A
Output	5W / 7.5W / 10W
Product Dimensions	4.5 x 3 x 2.7 inches
Item Weight	8 ounces
Connector Type	Wireless
Compatible Devices	Smartphones (Qi-compatible)
Compatible Phone Models	Apple iPhone 8, Apple iPhone 8 Plus, Apple iPhone X, Samsung devices supporting 10W wireless charging, and other Qi-compatible devices.
Cable Length	3 feet (Micro USB)
Manufacturer	ANKER TECHNOLOGY

8. MAINTENANCE

To maintain the performance and longevity of your PowerWave Evo Stand:

- Keep the charging surface clean and free of dust or debris. Use a soft, dry cloth for cleaning.

- Avoid dropping the device or subjecting it to strong impacts.
- Store the charger in a cool, dry place when not in use.

9. WARRANTY AND SUPPORT

The Anker PowerWave Evo Stand comes with an **18-month hassle-free warranty**.

For technical support, warranty claims, or other inquiries, please contact Anker customer service. Contact information can typically be found on the official Anker website or through your retailer.

[Visit Anker's Official Website](#) for more information and support resources.