



Manuals.plus /

› Lumineo /

› Lumineo 160 LED Warm White Flashing Polestar Instruction Manual

## Lumineo 160 LED Polestar

# Lumineo 160 LED Warm White Flashing Polestar Instruction Manual

Model: 160 LED Polestar

## INTRODUCTION

Thank you for choosing the Lumineo 160 LED Warm White Flashing Polestar. This product is designed to provide decorative lighting for both indoor and outdoor environments. It features 160 warm white LED lights on silver wire, creating a star-like display. This manual provides important information regarding the safe installation, operation, and maintenance of your Polestar light.

## SAFETY INFORMATION

- Read all instructions before use.
- This product is UL588 Standard Certified, indicating compliance with safety standards for seasonal decorative lighting products.
- Ensure the power source matches the requirements specified on the product label.
- Do not connect to another lighting string or electrical supply.
- Do not secure the wiring of the product with staples or nails, or place it on sharp hooks or nails.
- Unplug the product when leaving the house, when retiring for the night, or if left unattended.
- Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
- Do not cover the product with cloth, paper, or any material not part of the product when in use.
- Do not immerse electrical components in water.
- Keep away from children and pets.

## PACKAGE CONTENTS

Verify that all components are present before proceeding with installation:

- 1 x Lumineo 160 LED Warm White Flashing Polestar (27-inch diameter)
- 1 x Power Adapter with 16.5-foot lead wire




Image: The Lumineo Polestar in its unlit state, showing the silver wire branches extending from a central point.

## SETUP AND INSTALLATION

1. **Unpack:** Carefully remove the Polestar light from its packaging.
2. **Unfold Branches:** The Polestar features posable silver wire branches. Gently spread out the branches to achieve the desired starburst shape. Be careful not to bend the wires too sharply or apply excessive force.
3. **Placement:**
  - For indoor use, hang the Polestar from a secure hook or fixture.
  - For outdoor use, ensure the hanging location is protected from extreme weather conditions, though the product is suitable for outdoor use. Secure it firmly to prevent movement in wind.
4. **Connect Power:** Plug the power adapter into a standard electrical outlet. The lead cable is 16.5 feet long, providing flexibility for placement. Ensure the UL-approved transformer is used.



Image: The Lumineo Polestar fully illuminated, showcasing its warm white flashing LED lights.

## OPERATING INSTRUCTIONS

---

The Lumineo Polestar light is designed for simple operation.

1. **Power On:** Once plugged into a power outlet, the Polestar lights will automatically illuminate and begin their flashing sequence.
2. **Power Off:** To turn off the lights, simply unplug the power adapter from the electrical outlet.
3. **Flashing Function:** The 160 LED lights are designed to flash, creating a dynamic visual effect. There is no manual control for the flashing pattern; it operates automatically.



Image: Three Lumineo Polestar lights displayed together in an outdoor covered area, demonstrating their decorative effect.

## MAINTENANCE

---

- **Cleaning:** Disconnect the power before cleaning. Wipe the Polestar gently with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the Polestar in its original packaging or a suitable container in a cool, dry place, away from direct sunlight and moisture. Carefully fold the branches to prevent damage.
- **Bulb Replacement:** The LED lights are integrated and not user-replaceable. The bulbs have an approximate life of 50,000 hours.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Lights do not turn on.	Not plugged in. Power outlet is not active. Damaged power adapter or wiring.	Ensure the power adapter is securely plugged into a working electrical outlet. Test the outlet with another device. Inspect the power adapter and lead wire for any visible damage. If damaged, discontinue use and contact support.
Some LEDs are not lighting up.	Individual LED failure.	LEDs are integrated and not user-replaceable. A few non-working LEDs typically do not affect the overall functionality of the string. If a significant number fail, contact support.
Flashing pattern is inconsistent or stops.	Internal circuit issue.	Unplug the unit for a few minutes, then plug it back in. If the issue persists, contact support.

## SPECIFICATIONS

<b>Brand</b>	Lumineo
<b>Model</b>	160 LED Polestar
<b>Light Source</b>	160 LED Lights
<b>Light Color</b>	Warm White
<b>Diameter</b>	27 Inches
<b>Lead Cable Length</b>	16.5 feet
<b>Power Source</b>	Corded Electric (UL Approved Transformer)
<b>Indoor/Outdoor Usage</b>	Indoor, Outdoor
<b>Material</b>	Silver-Colored Metal Wire
<b>Estimated LED Life</b>	50,000 hours
<b>Certification</b>	UL588 Standard Certified
<b>Item Weight</b>	1.9 pounds
<b>UPC</b>	688956522540

## WARRANTY INFORMATION

Specific warranty details for the Lumineo 160 LED Warm White Flashing Polestar are not provided in the product information. Please refer to your retailer's return policy or contact Lumineo customer service for warranty inquiries.

## **CUSTOMER SUPPORT**

---

For further assistance or technical support, please contact your point of purchase or visit the official Lumineo website for contact information.