

[Manuals.plus](#) /

› [IRIS USA](#) /

› IRIS USA 1.3L Pet Water Fountain (Model PWF-01) Instruction Manual

IRIS USA PWF-01

IRIS USA 1.3L Pet Water Fountain (Model PWF-01)

Instruction Manual

IMPORTANT SAFETY INFORMATION

- This product is intended for indoor use only.
- Always unplug the fountain from the power outlet before cleaning or performing any maintenance.
- Ensure the power cord is not damaged or frayed. Do not operate the fountain with a damaged cord or plug.
- Keep the power cord away from pets to prevent chewing.
- Use only as a pet water fountain. Do not use for any other purpose.
- Do not allow the pump to run dry. Always ensure there is sufficient water in the reservoir.

PRODUCT COMPONENTS

The IRIS USA 1.3L Pet Water Fountain consists of the following main components:

- **Spout:** Directs water flow, offering waterfall or gentle fountain options.
- **Bowl:** The upper section where pets drink.
- **Filter:** Charcoal filter for water purification.
- **Water Pump:** Circulates water from the reservoir to the spout.
- **Reservoir:** The main water storage tank.
- **Power Cord:** Connects the pump to a power source.

Easy To Assemble



Figure 1: Exploded view of the fountain components, illustrating the Spout, Bowl, Filter, Water Pump, and Reservoir.

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Rinse Parts:** Wash the reservoir, bowl, and spout with warm, soapy water. Rinse thoroughly to remove any residue.
3. **Prepare Filter:** Rinse the charcoal filter under cold running water for approximately 30 seconds to remove any loose carbon dust.
4. **Assemble Pump:** Place the water pump into the designated area at the bottom of the reservoir. Ensure the power cord is routed through the notch in the reservoir.
5. **Install Filter:** Insert the rinsed charcoal filter into the filter slot within the reservoir.
6. **Fill Reservoir:** Fill the reservoir with clean water up to the maximum fill line. Do not overfill.
7. **Place Bowl:** Carefully place the bowl onto the reservoir, ensuring it sits securely and the pump's water outlet aligns with the opening in the bowl.

8. **Attach Spout:** Insert the spout into the opening on the top of the bowl. You can choose between the waterfall feature or remove it for a gentle bubbling fountain.
9. **Connect Power:** Plug the power cord into a standard electrical outlet. The fountain will begin to operate.

OPERATING THE FOUNTAIN

The IRIS USA Pet Water Fountain is designed for continuous operation, providing fresh, filtered water for your pets. It offers two distinct water flow options:

- **Waterfall Spout:** For a flowing stream of water, attach the blue spout to the top of the fountain. This mimics a faucet, which some pets prefer.
- **Gentle Fountain:** For a bubbling, gentle flow, remove the blue spout. Water will bubble up from the center of the bowl.

The fountain features an ultra-silent submersible pump, ensuring minimal noise during operation. The flow rate is adjustable via a switch on the pump itself, allowing you to customize the water flow intensity to your pet's preference.

Two Flow Options



Waterfall
Spout



Gentle
Fountain

Figure 2: The fountain offers both a waterfall spout and a gentle bubbling fountain option.

Your browser does not support the video tag.

Video 1: An official product video demonstrating the IRIS Pet Water Fountain in use with cats and dogs, highlighting its features and quiet operation.

MAINTENANCE

Regular cleaning and filter replacement are crucial for maintaining water quality and the longevity of your fountain.

Cleaning the Fountain


- **Daily:** Check the water level and refill as needed.
- **Weekly:** Unplug the fountain. Disassemble all components (spout, bowl, filter, pump, reservoir). Wash all parts, except the pump, with warm, soapy water. Rinse thoroughly.
- **Pump Cleaning:** The pump should be cleaned every 2-4 weeks. Disassemble the pump by removing the cover and impeller. Use a small brush (like a toothbrush) to clean any debris, hair, or mineral buildup from the impeller and pump housing. Rinse well and reassemble.

Filter Replacement

The charcoal filter helps remove impurities, hair, and odors from the water. Replace the filter every 2-4 weeks, or more frequently if you have multiple pets or notice reduced water flow or odor.

- Unplug the fountain and disassemble the top components.
- Remove the old filter and dispose of it.
- Rinse a new charcoal filter under cold running water for 30 seconds.
- Insert the new filter into the designated slot in the reservoir.
- Reassemble the fountain and refill with fresh water.

Continuous Filtration



Filters Hair Residue



Removes Chlorine & Heavy Metals



Improves The Taste

Figure 3: Diagram showing the continuous filtration system, where water is filtered before being recirculated.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fountain not flowing or weak flow	Low water level Pump clogged with debris/hair Filter clogged Pump not properly connected	Add water to the reservoir. Clean the pump and impeller. Replace the filter. Ensure pump is securely connected and aligned.
Excessive noise from pump	Low water level Debris in pump	Add water to the reservoir. Clean the pump and impeller.

Problem	Possible Cause	Solution
Water leaking from fountain	Improper assembly of components Water level too high Pump squirting due to low water	Disassemble and reassemble all parts, ensuring a tight fit. Do not overfill the reservoir. Ensure water level is adequate.
Water has an odor or appears dirty	Dirty fountain components Old filter	Clean all fountain components thoroughly. Replace the charcoal filter.

SPECIFICATIONS

Feature	Detail
Model Name	PWF-01
Item Model Number	587291
Capacity	1.3 Liters (44 oz / 5.5 Cups)
Dimensions (L x W x H)	8.07" x 8.07" x 6.75"
Item Weight	1.72 pounds
Material	Polypropylene (PP)
Power Cord Length	11 feet
Target Audience	Cats, Dogs, Rabbits
Specific Uses	Indoor



3.25"L x 2.88"W x 1.2"H



Figure 4: Product dimensions of the IRIS USA Pet Water Fountain.

WARRANTY AND SUPPORT

Specific warranty details for the IRIS USA 1.3L Pet Water Fountain (Model PWF-01) are not provided in this manual. For warranty information, please refer to the product packaging or contact IRIS USA customer service directly.

For additional support, frequently asked questions, or to purchase replacement parts and filters, please visit the official IRIS USA website or contact their customer support department.

Manufacturer: IRIS USA, Inc.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07L5GK29S>

More documents and user manuals: **<https://manuals.plus/>**