



[Manuals.plus](#) /

› [Dancover](#) /

› Dancover Garage Tent PRO 3.3x6x2.4m PVC, Grey User Manual

## Dancover ST01101

# Dancover Garage Tent PRO 3.3x6x2.4m PVC, Grey User Manual

Model: ST01101

[Contents](#)   [Setup](#)   [Operation](#)   [Maintenance](#)   [Product Overview](#)   [Safety Information](#)   [Troubleshooting](#)   [Package](#)   [Specifications](#)   [Warranty & Support](#)

## 1. PRODUCT OVERVIEW

The Dancover PRO Garage Tent (Model ST01101) provides a robust and flexible solution for protecting vehicles and other items from environmental elements. This grey garage tent features a durable PVC cover and a galvanized steel frame, designed for stability and longevity. It is suitable for various storage needs, including cars, garden machinery, bicycles, trailers, and building materials.

Key features include a UV-resistant and 100% waterproof cover, two doors for convenient access, and two air ventilation openings to ensure efficient airflow within the structure.



*Image 1.1: The Dancover PRO Garage Tent fully assembled, providing shelter for a vehicle.*

## 2. SAFETY INFORMATION

---

- **Proper Anchoring:** Always ensure the garage tent is securely anchored to the ground using the provided pegs or by burying the ground flap. In windy conditions, additional anchoring methods may be required. Failure to properly anchor the tent can result in damage or injury.
- **Site Selection:** Choose a level and stable surface for installation. Avoid areas prone to water accumulation or strong wind gusts.
- **Assembly:** Follow all assembly instructions carefully. It is recommended that at least two adults assemble the tent. Wear appropriate safety gear, such as gloves, during assembly.
- **Weather Conditions:** While the tent is designed to be waterproof and UV-resistant, extreme weather conditions (e.g., heavy snow loads, severe storms) may exceed its structural limits. Consider disassembling or reinforcing the tent during such events.
- **Fire Safety:** Keep all heat sources, open flames, and flammable materials away from the tent cover. The PVC material is not fireproof.
- **Ventilation:** Ensure the ventilation openings are not obstructed to maintain proper airflow and prevent condensation buildup.
- **Children and Pets:** Do not allow children or pets to play unsupervised inside or around the tent, especially during assembly or in windy conditions.

## 3. PACKAGE CONTENTS

---

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, contact Dancover customer support.

- Galvanized Steel Frame Components (tubes and fittings)
- PVC Cover (roof and side walls)
- Front Door Panel
- Rear Door Panel
- Ground Pegs/Anchors
- Ropes and Fasteners
- Assembly Manual

## 4. SETUP AND ASSEMBLY

---

Assembly of the Dancover PRO Garage Tent requires careful attention to detail. It is recommended to have at least two people for assembly. Choose a flat, clear area for construction.

### 4.1 Frame Assembly

1. Unpack all galvanized steel frame components. Sort them by size and type according to the assembly diagram in the separate manual.
2. Begin by assembling the base frame on the ground. Connect the horizontal and vertical tubes using the appropriate fittings.
3. Erect the arch sections of the frame, connecting them to the base and to each other using the ridge tubes. Ensure all connections are secure.
4. Attach the end frame sections, including the door frames.



Image 4.1: The robust galvanized steel frame structure before the cover is applied.



Image 4.2: Detail of the frame connections and rope attachment points for securing the cover.

## 4.2 Cover Installation

1. Carefully unfold the PVC cover and drape it over the assembled frame. Ensure the cover is centered and evenly distributed.
2. Secure the cover to the frame using the provided ropes and fasteners. Start from one end and work your way around, ensuring the cover is taut to prevent water pooling.
3. Attach the front and rear door panels. The doors are designed to open sideways for easy access.




Image 4.3: Detail showing how the PVC cover is secured to the frame using ropes and eyelets.

## 4.3 Ground Anchoring

1. Once the frame and cover are in place, secure the tent to the ground. Use the provided steel pegs to anchor the ground rails of the frame.
2. The tent features a dirt flap (overlapping canvas) around the base. For maximum stability and protection against wind and dirt, bury this flap in the ground or weigh it down with heavy stones or other suitable material.
3. For a more permanent installation on a concrete surface, the tent can be mounted using extended bolts (not included).



Image 4.4: The ground flap designed to be buried or weighted for enhanced stability and protection.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Door Access

The Dancover PRO Garage Tent is equipped with two doors, one at each end. These doors can be opened sideways by unfastening the securing straps and rolling or folding the door panel to the side. Secure the rolled door panel with the integrated ties to keep it open.

### 5.2 Ventilation

The tent includes two air ventilation openings. Ensure these are clear of obstructions to allow for efficient air circulation. Proper ventilation helps to reduce condensation inside the tent and maintain a healthier environment for stored items.

## 6. MAINTENANCE

---

- **Regular Cleaning:** Clean the PVC cover periodically with mild soap and water. Avoid harsh chemicals or abrasive cleaners, which can damage the material. Rinse thoroughly and allow to air dry completely before closing the tent for extended periods.
- **Frame Inspection:** Regularly inspect the galvanized steel frame for any signs of corrosion, loose connections, or damage. Tighten any loose bolts or fittings.
- **Anchoring Check:** Periodically check the ground pegs and the dirt flap to ensure the tent remains securely anchored, especially after strong winds or heavy rainfall. Re-secure or re-bury the flap as needed.
- **Cover Condition:** Inspect the PVC cover for any tears, punctures, or signs of wear. Small damages can often be repaired with a suitable PVC repair kit to prevent further deterioration.
- **Snow Removal:** In areas with snowfall, regularly remove accumulated snow from the roof to prevent excessive weight, which could lead to structural collapse.

## 7. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Water pooling on roof	Cover not taut enough; improper frame assembly.	Re-tension the cover ropes and fasteners. Check frame connections for proper alignment and tightness.
Tent unstable in wind	Insufficient ground anchoring; dirt flap not secured.	Ensure all ground pegs are fully inserted. Bury the dirt flap or weigh it down. Consider additional storm straps or anchors in very windy areas.
Condensation inside tent	Poor ventilation; high humidity.	Ensure ventilation openings are clear. Open doors periodically to air out the tent.
Difficulty opening/closing doors	Cover tension too high/low; obstruction.	Adjust cover tension. Check for any debris or frame misalignment obstructing the door path.

## 8. SPECIFICATIONS

Feature	Detail
Model Number	ST01101
Dimensions (L x W x H)	6.00 m x 3.30 m x 2.44 m
Side Height	2.00 m
Door Dimensions (W x H)	3.3/2.2 m x 1.8 m (top/bottom width x height)
Cover Material	Strong PVC 500 g/m <sup>2</sup>
Frame Material	Galvanized Steel
Tube/Fitting Dimensions	Ø 32x1.2mm + Ø 25x1.0mm + Ø 25x0.8mm
Construction Standard	EN 1090-1:2009+A1:2011
Color	Grey
UV Resistance	Yes
Waterproof	100%
Product Weight	101 kg




Image 8.1: Technical drawing illustrating the dimensions of the garage tent.

## 9. WARRANTY AND SUPPORT

### 9.1 Warranty Information

Dancover products are manufactured to high-quality standards. For specific warranty terms and conditions applicable to your Dancover PRO Garage Tent, please refer to the warranty documentation included with your purchase or visit the official Dancover website. The warranty typically covers manufacturing defects under normal use.

### 9.2 Customer Support

Should you require assistance with assembly, have questions about product features, or need to report a missing or damaged part, please contact Dancover customer support. Contact details can usually be found on the Dancover website or in your purchase documentation.

When contacting support, please have your model number (ST01101) and purchase date readily available.