

[Manuals.plus](#) /

> [Aexit](#) /

> Aexit 9403 Belt Sander Roller Instruction Manual

Aexit modle

Aexit 9403 Belt Sander Roller Instruction Manual

Model: modle

INTRODUCTION

This manual provides essential information for the safe and effective use of the Aexit 9403 Belt Sander Roller. This product is designed as a replacement part for the 9403 belt sander. Please read these instructions carefully before installation and operation to ensure proper function and safety.

SAFETY INFORMATION

WARNING: Always disconnect the power tool from its power source before performing any adjustments, changing accessories, or storing the tool.

- Wear appropriate personal protective equipment (PPE) such as safety glasses, gloves, and hearing protection when working with power tools.
- Ensure the belt sander is turned off and unplugged before attempting to install or remove the roller.
- Use only genuine or approved replacement parts. This roller is specifically designed for the 9403 belt sander.
- Keep work area clean and well-lit. Cluttered or dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- If you are unsure about any part of the installation or operation, consult a qualified technician.

PRODUCT OVERVIEW

The Aexit 9403 Belt Sander Roller is a cylindrical component made from aluminum alloy and metal, designed to replace worn or damaged rollers in 9403 model belt sanders. It ensures proper belt tension and smooth operation of the sanding belt.



Figure 1: Top-down view of the Aexit 9403 Belt Sander Roller, showing its cylindrical shape and internal structure. This roller is a replacement part for the 9403 belt sander.



Figure 2: Angled view of the Aexit 9403 Belt Sander Roller, highlighting its silver-tone finish and robust construction from aluminum alloy and metal.

SETUP AND INSTALLATION

This section outlines the general steps for replacing the roller in a 9403 belt sander. Specific procedures may vary slightly depending on the exact model of your sander. Always refer to your belt sander's original manual for detailed instructions.

1. **Disconnect Power:** Ensure the belt sander is unplugged from the power source to prevent accidental startup.
2. **Access Roller Area:** Depending on your sander model, you may need to remove a cover or housing to access the existing roller. Use appropriate tools as specified by your sander's manual.
3. **Remove Old Roller:** Carefully detach the old roller. This usually involves releasing tension mechanisms or unscrewing retaining bolts. Note the orientation of the old roller for correct installation of the new one.
4. **Install New Roller:** Position the Aexit 9403 Belt Sander Roller into the designated slot. Ensure it fits securely and aligns correctly with the belt path.
5. **Secure Roller:** Re-engage any tension mechanisms or re-insert retaining bolts to secure the new roller in place. Ensure it can rotate freely without excessive play.
6. **Reassemble:** Replace any covers or housing removed in step 2.

7. **Test:** Before connecting to power, manually check that the sanding belt can be installed and tensioned correctly around the new roller and other components.

OPERATING INSTRUCTIONS

Once the Aexit 9403 Belt Sander Roller is correctly installed, operate your belt sander according to its original manufacturer's instructions. The roller's function is to provide a stable and smooth surface for the sanding belt to run on, contributing to efficient material removal.

- Ensure the sanding belt is properly aligned and tensioned after roller installation.
- Always hold the belt sander firmly with both hands during operation.
- Apply even pressure and move the sander smoothly across the workpiece.
- Avoid excessive force, which can damage the roller, belt, or motor.
- Regularly check the roller for smooth rotation during operation.

MAINTENANCE

Proper maintenance extends the life of your Aexit 9403 Belt Sander Roller and ensures consistent performance.

- **Cleaning:** Periodically clean dust and debris from around the roller and inside the belt sander housing. Use compressed air or a soft brush. Ensure the sander is unplugged before cleaning.
- **Inspection:** Regularly inspect the roller for signs of wear, damage, or uneven surfaces. A worn roller can cause belt tracking issues or reduced sanding efficiency.
- **Lubrication:** The roller typically does not require lubrication. If your sander's original manual specifies lubrication for roller bearings, follow those instructions.
- **Storage:** Store the belt sander in a clean, dry place when not in use.

TROUBLESHOOTING

If you encounter issues after installing the Aexit 9403 Belt Sander Roller, consider the following common problems and solutions:

- **Sanding belt not tracking correctly:**
 - Ensure the roller is installed correctly and securely.
 - Check if the belt tension is adjusted properly according to your sander's manual.
 - Inspect the sanding belt for damage or stretching.
- **Unusual noise or vibration:**
 - Verify the roller is seated correctly and not loose.
 - Check for any debris trapped around the roller or belt.
 - Inspect the roller for damage or uneven wear.
- **Roller not rotating smoothly:**
 - Clean any dust or debris from the roller's axle and housing.
 - Ensure no components are obstructing its rotation.
 - If the roller is damaged, it may need replacement.

If problems persist, consult a qualified technician or contact the manufacturer.

SPECIFICATIONS

Model	for 9403 Belt Sander
Material	Aluminum Alloy, Metal
Main Color	Silver Tone
Size (L*Max D)	90 x 55mm / 3.6" x 2.2"
Net Weight	210g
Package Content	1 x Roller
Country of Manufacture	CHINA

WARRANTY AND SUPPORT

This product is a replacement part. For specific warranty information, please refer to the terms and conditions provided by the retailer or manufacturer at the time of purchase. For technical support or inquiries regarding this Aexit product, please contact the manufacturer or your point of purchase.

Manufacturer: Aexit

© 2023 Aexit. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07L7ZNDWY>

More documents and user manuals: <https://manuals.plus/>