

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Pinkfong](#) /
- › [Pinkfong Baby Shark Sing-Alongs Sound Book Instruction Manual](#)

**Pinkfong 150480**

# Pinkfong Baby Shark Sing-Alongs Sound Book Instruction Manual

**Brand:** Pinkfong | **Model:** 150480

## 1. INTRODUCTION

This manual provides essential information for the safe and effective use of your Pinkfong Baby Shark Sing-Alongs Sound Book. Please read these instructions carefully before use and retain them for future reference. This interactive sound book features 10 full songs and 16 beautifully illustrated pages, designed for toddlers and preschoolers.



Image: A child holding the Pinkfong Baby Shark Sing-Alongs Sound Book, showcasing its design and size.

## 2. SETUP

### 2.1 Battery Installation

The sound book requires 2 AAA batteries (not included) for operation. Follow these steps to install or replace batteries:

1. Locate the battery compartment on the back of the sound book.
2. Using a small screwdriver, open the battery compartment cover.
3. Insert 2 new AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover and secure it with the screw.



Image: The battery compartment of the sound book, showing the correct placement of AAA batteries.

### 2.2 Power On/Off

To activate the sound features, slide the ON/OFF switch located near the battery compartment to the 'ON' position. To conserve battery life, slide the switch to 'OFF' when the book is not in use.



Image: Close-up of the ON/OFF switch on the back of the sound book.

## 3. OPERATING INSTRUCTIONS

The Pinkfong Baby Shark Sing-Alongs Sound Book is designed for easy interaction. Follow these steps to enjoy the songs and stories:

1. **Select a Song:** Press any of the 10 press-and-play buttons on the right side of the book to play a song. Each button corresponds to a specific song.
2. **Follow Along:** Turn the pages to find the lyrics and illustrations for the currently playing song.
3. **Sing-Along:** Read the lyrics on the pages and sing along with the music.



Image: A hand pressing one of the interactive song buttons on the sound book.

### 3.1 Available Songs

- Baby Shark
- S-H-A-R-K
- Twinkle, Twinkle, Little Shark
- Where Is Daddy Shark?
- This Little Baby Shark
- Move Like the Baby Shark
- Shark ABC
- Shark 123
- Baby Shark on the Bus
- Christmas Shark

Video: An official demonstration of the Pinkfong Baby Shark Sound Book, showcasing its features and songs.

## 4. CARE AND MAINTENANCE

---

- **Cleaning:** Wipe the book with a soft, damp cloth. Do not immerse in water.
- **Storage:** Store the book in a dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Remove batteries if the book will not be used for an extended period to prevent leakage.
- **Material:** The book is constructed from high-quality ABS plastic and durable board pages.

## 5. TROUBLESHOOTING

---

- **No Sound:**
  - Ensure the ON/OFF switch is in the 'ON' position.
  - Check if the batteries are correctly installed with the proper polarity.
  - Replace old batteries with new AAA batteries.
- **Distorted Sound:**
  - Replace batteries if they are low.
  - Ensure the speaker area is clean and free from obstructions.

## 6. SPECIFICATIONS

---

Feature	Detail
Product Dimensions	8 x 0.7 x 8 inches
Item Weight	11.4 ounces
Model Number	150480
Manufacturer Recommended Age	12 months and up
Batteries Required	2 AAA batteries
Manufacturer	Smart Study



Image: The sound book displaying its product dimensions.

## 7. WARRANTY AND SUPPORT

---

For warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official Pinkfong website. Keep your purchase receipt as proof of purchase.