

[Manuals.plus](#) /

› [Frigelux](#) /

› Frigelux RF190A++VCM 161L Vertical Refrigerator Instruction Manual

Frigelux RF190A++VCM

Frigelux RF190A++VCM 161L Vertical Refrigerator Instruction Manual

Model: RF190A++VCM

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your new Frigelux RF190A++VCM 161L Vertical Refrigerator. Please read these instructions carefully before installation and operation, and retain them for future reference. This appliance is designed for household use to store fresh food.

2. SAFETY INFORMATION

To prevent personal injury or damage to the appliance, observe the following safety precautions:

- Ensure the appliance is properly grounded.
- Do not use electrical appliances inside the food storage compartments unless they are of the type recommended by the manufacturer.
- Keep ventilation openings clear of obstruction.
- Do not damage the refrigerant circuit.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Unplug the refrigerator before cleaning or performing maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. SETUP AND INSTALLATION

3.1 Unpacking and Inspection

Carefully remove all packaging materials. Inspect the refrigerator for any damage. Report any damage to your retailer immediately. Keep packaging materials out of reach of children.

3.2 Location and Leveling

Place the refrigerator on a firm, level surface away from direct sunlight, heat sources (e.g., oven, radiator), and

extreme cold. Ensure adequate air circulation around the appliance. The refrigerator is equipped with adjustable feet and wheels for easy positioning and leveling. Adjust the front feet to ensure the appliance is stable and level.



Image: Front view of the FrigeluX RF190A++VCM refrigerator with the door open, showing its compact design and internal layout.

3.3 Door Reversal

The refrigerator features a reversible door with an integrated handle, allowing it to open from either the left or right side to suit your kitchen layout. Refer to the detailed diagram in the full manual for instructions on how to reverse the door swing.

3.4 Initial Cleaning

Before first use, clean the interior and exterior of the refrigerator with a soft cloth and a mild detergent. Rinse with clean water and dry thoroughly.

3.5 Power Connection

Plug the refrigerator into a dedicated, properly grounded electrical outlet. Allow the appliance to stand for at least 2-4 hours before plugging it in to allow refrigerants to settle.

3.6 First Use

After plugging in, set the thermostat to a medium setting. Allow the refrigerator to cool for several hours before placing food inside.

4. OPERATION

4.1 Temperature Control

The refrigerator is equipped with a mechanical thermostat for precise temperature adjustment. The thermostat dial is typically located inside the refrigerator compartment. Turn the dial to adjust the cooling intensity. Higher numbers usually indicate colder temperatures.

4.2 Internal Layout

The 161L capacity refrigerator features a practical internal layout:

- **Glass Shelves:** Three adjustable glass shelves provide flexible storage options for various food items.
- **Door Balconies:** Four door balconies offer convenient storage for bottles, jars, and smaller items.
- **Vegetable Crisper:** A dedicated vegetable crisper drawer at the bottom helps maintain the freshness of fruits and vegetables.



Image: The interior of the FrigeluX RF190A++VCM refrigerator, showing the arrangement of glass shelves, door balconies, and the vegetable crisper drawer.



Image: The FrigeluX RF190A++VCM refrigerator interior, demonstrating its storage capacity with various food items and beverages.



Image: A close-up view of the transparent vegetable crisper drawer at the bottom of the FrigeluX RF190A++VCM refrigerator.

4.3 LED Lighting

The refrigerator is equipped with low-consumption LED lighting, providing optimal visibility of the contents while saving energy.

5. MAINTENANCE

5.1 Automatic Defrosting

The refrigerator features an automatic defrost system, which simplifies daily maintenance by preventing ice buildup in the main compartment. Water from defrosting is automatically evaporated.

5.2 Cleaning the Interior and Exterior

Regular cleaning helps maintain hygiene and efficiency. Always unplug the appliance before cleaning.

- **Interior:** Clean with a solution of mild detergent and warm water. Wipe dry with a soft cloth. Remove shelves and drawers for thorough cleaning.
- **Exterior:** Wipe surfaces with a soft, damp cloth. For the stainless steel finish, use a specialized stainless steel cleaner to prevent fingerprints and maintain its appearance.
- **Door Seal:** Clean the door gasket regularly to ensure a tight seal.

5.3 Power Outage Guidelines

In case of a power outage, keep the refrigerator door closed to maintain the internal temperature for as long as possible. Avoid opening the door unnecessarily.

6. TROUBLESHOOTING

Before contacting customer service, check the following common issues:

- **Refrigerator not cooling:** Check if the power cord is properly plugged in, the circuit breaker, and the thermostat setting. Ensure the door is fully closed.
- **Unusual noises:** Some operational noises (e.g., gurgling, humming) are normal. Check if the appliance is level and not touching a wall or other objects.
- **Water leakage:** Ensure the drain hole for defrost water is not blocked. Check that the water collection tray at the back is correctly positioned.
- **Door not closing properly:** Check for obstructions, ensure shelves are correctly placed, and clean the door gasket.

If the problem persists after checking these points, please contact customer support.

7. SPECIFICATIONS




Image: Energy label for the FrigeluX RF190A++VCM refrigerator, showing energy efficiency class E and annual consumption of 155 kWh. For more details, visit eprel.ec.europa.eu/qr/375148.

Technical Specifications - FrigeluX RF190A++VCM

Feature	Detail
Brand	FrigeluX
Model Number	RF190A++VCM
Product Dimensions (L x W x H)	52 x 55 x 123 cm
Weight	32 kg

Feature	Detail
Energy Efficiency Class (7 levels)	E
Annual Energy Consumption	155 kWh/year
Total Capacity	161 Liters
Refrigerator Volume	137 Liters
Freezer Volume	1 Liter (internal freezer compartment)
Noise Level	41 Decibels
Installation Type	Freestanding
Type	Upright Refrigerator
Color	Anthracite
Voltage	240 Volts
Wattage	60 Watts
Number of Shelves	3 (Glass)
Number of Drawers	1 (Vegetable Crisper)
Defrost System	Automatic
Door Hinge	Left (Reversible)
Material	Stainless Steel
Included Components	1 removable glass shelf, 1 removable half-glass shelf, 2 removable plastic door balconies.

8. WARRANTY AND SUPPORT

Your FrigeluX RF190A++VCM refrigerator comes with a **2-year manufacturer's warranty**. Spare parts are available for a period of **10 years** from the date of purchase.

For technical assistance, warranty claims, or to purchase spare parts, please contact FrigeluX customer support or visit the official FrigeluX brand store:

Visit the FrigeluX Brand Store