GRIFEMA G4004

GRIFEMA G4004 Foldable Kitchen Faucet Instruction Manual

Model: G4004 | Brand: GRIFEMA

1. Introduction

Thank you for choosing the GRIFEMA G4004 Foldable Kitchen Faucet. This product is designed to provide reliable performance and convenience, especially for installations where window clearance is a concern. This manual contains important information regarding the installation, operation, and maintenance of your new faucet. Please read it thoroughly before installation and retain it for future reference.

2. Product Features

- **Foldable Design:** The faucet spout can be folded down, making it suitable for installation under windows that open inwards.
- **Chrome Finish:** High-gloss chrome finish for enhanced durability and ease of cleaning.
- **Single-Lever Control:** Allows for precise adjustment of water flow and temperature with one hand.
- **Durable Construction:** Made from brass with a ceramic disc valve for smooth operation and drip-free performance.
- **Adjustable Spout:** The spout can be rotated horizontally to direct water as needed.

3. Safety Information

- Always turn off the main water supply before beginning any installation or maintenance work.
- Wear appropriate personal protective equipment, such as safety glasses and gloves, during installation.
- Ensure all connections are secure to prevent leaks. Do not overtighten.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Keep small parts out of reach of children.

4. Package Contents

Verify that all components listed below are present before beginning installation.



Image: All components included in the GRIFEMA G4004 package, including the faucet, hoses, and mounting hardware.

- 1 x GRIFEMA G4004 Foldable Kitchen Faucet
- 1 x Installation Kit (includes mounting nut, washers, and fixing screw)
- 2 x Flexible Connection Hoses (G3/8 inch, 40 cm length)
- 1 x Installation Wrench

5. Setup and Installation

This section outlines the general steps for installing your GRIFEMA G4004 faucet. Specific installation requirements may vary based on your sink and countertop configuration. Refer to the provided diagrams for visual guidance.



Image: Step-by-step visual guide for faucet installation, including inserting the faucet, securing it, and connecting water lines.

1. **Prepare the Sink:** Ensure the sink hole is clean and free of debris. The required hole diameter is approximately 35mm.
2. **Install the Faucet:** Insert the faucet body into the sink hole. Ensure the base gasket is correctly positioned.
3. **Secure the Faucet:** From underneath the sink, slide the rubber washer, metal washer, and mounting nut onto the threaded rod. Tighten the mounting nut securely using the provided wrench until the faucet is stable.
4. **Connect Water Lines:** Attach the hot (red indicator) and cold (blue indicator) flexible hoses to the corresponding water supply valves. Ensure a tight, leak-free connection.
5. **Test for Leaks:** Slowly turn on the main water supply and check all connections for any signs of leakage.




Image: Detailed technical drawing showing the dimensions of the GRIFEMA G4004 faucet in millimeters.



Image: The GRIFEMA G4004 faucet in its folded position, demonstrating its suitability for under-window installation.

6. Operation

The GRIFEMA G4004 faucet features a single lever for controlling both water flow and temperature.

- **Water Flow:** Lift the lever upwards to increase water flow. Push it downwards to decrease or stop the flow.
- **Temperature Control:** Move the lever to the left for hot water and to the right for cold water.
- **Folding Spout:** To fold the spout, gently push it downwards. It will pivot at the base, allowing for clearance when opening a window. To return it to the upright position, simply lift it back up.



Image: The GRIFEMA G4004 faucet in operation, demonstrating water flow.



Image: Close-up view of the single-lever handle, showing the GRIFEMA logo and hot/cold indicators.

7. Maintenance and Care

Proper care will ensure the longevity and appearance of your GRIFEMA faucet.

- **Cleaning:** Clean the faucet regularly with a soft cloth and mild soap or a non-abrasive cleaner specifically designed for chrome finishes.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, scouring pads, ammonia-based products, or bleach, as these can damage the chrome finish.
- **Aerator Maintenance:** Periodically unscrew the aerator at the end of the spout and clean any accumulated debris or mineral deposits to maintain optimal water flow.



Image: Close-up view of the faucet's aerator, located at the tip of the spout.

8. Troubleshooting

Refer to the table below for common issues and their potential solutions.

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed shut-off valve; debris in water lines.	Clean the aerator. Ensure shut-off valves are fully open. Flush water lines.
Leaks at Connections	Loose connections; damaged washers.	Tighten connections. Replace worn washers.
Dripping Faucet	Worn ceramic cartridge.	Contact customer support for a replacement cartridge.
Difficulty Folding Spout	Mineral buildup in pivot mechanism.	Clean the pivot area with a descaling solution.

9. Specifications

Feature	Specification
Model Number	G4004
Brand	GRIFEMA
Material	Brass
Finish	Chrome
Installation Method	Single Hole, Surface Mount
Number of Handles	1
Handle Material	Metal
Connection Size	G3/8 inch
Hose Length	40 cm
Faucet Height (Upright)	Approx. 311 mm (from base to top of spout curve)
Spout Reach	Approx. 182 mm (from center of faucet body to spout outlet)
Weight	Approx. 2.17 kg
Manufacturer	IBERGRIF GRIFERIAS SL



Image: The GRIFEMA G4004 faucet being weighed on a digital scale.

10. Warranty and Support

GRIFEMA products are manufactured to high-quality standards. For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact your seller directly. Please note that information regarding spare parts availability for this specific model is currently unavailable, and the product is no longer manufactured. It is recommended to contact the seller for any warranty claims or service inquiries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question