

## SENTRY SPBT7

# SENTRY SPBT7 Splash-Proof Wireless Bluetooth Speaker

Model: SPBT7 | Brand: SENTRY

## INTRODUCTION

Thank you for purchasing the SENTRY SPBT7 Splash-Proof Wireless Bluetooth Speaker. This speaker is designed for portable use, offering wireless audio streaming and splash resistance, making it ideal for various environments, including near water. Please read this manual carefully to ensure proper use and maintenance of your device.

## WHAT'S IN THE BOX

- SENTRY SPBT7 Splash-Proof Wireless Bluetooth Speaker
- USB Charging Cable
- Instruction Manual (this document)

## PRODUCT FEATURES

The SENTRY SPBT7 speaker offers a range of features for an enhanced audio experience:

- **Wireless Sound:** Connects wirelessly via Bluetooth to compatible devices.
- **IPX4 Rated:** Provides protection against splashing water from any direction. This means it is splash-proof, not submersible.
- **Rechargeable Battery:** Built-in battery for portable use.
- **Integrated Play Controls:** Easily manage your music playback directly from the speaker.
- **Suction Cup:** Allows for convenient mounting on smooth surfaces.
- **Wide Compatibility:** Works with most mobile and audio devices, including iPhone, Android smartphones, and tablets.



*Image: SENTRY SPBT7 speaker packaging highlighting key features.*

## SETUP

---

### 1. Charging the Speaker

1. Locate the charging port on the speaker.
2. Connect the small end of the USB charging cable to the speaker's charging port.
3. Connect the larger end of the USB charging cable to a USB power source (e.g., computer USB port,

USB wall adapter).

4. The charging indicator light will illuminate, typically red, during charging. It will turn off or change color (e.g., blue) when fully charged.
5. Allow approximately 2-3 hours for a full charge before first use.

## 2. Powering On/Off

- **To Power On:** Press and hold the Power button (usually marked with a power symbol) for a few seconds until you hear an audible tone or see an indicator light flash.
- **To Power Off:** Press and hold the Power button again for a few seconds until you hear an audible tone or the indicator light turns off.

## 3. Bluetooth Pairing

1. Ensure the speaker is fully charged and powered on.
2. The speaker will automatically enter pairing mode, indicated by a flashing LED light (often blue). If not, you may need to press and hold a dedicated Bluetooth pairing button.
3. On your mobile device (smartphone, tablet, laptop), go to the Bluetooth settings menu.
4. Enable Bluetooth and search for available devices.
5. Select "SPBT7" from the list of found devices.
6. Once paired, you will hear a confirmation tone, and the LED indicator light on the speaker will typically stop flashing and remain solid blue.
7. Your device is now connected, and you can play audio through the speaker.

## OPERATING INSTRUCTIONS

---

### Music Playback

- **Play/Pause:** Press the Play/Pause button (often marked with a triangle and two vertical lines) once to play or pause music.
- **Next Track:** Press and hold the Volume Up button or a dedicated "Next" button.
- **Previous Track:** Press and hold the Volume Down button or a dedicated "Previous" button.

### Volume Control

- **Increase Volume:** Press the Volume Up (+) button.
- **Decrease Volume:** Press the Volume Down (-) button.

### Using the Suction Cup

- Ensure the surface where you intend to attach the speaker is clean, smooth, and dry.
- Press the suction cup firmly against the surface until it adheres securely.
- To remove, gently pull the edge of the suction cup to break the seal. Avoid forceful pulling to prevent damage.

## MAINTENANCE

---

### Cleaning

- Wipe the speaker with a soft, damp cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the surface or internal components.
- Ensure the charging port cover is securely closed before cleaning or exposing to water.

## Water Resistance (IPX4 Rating)

- The SPBT7 speaker is IPX4 rated, meaning it is protected against splashing water from any direction.
- This speaker is **not** designed to be submerged in water. Do not immerse it in water.
- Ensure the charging port cover is fully sealed to maintain water resistance.
- Water resistance may decrease over time with normal wear and tear.

## Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid storing in environments with high humidity.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker won't turn on.	Battery is depleted.	Charge the speaker fully using the provided USB cable.
Cannot pair with Bluetooth device.	Bluetooth is off on your device; speaker is not in pairing mode; speaker is already connected to another device; devices are too far apart.	Ensure Bluetooth is enabled on your device. Make sure the speaker is in pairing mode (flashing LED). Disconnect from other devices. Move speaker and device closer (within 10 meters).
No sound or low volume.	Volume is too low on speaker or connected device; speaker is not properly paired; audio source issue.	Increase volume on both the speaker and your connected device. Re-pair the speaker. Check if the audio is playing correctly on your source device.
Poor sound quality.	Interference; device too far from speaker; low battery.	Move speaker closer to the connected device. Avoid obstacles between devices. Charge the speaker. Avoid strong electromagnetic interference sources.

## SPECIFICATIONS

- **Model:** SPBT7
- **Connectivity:** Bluetooth Wireless
- **Water Resistance:** IPX4 Rated (Splash-Proof)
- **Power Source:** Rechargeable Lithium Ion Battery
- **Audio Output Mode:** Stereo
- **Speaker Type:** Outdoor
- **Compatible Devices:** Laptop, Smartphone, Tablet
- **UPC:** 080068587002

## WARRANTY AND SUPPORT

The SENTRY SPBT7 Splash-Proof Wireless Bluetooth Speaker comes with a **60-day limited warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or submersion in water. For technical support or warranty claims, please refer to the contact information provided on the product packaging or visit the official SENTRY website. Please retain your proof of purchase for warranty service.

