

[Manuals.plus](#) /

› [LUTEC](#) /

› LUTEC Starry 1857 LED Wall Light Instruction Manual

LUTEC 1857

LUTEC Starry 1857 LED Wall Light Instruction Manual

Model: 1857 | Brand: LUTEC

INTRODUCTION

Thank you for choosing the LUTEC Starry 1857 LED Wall Light. This manual provides detailed instructions for the safe and efficient installation, operation, and maintenance of your new lighting fixture. Please read all instructions carefully before beginning installation and retain this manual for future reference.



Figure 1: Illuminated LUTEC Starry 1857 LED Wall Light with seeded glass effect.

SAFETY INFORMATION

WARNING: To avoid electric shock, ensure power is turned off at the circuit breaker or fuse box before installation or servicing. All wiring connections must be in accordance with local and national electrical codes.

- Always use caution when handling electrical components.
- Ensure the mounting surface is structurally sound to support the fixture's weight.
- This fixture is suitable for wet locations.
- Do not attempt to modify the fixture.
- Keep packaging materials away from children.

WHAT'S IN THE BOX

Verify that all components are present before beginning installation:

- LUTEC Starry 1857 LED Wall Light Fixture
- Mounting Hardware (screws, wire nuts, mounting bracket)
- Instruction Manual (this document)



Figure 2: Overview of the LUTEC Starry 1857 LED Wall Light and its included components.

SETUP & INSTALLATION

1. **Turn Off Power:** Before starting, ensure the power to the light fixture's location is turned off at the circuit breaker or fuse box.
2. **Prepare Mounting Surface:** Remove any existing fixture and its mounting bracket. Ensure the electrical box is securely mounted and accessible.
3. **Install Mounting Bracket:** Attach the provided mounting bracket to the electrical box using the screws. Ensure it is level and secure.



Figure 3: Secure the mounting bracket to the electrical box.

4. **Wire Connections:** Connect the fixture's wires to the house wires using the provided wire nuts.

- Connect the **black** wire (Live/Hot) from the fixture to the **black** wire (Live/Hot) from the electrical box.
- Connect the **white** wire (Neutral) from the fixture to the **white** wire (Neutral) from the electrical box.
- Connect the **green** or bare copper wire (Ground) from the fixture to the **green** or bare copper wire (Ground) from the electrical box.

Ensure all connections are secure. If you are unsure about wiring, consult a qualified electrician.

5. **Mount Fixture:** Carefully align the fixture with the mounting bracket and secure it using the provided screws. Ensure the fixture is flush against the mounting surface.



Figure 4: Attach the fixture securely to the mounting bracket.

6. **Seal (for wet locations):** For outdoor or wet locations, apply a bead of silicone sealant around the perimeter of the fixture where it meets the mounting surface to prevent water intrusion.
7. **Restore Power:** Once installation is complete, turn the power back on at the circuit breaker or fuse box.

OPERATING INSTRUCTIONS

The LUTEC Starry 1857 LED Wall Light is designed for simple operation via a standard wall switch (Push Button Controller Type). There are no complex settings or adjustments required for daily use.

- **Turning On/Off:** Use the connected wall switch to turn the light fixture on or off.
- **Light Effect:** The integrated LED light source shines through the seeded glass, creating a charming warm white light with a starry pattern effect. This design ensures the light is not glaring.



Figure 5: The unique starry light pattern created by the seeded glass.

MAINTENANCE

The LUTEC Starry 1857 LED Wall Light requires minimal maintenance due to its durable construction and integrated LED technology.

- **Cleaning:** To clean the fixture, wipe it with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or glass.
- **LED Light Source:** The fixture uses an integrated LED light source, meaning there are no bulbs to replace. This ensures long-lasting, energy-efficient illumination.
- **Inspection:** Periodically inspect the fixture for any signs of wear or damage, especially if installed in wet locations. Ensure the sealant remains intact.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connection. Faulty wall switch.	Check circuit breaker/fuse. Turn off power and check all wire connections. Test or replace the wall switch.
Light flickers or dims.	Loose wire connection. Incompatible dimmer switch (if applicable, though this model is switch-controlled). Power fluctuations.	Turn off power and check all wire connections. Ensure stable power supply.
Water inside fixture (for outdoor use).	Improper sealing during installation. Damaged sealant.	Turn off power. Remove fixture, reapply silicone sealant around the perimeter, and re-mount. Inspect for cracks in glass.

If troubleshooting steps do not resolve the issue, please contact LUTEC customer support.

SPECIFICATIONS

Brand	LUTEC
Model Number	1857
Light Source Type	Integrated LED
Brightness	795 Lumens
Color Temperature	3000K (Warm White)
Wattage	16.5 Watts
Material	Aluminum, Seeded Glass
Dimensions (L x W x H)	6.54" x 4.25" x 10.83"
Item Weight	4.9 Pounds
Indoor/Outdoor Usage	Indoor/Outdoor (Suitable for wet locations)
Installation Type	Wall Mount
Controller Type	Push Button

WARRANTY & SUPPORT

The LUTEC Starry 1857 LED Wall Light comes with a**5-year warranty** on the lighting element. The aluminum housing is designed for long-term durability.

For technical support, warranty claims, or any questions regarding your product, please contact LUTEC customer service through their official channels or visit their website.

Please retain your proof of purchase for warranty purposes.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07L9T5KKL>

More documents and user manuals: <https://manuals.plus/>