

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [GUESS](#) /

> [GUESS W1135L7 Quartz Watch User Manual](#)

GUESS W1135L7

GUESS W1135L7 Quartz Watch User Manual

Model: W1135L7

1. INTRODUCTION

Thank you for choosing the GUESS W1135L7 Quartz Watch. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

2. PRODUCT OVERVIEW

The GUESS W1135L7 is a stylish quartz watch featuring a durable stainless steel case, a comfortable silicone strap, and a mineral crystal dial window. It is equipped with a three-hand analog display and includes three functional sub-dials. The bezel is adorned with crystals for an elegant finish.



Figure 1: GUESS W1135L7 Quartz Watch. This image displays the watch face, including the three sub-dials, the crystal-encrusted bezel, and the white silicone strap with a buckle closure.

Watch Components:

- **Crown:** Used for setting the time.
- **Dial:** The watch face displaying hours, minutes, and seconds.
- **Hands:** Hour, minute, and second hands for time indication.
- **Sub-dials:** Three smaller dials on the watch face, typically indicating additional functions such as day, date, or 24-hour time, or chronograph functions.
- **Bezel:** The ring surrounding the watch crystal, featuring crystal embellishments.
- **Strap:** White silicone strap with a buckle closure.
- **Case:** Stainless steel housing for the watch movement.

3. SETUP

3.1 Setting the Time

1. Pull the crown out to the furthest position (position 2).
2. Rotate the crown clockwise or counter-clockwise to move the hands and set the correct time.

3. Once the time is set, push the crown back into its normal operating position (position 0).

3.2 Adjusting the Strap

The silicone strap is designed for comfort and adjustability. To adjust the fit, simply use the buckle closure to select the appropriate hole on the strap that provides a secure yet comfortable fit on your wrist.

4. OPERATING

4.1 Basic Timekeeping

Your GUESS W1135L7 watch provides accurate timekeeping with its three-hand analog display. The large hands indicate hours and minutes, while the thinner hand indicates seconds.

4.2 Sub-dial Functionality

The three sub-dials on your watch face offer additional information. Depending on the specific movement, these sub-dials may display features such as the day of the week, date, 24-hour time, or chronograph functions. For detailed instructions on operating the sub-dials, please refer to the official GUESS website or contact customer support, as specific functions can vary.

5. MAINTENANCE

5.1 Cleaning Your Watch

To maintain the appearance of your watch, wipe the case and strap regularly with a soft, dry cloth. For the silicone strap, a damp cloth with mild soap can be used, followed by thorough drying. Avoid using harsh chemicals or abrasive materials.

5.2 Water Resistance

Your GUESS W1135L7 watch is water resistant up to 30 meters (3 ATM). This means it is suitable for everyday use and can withstand splashes or brief immersion in water. However, it is **not** suitable for swimming, showering, diving, or any water sports where it may be subjected to high water pressure or prolonged immersion. Always ensure the crown is fully pushed in before any contact with water.

5.3 Battery Replacement

The watch is powered by a Lithium Ion battery. When the watch stops or the second hand begins to skip, it indicates that the battery needs to be replaced. Battery replacement should be performed by a qualified watch technician to ensure the watch's water resistance and proper functioning are maintained.

6. TROUBLESHOOTING

Watch Not Running:

- Ensure the crown is fully pushed into position 0.
- The battery may need replacement. Refer to section 5.3.

Incorrect Time:

- Reset the time as described in section 3.1.
- If the time continues to be inaccurate, the watch may require servicing.

For issues not covered here, please contact GUESS customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	W1135L7
Movement	Japanese Quartz, Three Hand Analog
Case Material	Stainless Steel
Band Material	Silicone
Crystal	Mineral
Water Resistance	30 Metres (3 ATM)
Case Diameter	40 Millimetres
Band Width	20 Millimetres
Battery Type	1 Lithium Ion battery
Weight	150 Grams

8. WARRANTY AND SUPPORT

Your GUESS W1135L7 watch is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. For technical support, service, or warranty claims, please contact GUESS customer service through their official website or authorized service centers.