

[Manuals.plus](#) /

› [Bean Envy](#) /

› Bean Envy EP-460A Handheld Milk Frother Instruction Manual

Bean Envy EP-460A

Bean Envy EP-460A Handheld Milk Frother Instruction Manual

Model: EP-460A

INTRODUCTION

Thank you for choosing the Bean Envy EP-460A Handheld Milk Frother. This battery-operated device is designed to create rich, creamy foam for a variety of beverages and mixes. Its versatile design makes it suitable for frothing milk for coffee, lattes, cappuccinos, matcha, and hot chocolate, as well as mixing protein powder shakes and whisking eggs.



Image: The Bean Envy EP-460A Handheld Milk Frother in blue, displayed on its metal stand on a kitchen counter.

Safety Information

- Keep the frother out of reach of children.
- Do not immerse the handle or motor unit in water. The whisk attachment is designed for immersion.
- Use only 2 AA batteries (not included) of the specified type. Ensure correct polarity when inserting batteries.
- Remove batteries if the frother will not be used for an extended period.

- Avoid contact with moving parts during operation.

PACKAGE CONTENTS

The Bean Envy EP-460A Handheld Milk Frother package includes:

- 1 x Handheld Milk Frother Unit
- 1 x Stainless Steel Stand

SETUP

1. **Install Batteries:** Open the battery compartment located at the back of the frother handle. Insert 2 AA batteries, ensuring correct polarity (+/-). Close the compartment securely.
2. **Assemble Stand:** Place the frother unit onto its stainless steel stand for convenient storage and access.

Video: This video demonstrates the battery installation process and initial setup of the Bean Envy handheld milk frother.

OPERATION

1. **Prepare Liquid:** Pour your desired liquid (milk, coffee, protein shake, etc.) into a cup or container. For best frothing results with milk, ensure it is slightly warm.
2. **Immerse Whisk:** Gently insert the stainless steel whisk end of the frother into the liquid, keeping it slightly below the surface to prevent splashing.
3. **Activate Frother:** Press and hold the button located on the top of the frother handle to activate the whisk.
4. **Froth/Mix:** Move the frother up and down or in a circular motion within the liquid until the desired consistency or foam is achieved. The 19,000 RPM motor provides powerful and consistent performance.
5. **Deactivate Frother:** Release the button to stop the frother.

CREATE RICH, SMOOTH Lattes, Cappuccinos, and More



FROTHY PERFECTION IN 4 Simple Steps



1 HEAT



2 FILL



3 WHISK



4 POUR

Image: The Bean Envy frother demonstrating its versatility for different drinks and mixes.

Video: This video provides a general overview of the Bean Envy milk frother in action, demonstrating its use for coffee.

Video: This video shows the daily use of the frother, including frothing milk and a quick cleaning demonstration.

CLEANING AND MAINTENANCE

1. **Rinse Whisk:** After each use, immediately dip the whisk end into warm, soapy water.
2. **Activate Briefly:** Briefly run the frother for a few seconds to rinse off any residue from the whisk.
3. **Wipe Handle:** Wipe the handle with a damp cloth. Do not immerse the handle in water.
4. **Dry and Store:** Place the frother back on its sleek stand to air dry and store neatly.

Easy to Clean & Store

Just Wash with Hot Water



Image: The Bean Envy frother being cleaned under running water.

TROUBLESHOOTING

- **Frother not turning on:** Check if the batteries are inserted correctly with the right polarity. Replace with fresh AA batteries if needed.
- **Weak frothing power:** This may indicate low battery power. Replace the AA batteries.
- **Excessive splashing:** Ensure the whisk is sufficiently immersed in the liquid and not too close to the surface.

SPECIFICATIONS

Feature	Detail
Brand	Bean Envy

Model Name	EP Milk Frothers (EP-460A)
Color	Blue
Material	Stainless Steel (whisk)
Product Dimensions	3"W x 10"H
Item Weight	8 Ounces
Power Source	Battery Operated (2 AA batteries required, not included)
Special Feature	Cordless
Included Components	Stand
Product Care Instructions	Hand Wash Only

Video: This video showcases the Bean Envy Milk Frother, highlighting its handheld design and included stand.

WARRANTY AND SUPPORT

The Bean Envy EP-460A Handheld Milk Frother comes with **lifetime warranty**. For any product inquiries, troubleshooting assistance, or warranty claims, please contact Bean Envy customer support through the official website or your retailer's support channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question