
ASAKUKI 100-DF002

ASAKUKI 300ML Essential Oil Diffuser User Manual

Model: 100-DF002

1. Introduction

The ASAKUKI 300ML Essential Oil Diffuser is a versatile 5-in-1 aromatherapy device designed to enhance your home or office environment. It functions as an essential oil diffuser, humidifier, and features 7 different LED light colors, multiple mist nebulizer modes, and an auto-off safety switch for peace of mind.



The ASAKUKI 300ML Essential Oil Diffuser, featuring a sleek design with a light brown wood-grain base and a white cylindrical top.

2. Important Safety Information

- Unplug the diffuser during filling and cleaning to prevent electrical hazards.
- Refer to product bullet points and description for general usage guidance.
- Ensure the diffuser is placed on a stable, flat surface to prevent spills.
- Do not exceed the maximum water fill line to avoid malfunction.
- Keep out of reach of children and pets.

3. Product Components

Your ASAKUKI 300ML Essential Oil Diffuser package includes the following items:

- ASAKUKI 300ML Essential Oil Diffuser Unit
- AC Power Adapter
- User Manual



Key features of the diffuser, including its LED mood lights and energy efficiency.

4. Setup

1. Place the diffuser on a flat, stable surface.
2. Remove the top cover by lifting it straight up.
3. Connect the AC power adapter to the DC socket on the side of the diffuser.
4. Fill the water tank with clean tap water up to the maximum fill line (300ml capacity). Do not overfill.
5. Add 3-5 drops of your preferred essential oil directly into the water tank. Adjust quantity based on desired aroma intensity.
6. Replace the top cover, ensuring it is securely seated.
7. Plug the AC power adapter into a wall outlet.



Filling the diffuser with water. Ensure not to exceed the maximum fill line.

5. Operating Instructions

Mist Control

Press the 'MIST' button to turn on the mist. Each press cycles through the timer settings:

- **60 minutes:** Mist operates for 60 minutes, then automatically shuts off.

- **180 minutes:** Mist operates for 180 minutes, then automatically shuts off.
- **360 minutes:** Mist operates for 360 minutes, then automatically shuts off.
- **ON:** Mist operates continuously until the water runs out.

To turn off the mist, cycle through all timer settings until the mist indicator light is off.



Control buttons for mist timer settings and light functions.

Light Control

Press the 'LIGHT' button to turn on the LED light. The light will cycle through 7 different colors automatically. Pressing the button again will fix the light on the current color. Continue pressing to cycle through each color individually.

To adjust the brightness of a fixed color, press and hold the 'LIGHT' button. To turn off the light, cycle through all colors until the light turns off.

Auto-Off Safety Switch

The diffuser is equipped with a safety auto-off switch that automatically turns the unit off when the water level is too low or runs out, preventing overheating and ensuring safe operation.

6. Maintenance

Regular cleaning of your diffuser is essential for optimal performance and longevity.

1. Unplug the diffuser from the power outlet.
2. Remove the top cover and carefully drain any remaining water from the tank, ensuring water does not enter the air outlet side.
3. Wipe the inside of the water tank with a soft cloth or sponge. For stubborn residue, use a cotton swab dipped in white vinegar to gently clean the ultrasonic vibrating plate (the small disc at the bottom of the tank).
4. Rinse the tank with clean water.
5. Wipe the exterior of the diffuser with a soft, dry cloth.
6. It is recommended to change the water every three days to maintain hygiene and prevent buildup.

7. Troubleshooting


Problem	Possible Cause	Solution
No mist or low mist output	Insufficient water; Water level too high; Ultrasonic plate dirty; Fan blocked.	Add water to appropriate level; Drain excess water; Clean ultrasonic plate; Check for obstructions.
No power/light	Power adapter not connected; No power from outlet; Unit not turned on.	Ensure adapter is securely plugged in; Test outlet with another device; Press 'MIST' or 'LIGHT' button.
Unusual noise	Water level too low; Unit not on a flat surface.	Add water; Place diffuser on a stable, flat surface.

If problems persist after attempting these solutions, please contact customer support.

8. Specifications

Feature	Detail
Brand	ASAKUKI
Model Name	100-DF002
Capacity	300 Milliliters
Runtime	Up to 10 hours (weak mist)
Coverage Area	250 Square Feet

Feature	Detail
Power Source	AC Power Adapter (7 watts)
LED Light Colors	7 different colors
Material	Polypropylene (PP), BPA Free
Product Dimensions	4.33"L x 4.33"W x 6.03"H
Auto Shutoff	Yes (when water runs out)



Physical dimensions and capacity of the diffuser.

9. Warranty and Support

ASAKUKI offers a 1-year technical support for this essential oil diffuser. For any inquiries or assistance, please refer to the contact information provided with your product packaging or visit the official ASAKUKI store.

Visit the ASAKUKI Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question