

SHARP LC-32HI5012E

SHARP LC-32HI5012E HD Ready Smart LED TV User Manual

Model: LC-32HI5012E | Brand: SHARP

1. INTRODUCTION

This user manual provides comprehensive instructions for the setup, operation, and maintenance of your SHARP LC-32HI5012E HD Ready Smart LED TV. Please read this manual thoroughly before using your television to ensure proper functionality and safety.

The SHARP LC-32HI5012E is an 81 cm (32-inch) HD Ready Smart LED TV featuring Active Motion 200 technology for enhanced picture quality and a Triple Tuner for versatile reception options. It includes integrated Wi-Fi and a Harman/Kardon sound system for a complete entertainment experience.

2. PACKAGE CONTENTS

Upon opening the package, please verify that all the following items are included:

- SHARP LC-32HI5012E Main Unit
- Remote Control (with batteries)
- User Manual (this document)



Image: Front view of the SHARP LC-32HI5012E television, displaying a vibrant city skyline on its screen. This image shows the slim bezel design and the central SHARP logo.

3. SETUP

3.1 Assembling the Stand

Carefully place the TV screen-down on a soft, flat surface to prevent damage. Attach the two stand feet to the designated slots at the bottom of the TV, securing them with the provided screws. Ensure the stand is firmly attached before proceeding.

3.2 Connecting Peripherals

Your TV offers various connection options for external devices:

- **HDMI Ports (x3):** Connect Blu-ray players, game consoles, or set-top boxes.
- **USB Ports (x2):** For media playback from USB drives.
- **Antenna In (RF):** Connect your terrestrial antenna for DVB-T/T2HD reception.
- **Sat In:** Connect your satellite dish for DVB-S/S2 reception.
- **RJ45 (LAN):** For wired internet connection.
- **CI+ Port:** For conditional access modules (CAM) to view encrypted channels.
- **Mini Component/YPbPr, Mini AV Composite:** For older analog devices.
- **Digital Optical Audio Output:** For connecting to external audio systems.
- **Audio out / Headphone:** For headphones or external speakers.



Image: Rear view of the SHARP LC-32HI5012E television, highlighting the arrangement of various input and output ports for connecting external devices.

3.3 Initial Power On and First-Time Setup

After connecting all necessary cables, plug the power cord into an electrical outlet. Press the power button on the remote control or the TV. The first-time setup wizard will guide you through:

1. Language selection.
2. Network connection (Wi-Fi or wired LAN).
3. Channel scanning for DVB-C, DVB-S/S2, or DVB-T/T2HD.
4. Time zone and other basic settings.

4. OPERATING INSTRUCTIONS

4.1 Basic TV Functions

- **Power On/Off:** Use the power button on the remote or TV.
- **Volume Control:** Use the VOL +/- buttons.
- **Channel Selection:** Use CH +/- or number buttons.
- **Input Source:** Press the SOURCE button to switch between HDMI, AV, TV, etc.
- **Menu Navigation:** Use arrow keys and OK button to navigate menus.

4.2 Smart TV Features

Your SHARP LC-32HI5012E is equipped with integrated Wi-Fi and offers access to various smart features:

- **Pre-installed Apps:** Access popular streaming services like Netflix and YouTube directly.
- **Web Browser:** Browse the internet directly from your TV.
- **Aquos Net+:** Access additional online content and services provided by Sharp.

Ensure your TV is connected to the internet for full Smart TV functionality.

4.3 Audio System

The integrated Harman/Kardon sound system provides a high-quality audio experience with excellent dynamics and clarity. Adjust audio settings in the TV menu to customize your sound preferences.

5. MAINTENANCE

5.1 Cleaning the Screen

To clean the screen, gently wipe it with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with

water or a specialized screen cleaner. **Do not** spray liquid directly onto the screen.

5.2 General Care

- Keep the TV away from direct sunlight and heat sources.
- Ensure adequate ventilation around the TV.
- Unplug the TV from the power outlet during lightning storms or when left unattended for long periods.

6. TROUBLESHOOTING

If you encounter any issues with your TV, please refer to the following common problems and solutions before contacting support.

Problem	Possible Cause	Solution
No Power	Power cord unplugged, power outlet issue.	Check power cord connection. Try a different outlet.
No Picture, but Sound is Present	Incorrect input source, faulty cable.	Verify correct input source. Check HDMI/AV cable connections.
No Sound	Volume muted or too low, external audio system issue.	Unmute volume, increase volume. Check external audio connections.
Cannot Connect to Wi-Fi	Incorrect password, router issue, TV too far from router.	Re-enter password. Restart router. Move TV closer or use wired connection.


7. SPECIFICATIONS

Feature	Detail
Brand	SHARP
Model Number	LC-32HI5012E
Screen Technology	LED
Resolution	HD Ready (1366 x 768 pixels)
Screen Diagonal	81.3 cm (32 inches)
Refresh Rate	60 Hz
Special Feature	Internet (Smart TV)
Supported Internet Services	Netflix, YouTube, Browser
Connectivity Technology	USB, HDMI, LAN, Wi-Fi
Tuners	DVB-C, DVB-S/S2, DVB-T/T2HD
Audio System	Harman/Kardon
Product Dimensions (W x H x D)	74 x 49.1 x 18 cm (with stand)
Weight	4.8 Kilograms

Feature	Detail
Mounting Type	Table Mount


7.1 Energy Efficiency

The SHARP LC-32HI5012E has an energy efficiency rating of F. For detailed energy consumption information, please refer to the energy label and product information sheet.





135 kWh/1000h



2019/2013

Image: Energy efficiency label for the SHARP LC-32HI5012E television, showing its energy class F and power consumption details.

For more details, visit the official EPREL database: <https://eprel.ec.europa.eu/qr/402565>

Fiche d'information sur le produit

RÈGLEMENT DÉLÉGUÉ (UE) 2019/2013 DE LA COMMISSION

INFORMATIONS		Valeur	Unité
1. Nom du fournisseur ou marque commerciale		Sharp	
2. Référence du modèle		LC-32HI5012E	
3. Classe d'efficacité énergétique pour la gamme dynamique standard (SDR)		F	
4. Puissance appelée en mode marche pour la gamme dynamique standard (SDR)		31,0	W
5. Classe d'efficacité énergétique pour la haute gamme dynamique (HDR)		G	
6. Puissance appelée en mode marche pour la haute gamme dynamique (HDR)		135	W
7. Puissance appelée en mode arrêt		0,0	W
8. Puissance appelée en mode veille		0,5	W
9. Puissance appelée en mode veille avec maintien de la connexion au réseau		s.o.	W
10. Catégorie de dispositif d'affichage électronique		Téléviseur	
11. Rapport de taille		16 : 9	
12. Résolution de l'écran (pixels)		1 366 x 768	pixels
13. Diagonale de l'écran		81,0	cm
14. Diagonale de l'écran		32	pouces
15. Surface visible de l'écran		2 754,0	cm ²
16. Technologie d'affichage utilisée		LED LCD	
17. Réglage automatique de la luminosité (ABC) disponible		Non	
18. Capteur de reconnaissance vocale disponible		Non	
19. Capteur de présence disponible		Non	
20. Taux de fréquence de rafraîchissement de l'image		50	Hz
21. Disponibilité minimale garantie des mises à jour du logiciel et du micrologiciel (jusqu'au)::		20 10 2026	
22. Disponibilité minimale garantie des pièces de rechange (jusqu'au)		20 10 2026	
23. Assistance produit minimale garantie (jusqu'au):		21 10 2020	
24. Type d'alimentation:		Interne	
i	Alimentation externe normalisée (EPS) (incluse dans l'emballage du produit)	Nom de la norme	-
		Tension d'entrée	- V
ii	Alimentation externe normalisée appropriée (si non incluse dans l'emballage du produit)	Tension de sortie	- V
		Nom de la norme	-
		Tension de sortie requise	- V
		Intensité du courant à fournir	- A
		Fréquence du courant requise	- Hz





8. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product or visit the official SHARP website. Keep your purchase receipt as proof of purchase for any warranty claims.

For technical support or service inquiries, please contact SHARP customer service. Contact details can typically be found on the SHARP official website or in the product packaging.

© 2024 SHARP. All rights reserved. Information in this manual is subject to change without notice.

Related Documents - LC-32HI5012E

	<p>Sharp AQUOS Liquid Crystal Television Operation Manual</p> <p>Comprehensive operation manual for Sharp AQUOS Liquid Crystal Televisions, covering safety, setup, operation, and troubleshooting for various models.</p>
	<p>SHARP LC-42LE756/758/759/760/761/762 & LC-50LE756/758/759/760/761/762 Series LCD Colour Television User Manual</p> <p>Comprehensive user manual for SHARP LC-42LE and LC-50LE series LCD Colour Televisions, covering setup, operation, features, safety, troubleshooting, and technical specifications.</p>
	<p>Guía de inicio rápido para televisores SHARP Roku</p> <p>Aprenda a configurar su televisor SHARP Roku con esta guía de inicio rápido. Cubre la conexión de dispositivos, la configuración de la red y la personalización de la pantalla de inicio.</p>
	<p>Sharp LC-60/70LE Series LCD TV Service Manual</p> <p>Official service manual for Sharp LC-60/70LE series LCD televisions (models LC-60/70LE650U, C6500U, LE657U, LE755U, LE757U, LE857U, C7500U). Provides technical specifications, repair procedures, troubleshooting guides, parts lists, and wiring diagrams for service professionals.</p>
	<p>Sharp Q5000 Series TV Quick Start Guide</p> <p>A concise guide to setting up your new Sharp Q5000 Series TV, covering unboxing, connections, network setup, and basic operation. Learn how to get the most out of your Sharp television with this easy-to-follow manual.</p>
	<p>SHARP LC-60LE830E/LC-52LE830E LCD Colour Television Operation Manual</p> <p>User operation manual for SHARP LC-60LE830E, LC-52LE830E, LC-60LE830RU, LC-52LE830RU, LC-60LE831E, LC-52LE831E, LC-60LE831S, and LC-52LE831S LCD Colour Televisions. Covers setup, features, connectivity, troubleshooting, and specifications.</p>

