

Warner Home Video B07LD4P46K

Supernatural: The Complete Fourteenth Season DVD Instruction Manual

Model: B07LD4P46K

PRODUCT OVERVIEW




Image Description: The DVD cover features the title "THE COMPLETE FOURTEENTH SEASON SUPERNATURAL" at the top. Below, three main characters, Dean Winchester (Jensen Ackles), Sam Winchester (Jared Padalecki), and Castiel (Misha Collins), are depicted in a dark, dramatic setting with blue light effects. A stylized symbol, resembling a devil's trap, is at the bottom center.

This manual provides instructions for the Supernatural: The Complete Fourteenth Season DVD set. It covers essential information for playback, understanding bonus features, and maintaining your discs.

SETUP AND INITIAL USE

1. **Unboxing:** Carefully remove the DVD set from its packaging.
2. **Disc Inspection:** Check each disc for any visible damage or smudges.
3. **Player Compatibility:** Ensure your DVD player is compatible with Region 1 (NTSC) DVDs.
4. **Disc Insertion:** Open your DVD player's disc tray and place a disc gently onto the spindle, label side up. Close the tray.
5. **Power On:** Turn on your DVD player and television. Select the correct input source on your television.

OPERATING INSTRUCTIONS

Main Menu Navigation

Upon disc insertion, the main menu should appear. Use your DVD player's remote control to navigate:

- Use the **arrow keys** to highlight desired options (e.g., "Play All," "Episode Selection," "Special Features," "Setup").
- Press the **Enter** or **OK** button to select a highlighted option.

Episode Playback

- Select "Play All" to watch all episodes on the disc sequentially.
- Select "Episode Selection" to choose a specific episode.
- During playback, use the remote's **Play/Pause**, **Stop**, **Fast Forward**, and **Rewind** buttons as needed.

Audio and Subtitle Settings

Access the "Setup" or "Audio/Subtitles" option from the main menu or during playback (if available via your remote's "Audio" or "Subtitle" button) to adjust:

- **Audio Language:** English (Dolby Digital 5.1).
- **Subtitles:** English, Spanish.

BONUS CONTENT

The Supernatural: The Complete Fourteenth Season DVD set includes the following special features:

- Supernatural 300th (NEW Featurette)
- The Winchester Mythology: The Quest to Stop Michael (NEW Featurette)
- Supernatural 2018 Comic-Con Panel
- Audio Commentaries with Talent & Producers
- Deleted Scenes
- Gag Reel

Access these features via the "Special Features" option on the main menu of the relevant disc.

MAINTENANCE AND CARE

- **Handling Discs:** Always hold discs by their edges or by placing a finger through the center hole. Avoid touching the shiny playback surface.
- **Cleaning Discs:** If a disc becomes dirty, gently wipe it with a soft, lint-free cloth from the center outwards. Do not use abrasive materials or harsh chemicals.
- **Storage:** Store discs in their original case, away from direct sunlight, extreme temperatures, and high humidity.
- **Case Care:** Keep the DVD case clean and free from dust.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Disc does not play or load.	Disc is dirty, scratched, or inserted incorrectly. Player is not compatible with Region 1 DVDs.	Clean the disc. Reinsert the disc correctly. Verify your DVD player's region compatibility. Try another disc to confirm player functionality.
Video or audio skipping/freezing.	Disc surface is dirty or scratched.	Clean the disc thoroughly. If scratches are deep, the disc may be permanently damaged.

Problem	Possible Cause	Solution
No sound or picture.	Incorrect TV input selected, loose cables, or TV/player volume too low.	Check TV input. Ensure all cables are securely connected. Adjust volume on TV and DVD player.
Remote control not working.	Dead batteries, obstructed sensor.	Replace remote batteries. Ensure a clear line of sight between the remote and the DVD player's sensor.

SPECIFICATIONS

- **Title:** Supernatural: The Complete Fourteenth Season
- **Format:** DVD, NTSC, Subtitled
- **Number of Discs:** 5
- **Run Time:** Approximately 20 hours
- **Audio:** English (Dolby Digital 5.1)
- **Subtitles:** English, Spanish
- **MPAA Rating:** NR (Not Rated)
- **Release Date:** September 10, 2019
- **Studio:** Warner Home Video
- **ASIN:** B07LD4P46K

WARRANTY AND SUPPORT

For issues related to manufacturing defects of the discs or packaging, please contact the retailer where the product was purchased. For general inquiries about the content or series, please refer to official Warner Home Video resources.

This product is covered by standard consumer rights regarding faulty goods. Specific warranty details may vary by region and retailer.

© 2023 Warner Home Video. All rights reserved. Information subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07LD4P46K>

More documents and user manuals: <https://manuals.plus/>