

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Sony](#) /

› [Sony Bravia FWD-65Z9F 65-inch 4K HDR LED Professional Display User Manual](#)

Sony FWD65Z9F

Sony Bravia FWD-65Z9F 65-inch 4K HDR LED Professional Display User Manual

INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your Sony Bravia FWD-65Z9F 65-inch 4K HDR LED Professional Display. Please read this manual thoroughly before using the product and retain it for future reference.



Figure 1: Sony Bravia FWD-65Z9F 65-inch 4K HDR LED Professional Display. This image shows the display from an angled perspective, showcasing its slim bezel and the vibrant image quality with a red floral pattern on screen.

SAFETY INFORMATION

Always observe the following safety precautions to prevent electric shock, fire, or damage to the display.

- Do not block ventilation openings.
- Do not expose the display to rain or moisture.
- Use only the power cord supplied with the display.
- Refer all servicing to qualified service personnel.

WHAT'S IN THE BOX

Verify that all items are present:

- Sony Bravia FWD-65Z9F 65-inch 4K HDR LED Professional Display
- Stand
- Remote Control
- Power Cord
- Setup Guide
- Warranty Card

SETUP

1. Attaching the Stand

1. Carefully place the display face down on a soft, flat surface.
2. Align the stand with the mounting holes on the back of the display.
3. Secure the stand using the provided screws.

2. Connecting Cables

Connect the necessary cables to the display's rear panel:

- **Power Cord:** Connect to the AC IN port and a power outlet.
- **HDMI Devices:** Use HDMI cables to connect external devices (e.g., Blu-ray player, set-top box) to the HDMI IN ports.
- **USB Devices:** Connect USB storage devices to the USB ports.
- **Network Connection:** For internet access, connect an Ethernet cable to the LAN port or configure Wi-Fi.

3. Initial Power On and Setup Wizard

1. Plug in the power cord and press the power button on the remote control or display.
2. Follow the on-screen instructions to complete the initial setup, including language selection, network configuration, and channel scanning.

OPERATING INSTRUCTIONS

Remote Control Functions

Familiarize yourself with the remote control buttons:

- **Power:** Turns the display on/off.
- **Input:** Selects input sources (HDMI, USB, etc.).
- **Volume +/-:** Adjusts the volume level.
- **Channel +/-:** Changes TV channels.

- **Home:** Accesses the smart TV home screen.
- **Navigation Buttons:** Used to navigate menus and select options.

Smart TV Features

Your Sony Bravia display includes smart TV capabilities:

- **App Access:** Download and use various applications like streaming services (e.g., Amazon Prime Video, YouTube) directly on the display.
- **Web Browser:** Browse the internet using the built-in web browser.
- **Screen Mirroring:** Cast content from compatible mobile devices to the display.

Maintenance

Cleaning the Display

- Turn off the display and unplug the power cord before cleaning.
- Use a soft, dry cloth to gently wipe the screen and cabinet.
- For stubborn marks, lightly dampen the cloth with water or a mild, non-abrasive screen cleaner.
- Avoid using strong detergents or abrasive cleaning agents.

Software Updates

Regularly check for and install software updates to ensure optimal performance and access to new features. Updates can typically be found in the display's settings menu under "System" or "About."

Troubleshooting

Problem	Possible Cause	Solution
No power	Power cord disconnected	Ensure power cord is securely plugged into the display and a working electrical outlet.
No picture/sound	Incorrect input source selected	Press the "Input" button on the remote to select the correct input source.
Poor picture quality	Cable connection issues, source quality	Check all cable connections. Ensure the source device is outputting a high-quality signal.
Remote control not working	Dead batteries, obstruction	Replace batteries. Ensure no obstructions between remote and display.

Specifications

Feature	Detail
Model Number	FWD-65Z9F
Screen Size	65 inches (64.5 inches diagonal)
Display Technology	4K HDR LED (Direct LED)

Feature	Detail
Resolution	3840 x 2160 (4K UHD)
Aspect Ratio	16:9
Refresh Rate	60 Hz
Connectivity	HDMI, USB, Ethernet, Wi-Fi, Serial
Dimensions (W x H x D)	57.2 x 33 x 2.6 inches (without stand)
Item Weight	62.2 pounds (without stand)
Manufacturer	Sony

WARRANTY AND SUPPORT

Your Sony Bravia FWD-65Z9F display comes with a manufacturer's warranty. Please refer to the included warranty card for specific terms and conditions. For technical support, product registration, or additional information, visit the official Sony support website or contact their customer service.

Online Support: [Sony Support Website](#)

© 2023 Sony Corporation. All rights reserved. Information in this document is subject to change without notice.