Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Snailax 482

Snailax Cordless Handheld Back Massager User Manual

Model: 482

Introduction

The Snailax Cordless Handheld Back Massager is designed to provide deep tissue percussion massage and soothing heat therapy for various body parts. Its cordless and rechargeable design offers convenience and portability, allowing for use at home, in the office, or while traveling. This manual provides essential information for safe and effective operation, maintenance, and troubleshooting of your massager.

Safety Information


For your safety and to ensure proper use of the Snailax Cordless Handheld Back Massager, please adhere to the following guidelines:

- Avoid using the massager for more than 15 minutes at a time. Allow the massager to cool down between uses to prevent overheating.
- Do not use the heated feature on sensitive skin or for extended periods to prevent burns.
- Always follow the charging instructions provided to prevent battery damage or overheating.
- Keep the massager out of reach of children and pets, especially when in use or charging.
- Do not use the massager on broken skin or near sensitive areas such as the eyes, ears, or genitals.

Product Features



The Snailax Cordless Handheld Back Massager, showcasing its ergonomic design and included interchangeable massage heads.



The cordless design allows for convenient massage anywhere, such as relaxing on a couch.

- **Cordless & Rechargeable:** Powered by a lithium-ion battery, this massager offers freedom of movement without being tethered to an outlet. The battery lasts approximately 80 minutes on a full charge and can be used while charging.
- **Percussion Massager:** Equipped with a powerful vibration motor, it delivers deep tissue percussion massage to effectively relieve muscle knots and soreness throughout the body.
- **Heat Therapy:** Features a heated massage function with infrared light to provide soothing warmth, helping to relax tension and knots in muscles.
- **Versatile Use:** Includes 4 interchangeable massage heads, 3 automatic massage modes, and 3 adjustable speed settings for a customizable massage experience. Suitable for neck, shoulders, back, waist, arms, legs, and feet.



The massager provides soothing heat for added comfort and muscle relaxation.



The four interchangeable massage heads allow for customized massage experiences for different body parts.

Setup

Before using your Snailax Cordless Handheld Back Massager, follow these setup steps:

1. **Charge the Massager:** Fully charge the massager before its first use. Connect the provided power adapter to the charging port on the massager and plug it into a standard electrical outlet. The battery indicator will show charging status.
2. **Select Massage Head:** Choose the appropriate massage head from the four interchangeable options based on your desired massage type and target body area. Gently push the chosen head onto the massager's main massage point until it clicks securely into place.
3. **Positioning:** Ensure you are in a comfortable position, whether sitting or lying down, to easily reach the area you wish to massage.



The massager comes with a charger and four interchangeable heads for versatile use.

Operating Instructions

Operate your Snailax massager using the integrated control panel on the handle:



The integrated control panel for easy operation.

- **Power Button:** Press the power button ( ) to turn the massager on or off.
- **Intensity Button:** Use the intensity button (‖) to cycle through Low, Medium, and High vibration intensities.
- **Mode Button:** Press the mode button (**M**) to change between the three automatic massage modes (M1, M2, M3).
- **Heat Button:** Activate or deactivate the heat function by pressing the heat button). *Note: For optimal heat function, do not install any interchangeable heads.*
- **Application:** Apply the massager gently to the desired area. Use circular or up-and-down motions, adjusting pressure as needed. Do not press too hard.
- **Duration:** Use the massager for up to 15 minutes per session. Take breaks between sessions to allow the device to cool down and to avoid over-massaging.

Your browser does not support the video tag.

Official product video demonstrating the Cordless Handheld Back Massager SL-482 in use.

Maintenance

Proper maintenance ensures the longevity and hygiene of your massager:

- **Cleaning:** After each use, wipe the massager and its attachments with a soft, damp cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the massager in a cool, dry place away from direct sunlight and extreme temperatures. Keep it in its original packaging or a protective bag to prevent dust accumulation.
- **Battery Care:** To maintain battery health, avoid fully discharging the battery frequently. Charge it regularly, even if not in frequent use.

Troubleshooting

If you encounter issues with your Snailax massager, consider the following common solutions:

Problem	Possible Cause	Solution
Massager does not turn on.	Low battery or not charged.	Ensure the massager is fully charged. Connect it to the power adapter and allow sufficient charging time.
Weak vibration or inconsistent performance.	Low battery; incorrect intensity setting; massage head not properly attached.	Recharge the battery. Adjust the intensity setting. Ensure the massage head is securely attached.
Heat function not working or is weak.	Massage head is installed; heat function not activated.	Remove any attached massage heads for optimal heat. Ensure the heat button is pressed. Allow a few minutes for the heat to build up.
Massager stops unexpectedly.	Overheating protection activated; low battery.	Allow the massager to cool down for at least 30 minutes before resuming use. Recharge the battery if low.

If the problem persists after trying these solutions, please contact Snailax customer support for further assistance.

Specifications

Feature	Detail
Product Dimensions	16.38 x 5.83 x 3.9 inches
Item Model Number	482
Item Weight	2.87 Pounds (1.3 Kilograms)
Batteries	1 Lithium Ion battery (included)
Power Source	Battery Powered
Material	Plastic

Feature	Detail
Manufacturer	Snailax
Date First Available	January 31, 2019



Physical dimensions of the Snailax Cordless Handheld Back Massager.

Warranty and Support

Snailax products are designed for quality and durability. This product typically comes with a standard manufacturer's warranty. For specific warranty details, registration, or to inquire about extended warranty options, please refer to the documentation included with your product or visit the official Snailax website.

For technical support, troubleshooting assistance beyond what is provided in this manual, or any other inquiries, please contact Snailax customer service. You can often find contact information on the product packaging, the official Snailax website, or through the retailer where you purchased the product.

You can also visit the official Snailax Store for more information and support: Snailax Store on Amazon.

© 2025 Snailax. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07LFSHC69

More documents and user manuals: **https://manuals.plus/**