DEWALT DWE305

DEWALT DWE305 12 Amp Corded Reciprocating Saw and DW4898 Bi-Metal Blade Set Instruction Manual

Model: DWE305 | Brand: DEWALT

Introduction

This manual provides essential instructions for the safe operation, maintenance, and setup of your DEWALT DWE305 12 Amp Corded Reciprocating Saw and the accompanying DW4898 Bi-Metal Reciprocating Saw Blade Set. Please read this manual thoroughly before using the tool to ensure safe and effective use.

Important Safety Instructions

Always follow basic safety precautions to reduce the risk of fire, electric shock, and personal injury. Failure to follow these instructions may result in serious injury.

- **Read All Instructions:** Familiarize yourself with the tool's operation and safety guidelines before use.
- **Wear Eye Protection:** Always wear safety glasses or goggles that comply with applicable standards.
- **Secure Workpiece:** Use clamps or other practical ways to secure the workpiece to a stable platform. Holding the work by hand or against your body is unstable and may lead to loss of control.
- **Keep Hands Clear:** Never place hands near the cutting area or blade.
- **Disconnect Power:** Always unplug the saw from the power source before changing blades, making adjustments, or performing maintenance.
- **Use Appropriate Blades:** Select the correct blade type for the material being cut to ensure efficient and safe operation.
- **Avoid Hazardous Environments:** Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- **Maintain Proper Footing:** Ensure stable footing and balance at all times. Do not overreach.
- **Store Idle Tools Safely:** When not in use, store tools in a dry, high, or locked-up place out of reach of children.

Product Overview

The DEWALT DWE305 is a powerful 12-amp corded reciprocating saw designed for heavy-duty cutting applications. It features a variable speed trigger for precise control and a 4-position blade clamp for increased versatility, including flush

cutting. The DW4898 blade set provides a selection of bi-metal blades suitable for various materials such as wood, metal, plastic, and fiberglass.




Image: DEWALT DWE305 12 Amp Corded Reciprocating Saw with a selection of yellow bi-metal saw blades. The saw is yellow and black, featuring a comfortable grip and a corded power supply. The blades vary in length and tooth configuration for different cutting tasks.

Setup

Unpacking

Carefully remove the saw and blade set from the packaging. Inspect all components for any signs of damage that may have occurred during shipping. Retain the packaging for future storage or transport of the tool.

Blade Installation

1. Ensure the saw is unplugged from the power source to prevent accidental startup.
2. Locate the keyless lever-action blade clamp on the front of the saw.

3. Lift the lever to open the blade clamp mechanism.
4. Insert the shank of the desired blade fully into the clamp.
5. Release the lever to secure the blade. Gently tug on the blade to ensure it is firmly seated and locked in place.

Power Connection

Connect the saw's power cord to a suitable 120V AC (or local standard) grounded electrical outlet. Ensure the outlet is protected by a Ground Fault Circuit Interrupter (GFCI) if operating in damp or wet locations, as recommended for electrical safety.

Operating Instructions

General Operation

To start the saw, depress the variable speed trigger. The cutting speed is controlled by the amount of trigger depression; pressing further increases the speed. To stop the saw, simply release the trigger.

Cutting Techniques

- **Wood and Nail-Embedded Wood:** Use coarse-tooth blades (e.g., 6 TPI) for fast cutting through wood.
- **Light to Heavy Gauge Metals:** Utilize fine-tooth bi-metal blades (e.g., 14 TPI, 18 TPI). Applying cutting fluid can enhance performance and extend blade life.
- **Drywall and Plaster:** General-purpose blades are suitable for these materials.
- **Plastics, Rubber, Fiberglass, and Composites:** Select blades appropriate for the specific density and thickness of the material to achieve optimal results.

4-Position Blade Clamp

The saw features a 4-position blade clamp, which allows the blade to be oriented in four different directions. This functionality is particularly useful for flush cutting applications or when working in confined spaces. To change the blade position, follow the blade installation steps and rotate the blade to the desired orientation before securing the clamp lever.

Maintenance

Cleaning

Regularly clean the saw's ventilation openings to prevent dust buildup and ensure proper motor cooling. Use a soft brush or compressed air to clear debris. Do not use solvents or harsh chemicals, as they may damage plastic parts.

Blade Replacement

Replace dull or damaged blades promptly. A dull blade can reduce cutting efficiency and increase strain on the tool. Refer to the "Blade Installation" section for the proper procedure.

Storage

Store the saw and blades in a dry, secure location, out of reach of children and unauthorized users. The DW4898 blade set includes an adjustable ToughCase designed for safe and organized blade storage.

Troubleshooting

Problem	Possible Cause	Solution
Saw does not start	No power supply, faulty power cord or switch	Check power connection, wall outlet, and circuit breaker. If problem persists, consult a qualified service technician.
Blade not cutting efficiently	Dull blade, incorrect blade type for material	Replace the blade with a sharp one. Ensure the correct blade type (e.g., TPI) is selected for the material being cut.
Excessive vibration during operation	Loose blade, damaged blade, worn internal components	Ensure the blade is securely clamped. Replace any damaged blades. If vibration continues, seek professional service.

Specifications

- **Brand:** DEWALT
- **Model:** DWE305
- **Power Source:** Corded Electric
- **Motor:** 12 Amp
- **Strokes Per Minute (SPM):** 0-2,900
- **Stroke Length:** 1-1/8 inches
- **Wattage:** 1440 watts
- **Special Feature:** Brushless Motor
- **Blade Material (DW4898 Set):** Bi-Metal, High Speed Steel
- **Surface Recommendation:** Fiberglass, Metal, Plastic, Wood

Warranty and Support

This DEWALT product comes with a limited warranty. For detailed warranty information, service, or technical support, please refer to the warranty card included with your purchase or visit the official DEWALT website. For direct assistance, contact DEWALT customer service.

© 2025 DEWALT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question