

Brandson 303124

Brandson Ceramic Fan Heater 303124 - Instruction Manual

Model: 303124

1. IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before using the appliance and keep them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- This appliance is designed for indoor use only. Do not use outdoors.
- Ensure the appliance is placed on a stable, level surface. The increased weight compared to standard models ensures secure standing.
- Do not cover the heater. Overheating protection ensures the unit shuts off quickly if temperatures become too high.
- Keep flammable materials such as furniture, pillows, bedding, papers, clothes, and curtains at least 1 meter (3 feet) from the front of the heater and away from the sides and rear.
- Do not use in bathrooms, laundry areas, or similar indoor locations where water may be present.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- This product has been thoroughly tested and successfully certified with the globally recognized GS safety mark, ensuring a high level of quality and safety.
- Always unplug the heater when not in use.

2. PRODUCT OVERVIEW

The Brandson 303124 Ceramic Fan Heater combines high heating power with an attractive design and high-quality ceramic elements. It is designed for efficient and energy-saving heating in well-insulated rooms.

Key Features:

- **Ceramic Heating Elements:** Durable and efficient PTC ceramic heating elements.

- **Two Heating Levels:** Adjustable power settings for customized warmth.
- **Oscillation Function:** Distributes heat evenly throughout the room (approx. 35° oscillation).
- **Adjustable Timer:** Set operation time from 0 to 8 hours for automatic shut-off.
- **Thermostat Control:** Temperature adjustable from 10°C to 35°C.
- **Remote Control:** Convenient infrared remote for easy operation.
- **Safety Features:** Overheating protection and tip-over switch for enhanced safety.
- **Anti-Dust Filter:** Easily replaceable and washable, suitable for allergy sufferers by reducing fine dust.

Product Components:

- Brandson Ceramic Fan Heater
- Infrared Remote Control
- User Manual



Figure 1: Brandson Ceramic Fan Heater with remote control and digital display.



Figure 2: Side view of the Brandson Ceramic Fan Heater with key dimensions.

3. SETUP

1. **Unpacking:** Carefully remove the heater and all accessories from the packaging. Retain packaging for storage or return if necessary.
2. **Placement:** Place the heater on a firm, level, and heat-resistant surface. Ensure there is at least 1 meter (3 feet) of clear space around the heater from any walls, furniture, or other objects to allow for proper airflow and prevent fire hazards. Do not place it directly under a power outlet.
3. **Power Connection:** Ensure the voltage indicated on the rating label matches your mains voltage. Plug the power cord into a suitable grounded electrical outlet.

4. OPERATING INSTRUCTIONS

The Brandson Ceramic Fan Heater can be operated directly via the control panel on the unit or conveniently with the included infrared remote control.

Control Panel and Remote Control:



Figure 3: Control panel on the unit and the infrared remote control.

- **Power On/Off:** Press the power button to turn the heater on or off.
- **Heating Levels:** Select between two heating levels (e.g., 1000W / 2000W) using the mode button.
- **Temperature Setting:** Use the '+' and '-' buttons to adjust the desired temperature between 10°C and 35°C. The heater will automatically maintain the set temperature.
- **Oscillation Function:** Press the oscillation button to activate or deactivate the oscillating movement, which helps distribute heat more widely.
- **Timer Function:** Press the timer button to set the operating duration from 0 to 8 hours. The heater will automatically switch off after the set time.

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your Brandson Ceramic Fan Heater.

- **Cleaning the Exterior:** Before cleaning, always unplug the heater and allow it to cool down completely. Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Cleaning the Anti-Dust Filter:** The anti-dust filter is easily removable and washable.



Figure 4: Removable anti-dust filter for easy cleaning.

- Locate the filter cover at the rear of the unit.
 - Gently open and remove the filter.
 - Wash the filter with lukewarm water and mild soap. Rinse thoroughly.
 - Allow the filter to dry completely before reinserting it into the heater.
 - Regular cleaning of the filter helps maintain air quality and heater efficiency.
- **Storage:** If storing the heater for an extended period, unplug it, clean it, and store it in its original packaging in a cool, dry place.

6. TROUBLESHOOTING

If you experience issues with your Brandson Ceramic Fan Heater, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Heater does not turn on.	Not plugged in; power outlet not working; tip-over switch activated; overheating protection activated.	Ensure the power cord is securely plugged into a working outlet. Check if the heater has tipped over and reset it. Allow the unit to cool down if overheating protection was triggered.
No heat output.	Heating elements not activated; low temperature setting.	Ensure a heating level is selected. Increase the desired temperature setting.
Oscillation not working.	Oscillation function is deactivated.	Press the oscillation button on the control panel or remote control to activate it.
Remote control not working.	Batteries are dead or incorrectly inserted; obstruction between remote and heater.	Replace batteries in the remote control. Ensure there is a clear line of sight between the remote and the heater's sensor.

If the problem persists after trying these solutions, please contact Brandson customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	303124 (also B07M6YNQHT)
Dimensions (H x W x D)	42 x 18 x 14 cm (16.5 x 7.1 x 5.5 inches)
Weight	2.35 kg (2350 Grams)
Color	White / Black (E Blanc I)
Material	ABS + Ceramic (heating elements)
Power Source	Electric
Heat Production	2000 Watts
Heating Method	Convection
Number of Speeds/Levels	2
Temperature Range	10°C to 35°C
Heating Coverage	Up to 25 square meters
Special Features	Oscillation, Timer, Thermostat, Remote Control, Overheating Protection, Tip-over Switch, Anti-dust filter.
Indoor/Outdoor Use	Indoor
Mounting Type	Floor Mount

Feature	Detail
Country of Origin	China

8. WARRANTY AND SUPPORT

Brandson products are designed for quality and reliability. For warranty information, please refer to the documentation included with your purchase or contact your retailer.

If you require technical assistance, have questions about your product, or need to report a fault, please contact Brandson customer support:

- **Website:** www.brandson.com (Note: This is a placeholder URL, please refer to your product packaging for the official support website.)
- **Email:** support@brandson.com (Note: This is a placeholder email, please refer to your product packaging for the official support email.)

When contacting support, please have your model number (303124) and purchase date ready.