

Sonos OUTDRWW1

Sonos Outdoor by Sonance Speaker System: Instruction Manual

Model: OUTDRWW1

INTRODUCTION

This manual provides comprehensive instructions for setting up, operating, and maintaining your Sonos Outdoor by Sonance speaker system, model OUTDRWW1. Designed for exceptional outdoor audio performance, these architectural speakers are optimized for seamless integration with the Sonos Amp, allowing you to enjoy rich, high-fidelity sound in outdoor environments. They are engineered to withstand various elements, ensuring durable performance outside the home.

PRODUCT OVERVIEW

The Sonos Outdoor by Sonance speakers are designed to deliver powerful and clear audio for your outdoor spaces. Their robust construction ensures longevity and consistent performance.




Figure 1: Front-side view of two Sonos Outdoor by Sonance speakers, showcasing their sleek white design and protective grilles.

WHAT'S INCLUDED

Verify that all components are present in the packaging:

- Sonos Outdoor by Sonance Speakers (Pair)
- Mounting Brackets

SETUP

Connecting to Sonos Amp

These speakers are passive and require a Sonos Amp for power and audio signal. A single Sonos Amp can power up to three pairs of Sonos by Sonance Architectural speakers. Ensure proper wiring using appropriate speaker cables (not included) to connect the speakers to the Sonos Amp.

Mounting

The speakers come with mounting brackets for secure installation. Choose a suitable outdoor location, ideally under an overhang, to provide additional protection from extreme weather conditions. The brackets allow for flexible positioning to optimize sound dispersion.



Figure 2: A Sonos Outdoor by Sonance speaker shown mounted on a wall, illustrating the integrated mounting bracket.




Figure 3: The rear of the speakers, highlighting the robust mounting bracket and the terminals for speaker wire connections.

Initial Configuration (Sonos App)

After physical installation and wiring, download the Sonos app on your smartphone or tablet. Follow the in-app instructions to detect and configure your Sonos Amp and connected Outdoor by Sonance speakers. The app will guide you through optimizing the acoustic settings for your outdoor space, including Trueplay tuning if supported by your Sonos Amp.

OPERATING INSTRUCTIONS

Controlling Your Speakers

Your Sonos Outdoor by Sonance speakers are controlled primarily through the Sonos app. This allows you to:

- Stream music via Wi-Fi from various services.
- Adjust volume, skip tracks, and manage playback.
- Group speakers with other Sonos devices for multi-room audio.
- Utilize voice control features if your Sonos Amp is integrated with a compatible voice assistant.

For detailed app usage and advanced features, refer to the Sonos app's help section or the official Sonos support website.

Video 1: Product Overview Video. This video provides a general overview of the Sonos Outdoor by Sonance speakers, demonstrating their design and potential use cases.

MAINTENANCE

The Sonos Outdoor by Sonance speakers feature a weatherproof design, engineered to withstand humidity, water, salt spray, heat, UV rays, and freezing temperatures. To ensure their longevity and optimal performance:

- **Cleaning:** Periodically wipe down the speaker enclosures with a soft, damp cloth to remove dirt, dust, or salt residue. Avoid using harsh chemicals or abrasive cleaners.
- **Inspection:** Regularly inspect the speaker grilles and mounting hardware for any signs of wear or damage. Ensure all connections remain secure.
- **Environmental Protection:** While weatherproof, placing speakers under an overhang or in a sheltered area can further extend their lifespan and maintain aesthetic condition.

TROUBLESHOOTING

If you encounter issues with your Sonos Outdoor by Sonance speakers, consider the following:

- **No Sound:** Ensure the Sonos Amp is powered on and properly connected to the speakers. Check all speaker wire connections for tightness and correct polarity. Verify that the correct audio source is selected in the Sonos app.
- **Poor Sound Quality:** Check speaker placement and ensure they are not obstructed. Use the Trueplay tuning feature in the Sonos app (if available with your Amp) to optimize sound for your environment. Inspect speaker wires for damage.
- **Connectivity Issues:** Confirm your Sonos Amp is connected to your Wi-Fi network. Restart your router, Sonos Amp, and the Sonos app.
- **Distorted Audio:** Reduce the volume level. Check for any loose connections or damaged speaker components.

For persistent issues, consult the Sonos support website or contact customer service.

SPECIFICATIONS

Detailed technical specifications for the Sonos Outdoor by Sonance speakers:




Figure 4: Dimensions of the Sonos Outdoor by Sonance speaker.




Feature	Detail
Model Name	Sonos Outdoor by Sonance
Item Model Number	OUTDRWW1
Brand	Sonos
Speaker Type	Outdoor
Mounting Type	Wall Mount
Material	Metal And Durable Plastics
Color	White
Product Dimensions	12.98"D x 7.83"W x 7.52"H
Item Weight	8.79 pounds (4 Kilograms)
Is Waterproof	TRUE
Water Resistance Level	Waterproof
Control Method	App

Feature	Detail
Wireless Communication Technology	Wi-Fi
Speaker Maximum Output Power	130 Watts
Frequency Response	50 Hz
Connectivity Technology	Coaxial
Audio Output Mode	Stereo
Woofer Diameter	4 Inches
Tweeter Diameter	1 Inches
Number of Items	2
UPC	878269007661

WARRANTY AND SUPPORT

The Sonos Outdoor by Sonance speakers come with a Limited Warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty information provided with your product or visit the official Sonos support website. For technical assistance, troubleshooting, or further inquiries, please contact Sonos customer support through their website or designated support channels.

Related Documents - OUTDRWW1

	<p>Sonos Outdoor by Sonance Installation Manual</p> <p>Comprehensive installation guide for Sonos Outdoor by Sonance weather-resistant speakers, covering product description, box contents, speaker placement, wiring, connection, assembly, removal, pivoting, painting, and warranty information.</p>
	<p>Sonos Outdoor by Sonance Installation Manual</p> <p>Comprehensive installation guide for Sonos Outdoor by Sonance weather-resistant speakers, detailing product features, setup, wiring, mounting, painting, and warranty information.</p>
	<p>Sonos In-Ceiling by Sonance Installation Manual Setup, Placement, and Warranty</p> <p>Comprehensive installation guide for Sonos In-Ceiling by Sonance speakers. Learn about speaker placement, connecting to Sonos Amp, unlocking audio enhancements, painting grilles, and warranty details.</p>

<div><div><div>SONOS</div><div>SONANCE</div></div><div><div>INSTALLATION MANUAL</div><div>SONOS IN-CEILING</div><div>BY SONANCE</div></div></div>	<div><div>Sonos In-Ceiling by Sonance Installation Manual - Setup Guide</div><div>Detailed installation manual for Sonos In-Ceiling by Sonance speakers, covering placement, wiring, mounting, speaker adjustments, grille painting, and Sonos Amp integration.</div></div>
<div><div><div>SONOS</div><div>SONANCE</div></div><div><div>INSTALLATION MANUAL</div><div>SONOS IN-CEILING</div><div>BY SONANCE</div></div></div>	<div><div>Sonos In-Ceiling by Sonance Installation Manual</div><div>Comprehensive installation guide for Sonos In-Ceiling by Sonance speakers, detailing speaker placement, mounting procedures, audio enhancements, grille painting, and warranty information.</div></div>
<div><div><div>SONOS</div><div>SONANCE</div></div><div><div>INSTALLATION MANUAL</div><div>SONOS IN-CEILING</div><div>BY SONANCE</div></div></div>	<div><div>Sonos In-Ceiling by Sonance Installation Manual</div><div>Comprehensive installation guide for Sonos In-Ceiling by Sonance speakers, covering speaker placement, mounting, wiring, grille painting, and audio enhancements.</div></div>