



Manuals.plus /

- › Tamagotchi /
- › Tamagotchi x Gudetama (Model 42820) Digital Pet Instruction Manual

Tamagotchi 42820

Tamagotchi x Gudetama Digital Pet Instruction Manual

Model: 42820

1. INTRODUCTION

Welcome to the world of Tamagotchi x Gudetama! This manual provides essential instructions for setting up, operating, and maintaining your new digital pet. Follow these guidelines to ensure a fun and engaging experience with your Gudetama.

BAN
DAI

15+

#42820
#42821

gudetama™ Tamagotchi®

HATCH
FAIS ÉCLORE
ROMPE EL
CASCARÓN



TAKE CARE OF
GUDETAMA
PREND S OIN
DE GUDETAMA
CUIDA A
GUDETAMA



FEED • NOURRIS
ALIMENTA



OR IT BECOMES
AN EGG DISH
OU IL DEVIENT UN
PLAT AUX CEUFS
O SE CONVIERTE EN
UN PLATO DE HUEVO



2 LR44 batteries included / 2 piles LR44 inclusas / 2 pilas LR44 incluidas.

⚠️ **WARNING:**
CHOKING HAZARD
Small parts. Not for children under 3 years.

⚠️ **AVERTISSEMENT:**
RISQUE D'ÉTOUFFEMENT - Petites pièces.
Ne convient pas aux enfants de moins de 3 ans.

⚠️ **ADVERTENCIA:** PELIGRO DE ASFIXIA - Piezas pequeñas.
No apto para niños de menos de 3 años.

Image 1: Tamagotchi x Gudetama (Yellow) in original packaging.

2. WHAT'S IN THE BOX

Your Tamagotchi x Gudetama package includes:

- 1 Gudetama Tamagotchi device with chain
- 2 LR44 Batteries (pre-installed)



Image 2: Contents of the Tamagotchi x Gudetama package.

3. SETUP

3.1. Initial Activation

1. Locate the plastic pull-tab on the back of the device.
2. Gently pull out the tab to activate the batteries.
3. The device will power on, and you will hear a sound.

3.2. Setting the Time

Upon activation, you will need to set the current time. Use the buttons on the device to adjust the hours and minutes. Refer to the on-screen prompts for guidance.

4. OPERATING YOUR TAMAGOTCHI X GUDETAMA

Your Gudetama will hatch shortly after setup. Once hatched, it requires your attention and care to grow and evolve.

4.1. Basic Care

- **Feeding:** Your Gudetama will indicate when it is hungry. Select the food icon to feed it soy sauce or a tomato.
- **Playing:** Engage with your Gudetama by playing games. This helps keep it happy and prevents it from turning into an egg dish.
- **Attention:** Respond to your Gudetama's calls for attention. Neglect can lead to undesirable outcomes.
- **Lights:** Turn the lights on or off as needed, especially when Gudetama is sleeping.



gudetama™
Tamagotchi



HATCH
FAIS ÉCLORE
ROMPE EL
CASCARÓN



FEED
NOURRIS
ALIMENTA



PLAY
JOUE
JUEGA



RAISE YOUR GUDETAMA • ÉLÈVE TON GUDETAMA • CRÍA A TU GUDETAMA



EGG
ŒUF
HUEVO



BABY
BÉBÉ
BEBÉ



GROW TO BE ONE OF
IL GRANDIRA ET DEVIENDRA UN DES
CRECE PARA SER UNO DE LOS




8 CHARACTERS
PERSONNAGES
PERSONAJES

BECOME ONE OF
DEVIENS UN DES
SE CONVIERTE EN
UNO DE

20

EGG DISHES
PLATS AUX ŒUFS
PLATOS DE
HUEVOS



Find Gudetama online. • Trouve Gudetama en ligne. • Encuentra a Gudetama en línea.



gudetarna



sanrio



gudetama



SIL-34842



gudetama™
by Sanrio®

B3L

MADE IN CHINA. Actual size, color, style and decoration may vary.

Distributed by Bandai America Incorporated.
2120 Park Place, Suite 120, El Segundo, California 90245.

Bandai logo: © and © 2018 Bandai. TAMAGOTCHI and all related logos, names and distinctive likenesses are the exclusive property of Bandai. © BANDAI, WIZ. All Rights Reserved. Package: © 2018 Bandai.

FABRIQUÉ EN CHINE. Taille, couleur, style et décoration réels pouvant varier.

Distribué par Bandai America Incorporated. 2120 Park Place,
Suite 120, El Segundo, California 90245. Logo Bandai: MD et © 2018 Bandai.

TAMAGOTCHI et les logos, noms et ressemblances distinctives connexes appartiennent exclusivement à Bandai.
© BANDAI, WIZ. Tous droits réservés. Emballage: © 2018 Bandai.

HECHO EN CHINA. Tamaño, color, estilo y decoraciones reales pueden variar. Distribuido por Bandai America Incorporated. 2120 Park Place, Suite 120, El Segundo, California 90245. Logotipo Bandai: © y © 2018 Bandai. TAMAGOTCHI y los logotipos, nombres y similitudes distintivas asociadas son propiedad exclusiva de Bandai. © BANDAI, WIZ. Todos los derechos reservados. Embalaje: © 2018 Bandai.

IMPORTADO Y DISTRIBUIDO EN MÉXICO POR: BANDAI CORPORACIÓN MÉXICO, S.A. DE C.V. Av. Insurgentes Sur No. 863, Piso 11, Colonia Nápoles, C.P. 03810, Ciudad de México, México, Tel. 01-800-1BANDAI (01 800 1226324).



Your Gudetama will evolve through different stages based on the care it receives. There are 8 different versions of Gudetama and 20 kinds of egg dishes it can become. Experiment with different care routines to discover all the possible evolutions.

5. MAINTENANCE

5.1. Cleaning

To clean your Tamagotchi device, gently wipe it with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the screen or casing.

5.2. Battery Replacement

The device uses 2 LR44 batteries. When the display becomes dim or the device stops responding, it's time to replace the batteries. Carefully open the battery compartment on the back of the device, remove the old batteries, and insert new ones, ensuring correct polarity. Dispose of used batteries responsibly.

6. TROUBLESHOOTING

- **Device not turning on:** Ensure the plastic pull-tab has been removed. If it has, check that the LR44 batteries are correctly installed and not depleted.
- **Gudetama is unhappy/sick:** Provide regular care, including feeding, playing, and responding to its needs. If it appears sick, look for a medicine option in the menu.
- **Screen issues:** If the screen is dim or flickering, replace the batteries. If the issue persists, contact customer support.
- **Sound issues:** Check the device's settings to ensure the sound is not muted.

7. SPECIFICATIONS

Feature	Detail
Model Number	42820
Product Dimensions	1.34"L x 0.98"W x 1.5"H
Item Weight	1.41 ounces
Power Source	Battery Powered
Batteries Required	2 LR44 batteries (included)
Display Type	LCD
Material	Plastic
Manufacturer Recommended Age	15 years and up

8. SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

This product contains small parts and batteries. Keep out of reach of small children to prevent accidental ingestion. Adult supervision is recommended for younger users.

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official Tamagotchi website. Keep your proof of purchase for any warranty claims.