

[Manuals.plus](#) /

› [PAGARIA](#) /

› PAGARIA SANYONI COMMANDER FM Recorder Bluetooth Speaker User Manual

PAGARIA SANYONI COMMANDER

PAGARIA SANYONI COMMANDER FM Recorder Bluetooth Speaker User Manual

Model: SANYONI COMMANDER

INTRODUCTION

The PAGARIA SANYONI COMMANDER is a versatile FM Recorder Bluetooth Speaker designed for audio playback and recording. It features a built-in 16GB memory, FM radio, Bluetooth connectivity, USB and Micro SD card support, AUX input, and a microphone function for recording. This manual provides detailed instructions for setting up, operating, and maintaining your device.

PACKAGE CONTENTS

- PAGARIA SANYONI COMMANDER Speaker
- Remote Control
- Carry Sling
- AUX Cable

SETUP

1. Unpacking

Carefully remove all components from the packaging. Inspect the speaker and accessories for any signs of damage. Retain the packaging for future transport or storage.

2. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided charging cable to the speaker's charging port and a suitable USB power adapter (not included). The charging indicator will show the charging status and turn off when fully charged.

3. Powering On/Off

To power on the speaker, press and hold the Power button located on the control panel. The LCD screen will illuminate. To power off, press and hold the Power button again until the screen turns off.



Figure 1: Front view of the PAGARIA SANYONI COMMANDER speaker, showing the display and speaker grille.

OPERATING INSTRUCTIONS

1. Control Panel and Remote

The speaker can be operated using the buttons on its top panel or the included remote control. The remote offers full functionality for convenient operation from a distance of up to 10 meters.



Figure 2: Top panel of the speaker, illustrating the various control buttons for mode selection, playback, recording, and volume.

2. Mode Selection

Press the **MODE** button on the speaker or remote to cycle through available modes: FM Radio, Bluetooth, USB, Micro SD, and AUX.

3. FM Radio Operation

- **Automatic Scan:** In FM mode, press and hold the **P/P/SCAN** button to automatically scan and save available FM stations.
- **Manual Tuning:** Use the **TUN-** and **TUN+** buttons to manually adjust the frequency.
- **Station Navigation:** Use the **PREV/CH-** and **NEXT/CH+** buttons to switch between saved stations.

4. Bluetooth Connectivity

- Switch the speaker to Bluetooth mode. The LCD screen will display "Bluetooth" or a similar indicator.
- On your mobile device, laptop, or computer, enable Bluetooth and search for available devices.
- Select "SANYONI COMMANDER" from the list of devices to pair. A confirmation sound will indicate successful pairing.

- You can now play audio from your connected device through the speaker.

5. USB and Micro SD Playback

- Insert a USB drive into the USB port or a Micro SD card into the Micro SD slot.
- Switch the speaker to USB or Micro SD mode. The speaker will automatically detect and begin playing audio files (MP3 format supported).
- Use the **PREV/CH-**, **NEXT/CH+**, **PLAY/PAUSE** buttons to control playback.
- The **FOLD+** and **FOLD-** buttons allow navigation through folders on your storage device.
- The LCD screen will display the song name and other relevant information.

6. AUX Input

- Connect one end of the provided AUX cable to the speaker's AUX input port and the other end to the audio output jack of your external device (e.g., mobile phone, laptop).
- Switch the speaker to AUX mode. Audio from your external device will now play through the speaker.

7. Recording Function

The SANYONI COMMANDER supports recording from FM radio, online sources (via AUX input), and microphone input.

- **FM Recording:** In FM mode, press the **REC** button to start recording the current FM broadcast. Press **REC** again to stop and save the recording.
- **Online/AUX Recording:** Connect your mobile device or laptop via the AUX cable and play audio from online apps. In AUX mode, press the **REC** button to record the audio. Press **REC** again to stop and save.
- **Microphone Recording:** Connect a microphone to the designated MIC input. Press the **REC** button to start recording your voice. Press **REC** again to stop and save.
- **Playback Recordings:** Use the **REC PLAY** button to access and play your saved recordings.



SANYONI

Commander



Listen &
Record your
Favourite Songs
online



MAKE YOUR OWN PLAYLIST OF **7000** SONGS



Figure 3: Illustration of the speaker's capability to record audio from online sources when connected via AUX to a mobile device.



SANYONI

Commander

BE A RISING STAR,
with mic *Sing & Record* function.

"Dad now even I can
sing and *record*
my songs..."



MAKE YOUR
OWN PLAYLIST OF **7000** SONGS



Figure 4: Depiction of using the speaker with a microphone for voice recording.

8. Digital Equalizer

The speaker features a digital equalizer. Press the **EQ** button to cycle through various preset sound modes to optimize audio output for different music genres.

9. Portability

Attach the included carry sling to the designated points on the speaker for easy portability.



Figure 5: A person carrying the PAGARIA SANYONI COMMANDER speaker using the provided shoulder sling, demonstrating its portability.

MAINTENANCE

1. Cleaning

Wipe the speaker's exterior with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish. Avoid getting moisture into any openings.

2. Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the battery is partially charged before storage to prolong its lifespan.

3. Battery Care

To maintain optimal battery performance, avoid fully discharging the battery frequently. Recharge the speaker when the low battery indicator appears.

TROUBLESHOOTING

- **No Power:** Ensure the speaker is charged. Connect it to a power source and try turning it on again.
- **No Sound:** Check the volume level on both the speaker and the connected device. Ensure the correct mode (Bluetooth,

USB, AUX) is selected. For AUX, verify the cable connection.

- **Bluetooth Not Connecting:** Ensure the speaker is in Bluetooth mode and discoverable. Turn off and on Bluetooth on your device, then try pairing again. Make sure no other device is currently connected to the speaker.
- **FM Reception Poor:** Extend the antenna fully. Try repositioning the speaker to improve signal reception.
- **Recording Issues:** Ensure sufficient space is available on the internal 16GB memory. Check microphone connection if recording voice.
- **Remote Control Not Working:** Check the remote control's batteries. Ensure there are no obstructions between the remote and the speaker's IR receiver.

SPECIFICATIONS

Brand	PAGARIA
Model Number	SANYONI COMMANDER
Speaker Type	Dual Speaker
Peak Power Handling	10 Watts (5 x 2 Watts Dual Passive Radiator)
Product Dimensions (LxWxH)	23 x 14 x 5 cm
Item Weight	1.14 kg
Built-in Memory	16 GB
Connectivity	Bluetooth V5.0, USB, Micro SD, AUX
Microphone Form Factor	Built-in (external mic also supported)
Audio Format	MP3 Audio
Included Components	Speaker, Remote, Carry Sling, Aux Cable

WARRANTY INFORMATION

The PAGARIA SANYONI COMMANDER FM Recorder Bluetooth Speaker comes with a **One Year Warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your purchase receipt as proof of purchase. The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

SUPPORT

For technical assistance, warranty claims, or further inquiries, please contact PAGARIA customer support. Refer to the contact information provided with your product packaging or visit the official PAGARIA website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07M7Z5F92>

More documents and user manuals: **<https://manuals.plus/>**