Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY 2018122025

YING RAY Replacement Remote Control User Manual

For Sea Breeze Air Conditioners (Model 2018122025)

Introduction

This manual provides instructions for the YING RAY Replacement Remote Control, model 2018122025, designed for various Sea Breeze and Thermal Zone air conditioner units. This remote control features a green backlight for easy operation in low light conditions and displays temperature in Fahrenheit. Please read this manual thoroughly before use to ensure proper operation and longevity of your remote control.






Image: Front view of the YING RAY replacement remote control. The display shows '84°F' with 'FAN', 'AUTO', and 'OPER' indicators. Buttons for 'OFF/ON', 'MODE', '-', '+', 'FAN', 'HEALTH', 'BLOW', 'HUMIDITY', 'TURBO', 'SLEEP', 'TIME', and light functions are visible.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA 1.5V ordinary batteries, ensuring the positive (+) and negative (-) terminals match the markings inside the compartment.
4. Close the battery cover by sliding it back into place until it clicks securely.

Note: Batteries are not included with the remote control. Always use new batteries and dispose of old batteries responsibly.



Image: A hand holding the YING RAY replacement remote control, showing the side profile and button layout. This illustrates the ergonomic design for comfortable use.

Operating Instructions

Point the remote control directly at the air conditioner unit's receiver. Ensure there are no obstructions between the remote and the unit.

- **OFF/ON Button:** Press to turn the air conditioner unit on or off.
- **MODE Button:** Cycles through available operating modes (e.g., Cool, Heat, Fan, Dry, Auto).

- **+/- Buttons:** Adjust the temperature setting. The display shows temperature in Fahrenheit.
- **FAN Button:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **HEALTH Button:** Activates or deactivates the 'Health' function, if supported by your AC unit.
- **BLOW Button:** Activates or deactivates the 'Blow' function, if supported by your AC unit.
- **HUMIDITY Button:** Controls humidity settings, if supported by your AC unit.
- **TIME Button:** Sets the timer for scheduled operation. Refer to your air conditioner's main manual for detailed timer programming.
- **TURBO Button:** Activates maximum cooling or heating for rapid temperature change.
- **SLEEP Button:** Activates the 'Sleep' mode, which adjusts temperature and fan speed for comfortable sleep.
- **Light Button (Sun/Lightbulb icon):** Activates or deactivates the green backlight on the remote control's display for visibility in the dark.



Image: A close-up view of the top of the remote control, highlighting the infrared (IR) emitter. This component sends signals to the air conditioner unit.

Maintenance

Battery Replacement

When the remote control's display becomes dim or the remote stops responding, it is time to replace the batteries. Follow the battery installation steps outlined in the 'Setup' section.

Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's surface or internal components.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA 1.5V batteries.
  - Ensure there are no obstructions between the remote control and the air conditioner unit.
  - Make sure you are within the effective range of the air conditioner's receiver.
- **Display is dim or blank:**
  - Replace the batteries.
- **Air conditioner not responding to specific functions:**
  - Some functions on the remote may not be supported by all air conditioner models. Refer to your air conditioner's original manual for supported features.

Specifications

Brand	YING RAY
Model Number	2018122025
Compatible Devices	Air Conditioner (Sea Breeze / Thermal Zone models)
Connectivity Technology	Infrared
Special Feature	Ergonomic, Green Backlight
Display Temperature Unit	Fahrenheit
Battery Type	2 x AAA 1.5V (not included)

Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the seller directly. Keep your purchase receipt as proof of purchase.

© 2026 YING RAY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07M88BCWM

More documents and user manuals: **https://manuals.plus/**