

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Rowenta](#) /

› [Rowenta Smart Force Robot Vacuum Remote Control User Manual](#)

## Rowenta RS-RT900911

# Rowenta Smart Force Robot Vacuum Remote Control User Manual

Model: RS-RT900911

## 1. INTRODUCTION

This manual provides essential instructions for the proper use and maintenance of your Rowenta Smart Force Robot Vacuum Remote Control (Model RS-RT900911). This remote control is designed to provide convenient operation for compatible Rowenta Smart Force Essential robot vacuum models, including RR6925, RR6926, RR6927, RR6943, RR6971, and RR6976. Please read this manual thoroughly before using the remote control to ensure optimal performance and longevity.

## 2. SAFETY INSTRUCTIONS

- Keep the remote control away from water and other liquids to prevent damage.
- Do not expose the remote control to extreme temperatures or direct sunlight.
- Avoid dropping the remote control or subjecting it to strong impacts.
- Do not attempt to disassemble or repair the remote control yourself. Contact authorized service personnel for assistance.
- Dispose of used batteries according to local regulations. Do not mix old and new batteries, or different types of batteries.
- Keep batteries out of reach of children.

## 3. PRODUCT OVERVIEW

The Rowenta Smart Force Robot Vacuum Remote Control allows you to manage your robot vacuum's functions from a distance. It features an intuitive button layout for easy navigation and control.



**Image 1:** Rowenta Smart Force Robot Vacuum Remote Control. This image displays the red-colored remote control, highlighting its ergonomic design and the arrangement of its control buttons, including power, directional, and mode selection buttons.

## Remote Control Buttons and Functions:

- **Power Button ( ):** Turns the robot vacuum ON or OFF.
- **Start/Pause Button (▶/ ):** Starts or pauses the cleaning cycle.
- **Directional Arrows (▲, ▼, ◀, ▶):** Manually guides the robot vacuum's movement.
- **Home Button ( ):** Sends the robot vacuum back to its charging base.
- **Spot Cleaning Mode Button (⊙):** Activates intensive cleaning in a specific area.
- **Edge Cleaning Mode Button (⌞):** Directs the robot vacuum to clean along walls and edges.
- **Auto Cleaning Mode Button (A):** Initiates standard automatic cleaning.

## 4. SETUP

### 4.1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA batteries (not included), ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.

### 4.2. Initial Connection (Pairing)

The remote control is typically pre-paired with compatible Rowenta Smart Force Essential robot vacuums. If the remote control does not respond after battery installation, follow these steps to establish a connection:

1. Ensure your robot vacuum is charged and powered ON.
2. Stand within close proximity (1-2 meters) to the robot vacuum.
3. Press and hold the "Home" button ( ) on the remote control for approximately 5 seconds until you hear a confirmation beep from the robot vacuum or see an indicator light flash.
4. Test the remote control by pressing a directional button or the "Start/Pause" button. If the robot responds, the pairing is successful.
5. If pairing fails, replace the batteries in the remote control and repeat the process.

## 5. OPERATING INSTRUCTIONS

Once the remote control is set up, you can use it to control your Rowenta Smart Force robot vacuum.

- **To Start Cleaning:** Press the **Start/Pause (▶)** button. The robot will begin cleaning in its default mode.
- **To Pause Cleaning:** Press the **Start/Pause ( )** button during a cleaning cycle. Press again to resume.
- **To Stop Cleaning:** Press the **Power ( )** button to turn off the robot, or send it back to the charging base using the **Home ( )** button.
- **To Select Cleaning Mode:** Press the respective mode button (e.g., **Spot (⊙)**, **Edge (⌞)**, **Auto (A)**) to switch cleaning patterns.
- **Manual Control:** Use the **Directional Arrows (▲, ▼, ◀, ▶)** to steer the robot vacuum manually for precise cleaning

or navigation.

- **Return to Charging Base:** Press the **Home** ( ) button to send the robot vacuum back to its charging station.

## 6. MAINTENANCE

### 6.1. Cleaning the Remote Control

- Wipe the surface of the remote control with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or internal components.

### 6.2. Battery Replacement

When the remote control's range decreases or it becomes unresponsive, it's time to replace the batteries. Follow the battery installation steps in Section 4.1. Always replace both batteries at the same time with new AAA batteries.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control is unresponsive.	Dead or incorrectly installed batteries.	Check battery polarity or replace batteries with new ones.
Remote control has short range.	Low battery power; Obstruction between remote and robot.	Replace batteries. Ensure a clear line of sight to the robot vacuum.
Robot vacuum does not respond after battery replacement.	Remote control lost connection with the robot.	Attempt to re-pair the remote control with the robot vacuum as described in Section 4.2.
Specific buttons do not work.	Button malfunction or internal damage.	Ensure the remote is clean. If the issue persists, contact Rowenta customer support.

## 8. SPECIFICATIONS

- **Model Number:** RS-RT900911
- **Brand:** Rowenta
- **Color:** Red
- **Connectivity:** Wireless
- **Power Source:** 2 x AAA Batteries (not included)
- **Compatible Robot Vacuum Models:** RR6925, RR6926, RR6927, RR6943, RR6971, RR6976 (Rowenta Smart Force Essential series)

## 9. WARRANTY AND SUPPORT

For information regarding warranty coverage, technical support, or service, please refer to the documentation provided with your Rowenta Smart Force Robot Vacuum or visit the official Rowenta website. Keep your purchase receipt as proof of purchase for warranty claims.

For further assistance, you may contact Rowenta customer service through their official website or the contact information provided in your robot vacuum's main user manual.