

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [DELTA](#) /

› [Delta Faucet 77660-BL Stryke Universal Toilet Tank Lever User Manual](#)

## DELTA 77660-BL

# Delta Faucet 77660-BL Stryke Universal Toilet Tank Lever User Manual

Brand: DELTA | Model: 77660-BL

## 1. INTRODUCTION AND OVERVIEW

This manual provides essential information for the installation, operation, and maintenance of your Delta Faucet 77660-BL Stryke Universal Toilet Tank Lever. The Stryke Bath Collection features a robust design with an assured stature and ascending contours, making this transitional flush lever suitable for various bathroom styles.



Figure 1: Delta Faucet 77660-BL Stryke Universal Toilet Tank Lever, Flat Black.

## 2. PRODUCT FEATURES

- **Matte Black Finish:** Creates a sophisticated aesthetic and coordinates with various fixtures and accents.
- **Durable Construction:** Features a long-lasting finish designed to resist corrosion, tarnish, and discoloration.
- **Zinc Die Cast Material:** Ensures reliability and durability for extended use.
- **Universal Compatibility:** Designed to fit most American right and left mounted toilets.
- **Coordinated Design:** Complements other accessories within the Stryke bath collection.

## 3. PACKAGE CONTENTS

The following items are typically included with your Delta Faucet 77660-BL Stryke Universal Toilet Tank Lever:

- Toilet Tank Lever
- Installation Instructions
- Mounting Hardware

## 4. SETUP AND INSTALLATION

For detailed installation instructions, including step-by-step guides and diagrams, please refer to the official Installation Manual PDF provided by Delta Faucet. This document contains critical information for proper and secure installation.

[Download Official Installation Manual \(PDF\)](#)



Figure 2: Product dimensions of the toilet tank lever (10.06" L x 4.78" W).

#### General Installation Notes:

- Ensure the toilet's water supply is turned off before beginning installation.
- Remove the old tank lever by unscrewing the nut from the inside of the toilet tank.
- Insert the new lever through the hole in the toilet tank and secure it with the provided hardware.
- Attach the lift chain or rod from the flapper to the lever arm, ensuring proper tension for a complete flush and seal.
- Test the flush mechanism and adjust as necessary.

## 5. OPERATING INSTRUCTIONS

The Delta Faucet 77660-BL Stryke Universal Toilet Tank Lever operates by a simple downward press. To flush the toilet:

1. Locate the tank lever on the front or side of your toilet tank.
2. Gently press the lever downwards. This action lifts the flapper inside the tank, allowing water to flow into the bowl and initiate the flush cycle.
3. Release the lever once the flush is complete. The flapper will return to its closed position, and the tank will begin to refill.

Ensure the lever returns to its original position after each flush to prevent continuous water flow and conserve water.

## 6. MAINTENANCE

Proper care and maintenance will help preserve the finish and functionality of your toilet tank lever.

- **Cleaning:** Clean the lever regularly with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the matte black finish.
- **Inspection:** Periodically check the connection of the lift chain/rod to the flapper and the lever arm. Ensure it is securely attached and has appropriate tension.
- **Lubrication:** No lubrication is typically required for the lever mechanism itself.

## 7. TROUBLESHOOTING

---

If you encounter issues with your toilet tank lever, consider the following common troubleshooting steps:

- **Weak Flush:**

- Check the flapper chain: Ensure it is not too loose or too tight. A loose chain may not lift the flapper enough, while a tight chain may prevent it from sealing properly.
- Inspect the flapper: Ensure it is sealing correctly at the bottom of the tank.

- **Lever Not Returning to Original Position:**

- Check for obstructions: Ensure nothing is impeding the lever's movement inside or outside the tank.
- Verify installation: Re-check the mounting hardware to ensure it is not overtightened or misaligned, which could cause friction.

- **Continuous Running Water:**

- Adjust the flapper chain: If the chain is too tight, it might be holding the flapper slightly open.
- Inspect the flapper: A worn or damaged flapper may not create a proper seal.

If problems persist, consult the full installation manual or contact Delta Faucet customer support.

## 8. SPECIFICATIONS

---

Specification	Detail
<b>Brand</b>	DELTA
<b>Model Number</b>	77660-BL
<b>Color</b>	Flat Black
<b>Material</b>	Zinc
<b>Exterior Finish</b>	Matte Black
<b>Product Dimensions</b>	10.06" L x 4.78" W
<b>Item Weight</b>	9.4 Ounces
<b>Included Components</b>	Tank lever, installation instructions, hardware
<b>UPC</b>	034449884228

## 9. WARRANTY INFORMATION

---





Delta Faucet products are manufactured to high standards of quality and performance. For specific warranty details pertaining to your Stryke Universal Toilet Tank Lever, please refer to the documentation included with your product or visit the official Delta Faucet website. Warranty coverage typically includes defects in material and workmanship.

## 10. CUSTOMER SUPPORT

Should you require further assistance, have questions about installation, or need to report a product issue, please contact Delta Faucet customer support. Contact information can typically be found on the official Delta Faucet website or within the product packaging.

**Online Resources:** [www.deltafaucet.com](http://www.deltafaucet.com)

### Related Documents - 77660-BL

	<p><a href="#"><u>Delta Stryke™ Two Handle Wall Mount Lavatory Faucet (T3576LF-WL, T35766LF-WL) - Specifications and Warranty</u></a></p> <p>Detailed specifications, features, warranty information, and compliance standards for the Delta Stryke™ two-handle wall-mount lavatory faucet models T3576LF-WL and T35766LF-WL, including dimensions and rough-in requirements.</p>
	<p><a href="#"><u>Delta 980T-SS-DST Single Lever Pilar Touch Pull Down Kitchen Faucet Installation Manual &amp; Guide</u></a></p> <p>Comprehensive installation guide and troubleshooting manual for the Delta 980T-SS-DST and 980T-SSSD-DST single lever Pilar Touch pull down kitchen faucet. Includes parts list, warranty, and maintenance tips.</p>
	<p><a href="#"><u>Delta Leland Single Lever Pull Down Kitchen Faucet Installation and Warranty Guide</u></a></p> <p>Comprehensive installation instructions, warranty information, and maintenance tips for Delta Leland single lever pull down kitchen faucets (Models 978-DST, 978-SD-DST, 9978-DST).</p>
	<p><a href="#"><u>Delta Single Lever Pilar Touch Pull Down Kitchen Faucet Installation and Maintenance Manual</u></a></p> <p>Detailed installation, maintenance, troubleshooting, and warranty information for the Delta Single Lever Pilar Touch Pull Down Kitchen Faucet (Models 980T-SS-DST &amp; 980T-SSSD-DST). Includes parts list, diagrams, and electronic feature bypass instructions.</p>

 <p>DELTA Compel Collection</p>	<p><a href="#"><u>Delta Compel Collection Bath Accessories: Installation Guide &amp; Lifetime Warranty</u></a></p> <p>Comprehensive installation instructions and lifetime limited warranty details for Delta Faucet's Compel Collection bath accessories. Includes care tips, product information, and model details.</p>
	<p><a href="#"><u>Delta Touch2O Technology Lavatory Faucets - Installation, Warranty, and Maintenance Guide</u></a></p> <p>Comprehensive guide for Delta Touch2O Technology Lavatory Faucets, including installation, cleaning, care, limited warranty, maintenance, and troubleshooting. Covers models like COMPEL, LAHARA, DRYDEN, ADDISON, TESLA, and TALBOTT with Touch2O technology.</p>