

[manuals.plus](#) /› [Gorenje](#) /› [Gorenje HBX 603 RL Immersion Blender User Manual](#)

Gorenje HBX 603 RL

Gorenje HBX 603 RL Immersion Blender User Manual

Model: HBX 603 RL

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, maintenance, and care of your Gorenje HBX 603 RL Immersion Blender. Please read these instructions thoroughly before first use and keep them for future reference.

2. SAFETY INSTRUCTIONS

- Always unplug the appliance from the power supply before assembly, disassembly, or cleaning.
- Keep hands, hair, clothing, and utensils away from moving parts during operation to prevent injury.
- Do not immerse the motor unit in water or any other liquid.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The blades are sharp. Handle with care.

3. PRODUCT OVERVIEW

The Gorenje HBX 603 RL is a powerful immersion blender designed for various kitchen tasks. Familiarize yourself with its components:



Image 1: Gorenje HBX 603 RL Immersion Blender. This image displays the complete immersion blender unit. It features a cream-colored motor housing with two control buttons on the front, a silver-colored attachment point, and a long stainless steel blending shaft ending in a protective bell housing with a four-blade system. The Gorenje logo is visible on the motor housing.

1. **Motor Unit:** Contains the motor and control buttons.
2. **Speed Buttons:** Two buttons for different blending speeds.

3. **Blending Shaft:** Detachable stainless steel shaft with a four-blade system.
4. **Measuring Beaker:** 0.8 L capacity beaker with measurement markings.
5. **Chopper Attachment:** For chopping fruits, vegetables, herbs, and nuts.

4. SETUP AND ASSEMBLY

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for storage or future transport.
2. **Initial Cleaning:** Before first use, wash the blending shaft, measuring beaker, and chopper attachment (if included) in warm soapy water. Rinse thoroughly and dry. Wipe the motor unit with a damp cloth.
3. **Attaching the Blending Shaft:** Align the blending shaft with the motor unit and twist until it locks securely into place. Ensure it is firmly attached before use.
4. **Attaching the Chopper (if applicable):** Place the blade into the chopper bowl, add ingredients, then place the chopper lid on top. Align the motor unit with the chopper lid and twist to lock.

5. OPERATING INSTRUCTIONS

5.1 Blending with the Immersion Blender

1. Ensure the blending shaft is securely attached to the motor unit.
2. Immerse the blending shaft into the ingredients in a suitable container (e.g., the measuring beaker or a pot). Ensure the blades are fully submerged.
3. Plug the appliance into a power outlet.
4. Press and hold one of the speed buttons to start blending.
 - **Speed 1:** For lighter tasks and softer ingredients.
 - **Speed 2 (Pulse Function):** For tougher ingredients or shorter, controlled blending cycles.
5. Move the blender gently up and down and in circles to ensure even blending.
6. Release the button to stop the appliance.
7. Unplug the appliance from the power outlet after use.

5.2 Using the Chopper Attachment (if applicable)

1. Place the chopper blade onto the central pin in the chopper bowl.
2. Add ingredients to the chopper bowl. Do not overfill.
3. Place the chopper lid onto the bowl, ensuring it is properly seated.
4. Attach the motor unit to the chopper lid, twisting to lock it into place.
5. Plug the appliance into a power outlet.
6. Press and hold the desired speed button for short pulses until ingredients reach the desired consistency.
7. Release the button to stop. Unplug the appliance.
8. Carefully remove the motor unit, then the chopper lid, and finally the blade before emptying the contents.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your appliance.

1. **Always unplug the appliance before cleaning.**

- Motor Unit:** Wipe the motor unit with a damp cloth. Never immerse it in water or other liquids.
- Blending Shaft, Beaker, Chopper Bowl, and Blades:** These parts can be washed in warm soapy water. Rinse thoroughly and dry immediately. The blades are sharp; handle with extreme care.
- Dishwasher Safety:** Refer to the product packaging or manufacturer's website for specific dishwasher safety information for detachable parts. Generally, hand washing is recommended for blades to maintain sharpness.
- Storage:** Store the appliance and its accessories in a dry, safe place, out of reach of children.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet faulty; motor unit not properly attached to shaft/chopper.	Check power connection; try a different outlet; ensure motor unit is securely locked.
Blades are not rotating.	Ingredients are too large or too hard; appliance is overloaded; shaft/chopper not properly attached.	Cut ingredients into smaller pieces; reduce quantity; ensure proper assembly.
Unusual noise or smell during operation.	Overheating; foreign object caught in blades; motor malfunction.	Immediately unplug and allow to cool; check for obstructions (unplugged); if problem persists, contact customer support.

If the problem persists after attempting these solutions, please contact Gorenje customer support.

8. SPECIFICATIONS

Model: HBX 603 RL

Power: 600 Watts

Voltage: 230V

Number of Speeds: 2

Material: Plastic, Metal (Stainless Steel Blending Shaft)

Dimensions (L x W x H): 36.5 x 6 x 8 cm

Weight: 1.1 kg

Measuring Beaker Volume: 0.8 L

Chopper Bowl Capacity: 0.5 L

Cable Length: 1.1 m

9. WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please refer to the warranty card included with your purchase or visit the official Gorenje website. Keep your proof of purchase for warranty claims.

Gorenje Official Website: www.gorenje.com

