

Beldray BEL0701TQN

Beldray 10-in-1 Handheld Steam Cleaner User Manual

Model: BEL0701TQN

Brand: Beldray

1. INTRODUCTION

Thank you for purchasing the Beldray 10-in-1 Handheld Steam Cleaner. This versatile and powerful appliance is designed to effectively clean and sanitize various surfaces around your home using only water, providing a chemical-free cleaning solution. With its compact design and range of attachments, it is ideal for tackling grease, grime, and bacteria on multiple surfaces.

Please read this manual thoroughly before first use to ensure safe and optimal operation of your steam cleaner. Keep this manual for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

WARNING: Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Read all instructions before using the appliance.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- Do not leave the appliance unattended while it is switched on.
- Keep out of reach of children and pets. This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities unless supervised.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use the appliance if the power cord or plug is damaged, or if the appliance malfunctions or has been dropped or damaged in any way.
- Always unplug the appliance from the power outlet when not in use and before cleaning.

- Exercise extreme caution when using steam. Steam is very hot and can cause burns. Keep hands and face away from the steam nozzle.
- Do not open the water tank cap while the appliance is under pressure or hot. Allow it to cool down completely before refilling.
- Only fill the water tank with clean tap water. Do not add detergents, perfumes, or other chemicals to the water tank, as this can damage the appliance or create hazardous fumes.
- Ensure the appliance is placed on a stable, heat-resistant surface during use.

3. PACKAGE CONTENTS

Carefully unpack your Beldray 10-in-1 Handheld Steam Cleaner and check that all items are present and in good condition. If any items are missing or damaged, please contact customer support.



Figure 1: Beldray 10-in-1 Handheld Steam Cleaner and its accessories.

Your package should include:

- Beldray Handheld Steam Cleaner Unit
- Measuring Jug
- Funnel
- Flexible Extension Hose
- 3 x Plastic Round Brushes
- Mini Mop Head
- Angled Nozzle
- Window/Surface Cleaning Tool
- Fabric Steamer Tool
- Microfiber Cloth Pad

4. SETUP AND FIRST USE

4.1 Filling the Water Tank

1. Ensure the steam cleaner is unplugged from the power outlet and completely cool.
2. Unscrew the water tank cap (usually located on top of the unit).
3. Using the provided measuring jug and funnel, carefully fill the water tank with up to 250 ml of clean tap water. Do not overfill.
4. Securely replace the water tank cap, ensuring it is tightly sealed to prevent leaks.



Figure 2: Filling the water tank and accessory kit overview.

4.2 Attaching Accessories

Select the appropriate accessory for your cleaning task. Each accessory is designed to click securely into place

on the main nozzle or the flexible extension hose. To remove, press the release button (if present) or twist and pull gently.

5. OPERATING INSTRUCTIONS

5.1 Powering On and Heating Up

1. After filling the water tank and attaching the desired accessory, plug the steam cleaner into a suitable power outlet.
2. The indicator light will illuminate, signifying that the unit is heating up.
3. Allow approximately 2-3 minutes for the water to heat and steam to be ready. The indicator light may turn off or change color when ready, depending on the model.

5.2 Steam Cleaning

1. Once heated, press and hold the steam release button to emit steam.
2. Direct the steam nozzle towards the surface you wish to clean. For best results, hold the nozzle close to the surface.
3. Move the steam cleaner slowly and steadily over the area. For stubborn dirt, hold the steam over the area for a few seconds to loosen grime.
4. Wipe the cleaned surface with a clean cloth immediately after steaming to remove loosened dirt and moisture.



Figure 3: Using the round brush attachment for cleaning stovetops.

5.3 Using Different Attachments

- **Angled Nozzle:** Ideal for hard-to-reach areas, corners, and crevices.
- **Round Brushes:** Excellent for scrubbing stubborn dirt on grout, tiles, ovens, and barbecues.
- **Window/Surface Cleaning Tool:** Use with the microfiber cloth pad for streak-free cleaning of windows, mirrors, and smooth surfaces.
- **Fabric Steamer Tool:** Suitable for refreshing upholstery, curtains, and garments. Always test on an inconspicuous area first.

The 250 ml tank capacity provides approximately 10 minutes of continuous steaming. If the steam output decreases, the water tank may need refilling.

6. MAINTENANCE AND STORAGE

6.1 After Each Use

1. Unplug the steam cleaner from the power outlet.
2. Allow the unit to cool down completely before handling. This may take up to 30 minutes.
3. Once cool, carefully unscrew the water tank cap and empty any remaining water.
4. Wipe the exterior of the unit with a soft, damp cloth.
5. Clean any accessories that were used. Rinse plastic attachments under water. Microfiber pads can be hand washed or machine washed.

6.2 Descaling (Recommended Periodically)

Depending on the hardness of your water, mineral deposits may build up inside the water tank over time. To descale:

- Mix a solution of equal parts white vinegar and water.
- Pour the solution into the water tank (do not exceed max fill line).
- Allow the solution to sit in the tank for 30 minutes to an hour. Do NOT heat the unit with this solution.
- Empty the solution and rinse the tank thoroughly with clean water several times.
- Run a tank of clean water through the unit (by steaming into a sink) to flush out any remaining vinegar residue.

6.3 Storage

Store the steam cleaner and its accessories in a cool, dry place, away from direct sunlight and out of reach of children.

7. TROUBLESHOOTING

If you experience issues with your steam cleaner, please refer to the following table before contacting customer support.

Problem	Possible Cause	Solution
No steam or very little steam	Water tank is empty Unit not heated sufficiently Steam nozzle blocked	Refill water tank Allow 2-3 minutes for heating Clean nozzle with a small brush or pin (ensure unit is off and cool)
Water leaking from nozzle/attachments	Attachments not securely fitted Overfilled water tank Unit not fully heated	Ensure attachments are clicked into place Do not overfill water tank Wait until indicator light shows unit is ready
Steam cleaner not turning on	Not plugged in Power outlet issue Appliance malfunction	Ensure plug is fully inserted Test outlet with another appliance Contact customer support

Problem	Possible Cause	Solution
Steam smells unusual	Chemicals added to water Mineral buildup	Only use clean tap water Perform descaling procedure

8. PRODUCT SPECIFICATIONS

- **Model Name:** Best Germ Killer
- **Model Number:** BEL0701TQN
- **Brand:** Beldray
- **Power:** 1000 W
- **Voltage:** 230V (DC)
- **Tank Volume:** 250 ml
- **Continuous Steam Time:** Approx. 10 minutes
- **Product Dimensions:** 11.42 x 4.92 x 9.25 inches (29L x 12.5W x 23.5H cm)
- **Item Weight:** 4.33 pounds (1.96 kg)
- **Color:** Turquoise
- **Power Source:** Corded Electric
- **Special Feature:** 10-in-1 Handheld Steam Cleaner, Accessories, Long Power Cord, Efficient Steam Control

9. WARRANTY AND SUPPORT

Your Beldray 10-in-1 Handheld Steam Cleaner is covered by a manufacturer's warranty. Please refer to the warranty card included in your original packaging for specific terms and conditions, including the warranty period and coverage details.

For technical support, troubleshooting assistance beyond this manual, or to inquire about replacement parts, please contact Beldray customer service. Contact information can typically be found on the product packaging or the official Beldray website.

Please have your model number (BEL0701TQN) and purchase date ready when contacting support.