

Casio MTP-V004L-1A

Casio MTP-V004L-1A Men's Watch Instruction Manual

Model: MTP-V004L-1A

INTRODUCTION

This manual provides detailed instructions for the proper setup, operation, and maintenance of your Casio MTP-V004L-1A Men's Stainless Steel Leather Band Black Dial Date Watch. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.



Image: Front view of the Casio MTP-V004L-1A watch, showcasing its black dial, silver-tone case, and black leather strap. The date window is visible at the 3 o'clock position.

SETUP

1. Setting the Time

1. **Pull out the crown:** Gently pull the crown (the knob on the side of the watch case) out to the first click position.
2. **Rotate the crown:** Turn the crown in either direction to move the hour and minute hands. Set the time to the current time. Ensure that the AM/PM is correctly set if your watch has a 24-hour indicator or if you are setting the date.
3. **Push in the crown:** Once the correct time is set, push the crown back into its normal position.

2. Setting the Date

1. **Pull out the crown:** Gently pull the crown out to the first click position.
2. **Rotate the crown:** Turn the crown to adjust the date. The date changes by rotating the crown.
3. **Push in the crown:** Once the correct date is set, push the crown back into its normal position.
4. **Note:** Avoid setting the date between 9:00 PM and 1:00 AM, as this may interfere with the automatic date change mechanism. If you need to set the date during this period, first set the time outside this range, adjust the date, and then reset the time.

OPERATING THE WATCH

Your Casio MTP-V004L-1A watch is designed for reliable timekeeping with a simple analog display.

- **Time Display:** The watch features a 3-hand analog display showing hours, minutes, and seconds.
- **Date Function:** The date window at the 3 o'clock position displays the current day of the month.
- **Water Resistance:** This watch is water resistant up to 30 meters (3 ATM). This means it is suitable for everyday use and can withstand splashes or brief immersion in water. It is **not** suitable for swimming, diving, or showering. Avoid operating the crown while the watch is wet.

MAINTENANCE

Cleaning Your Watch

- **Case and Crystal:** Wipe the watch case and mineral crystal with a soft, dry cloth to remove dirt and fingerprints. For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth.
- **Leather Band:** Avoid prolonged exposure of the leather band to water, direct sunlight, and harsh chemicals. If the band gets wet, wipe it dry immediately with a soft cloth and allow it to air dry naturally. Regular cleaning with a specialized leather cleaner can help maintain its condition.

Battery Replacement

The watch is powered by a single battery. When the watch stops or the second hand moves erratically (e.g., skipping seconds), it indicates that the battery needs to be replaced. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance integrity.

Water Resistance Precautions

- Always ensure the crown is fully pushed in before exposing the watch to any moisture.
- Do not operate the crown or push buttons (if any) while the watch is submerged in water or wet.

- Avoid exposing the watch to extreme temperature changes, as this can affect the water resistance seals.

TROUBLESHOOTING

Watch Not Running

- **Check the crown:** Ensure the crown is fully pushed in. If it is pulled out, the watch will not operate.
- **Battery:** The battery may be depleted. Refer to the "Battery Replacement" section under Maintenance.

Date Not Changing Automatically

- **Time Setting:** The watch may be set to the wrong AM/PM cycle. Advance the time by 12 hours to correct this.
- **Manual Adjustment:** If the date is stuck, manually adjust it using the crown as described in the "Setting the Date" section.

Condensation Inside the Watch

If you notice condensation inside the watch crystal, it indicates a potential breach in the water resistance. This should be addressed immediately by a qualified technician to prevent damage to the movement.

SPECIFICATIONS

Feature	Detail
Model Number	MTP-V004L-1A
Movement	Precise Japan Quartz Movement
Accuracy	+/-20 seconds per month
Case Material	Stainless Steel
Band Material	Genuine Leather
Crystal Type	Mineral Crystal
Display Type	3-Hand Analog Display
Functions	Time (Hour, Minute, Second), Date
Case Diameter	41.5 mm
Case Thickness	10 mm
Water Resistance	30 Meters (3 ATM)
Module Number	1333

WARRANTY AND SUPPORT

Your Casio watch is covered by a manufacturer's warranty against defects in materials and workmanship.

The specific terms and duration of the warranty may vary by region. Please refer to the warranty card included with your purchase or visit the official Casio website for detailed warranty information.

For technical support, service, or inquiries regarding your watch, please contact Casio customer service or an authorized service center. You can find contact information and support resources on the official Casio website:

[Visit Casio Support Website](#)

Consider registering your product on the Casio website to receive updates and facilitate warranty claims.

Related Documents

	<p>Casio MTP-1369/1370, MTD-1076 Watch User Manual Module 5336/5337</p> <p>Detailed user manual for Casio MTP-1369/1370 and MTD-1076 watches, covering technical specifications, water resistance, time setting, maintenance, and care instructions for modules 5336 and 5337.</p>
	<p>CASIO MTP-1326/1353 Watch User Manual - Module 5228</p> <p>Comprehensive user guide for the CASIO MTP-1326/1353 watch (Module 5228). Covers essential care, water resistance guidelines, setting time and date, using the rotating bezel, and technical specifications.</p>
	<p>Casio 5154 Operation Guide: Timekeeping, Alarms, and Dual Time</p> <p>Detailed operation guide for the Casio 5154 watch, covering timekeeping, date setting, alarms, dual time, and stopwatch functions. Includes specifications and mode explanations.</p>
	<p>Casio MTP-4700 Module 4754 User Manual</p> <p>Comprehensive user manual for the Casio MTP-4700 wristwatch, module 4754. Learn about water resistance, battery replacement, watch care, setting time and date, world time, calendar, alarm, stopwatch, and countdown timer functions. Includes technical specifications and product information.</p>