Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Holiday Living 88B1598A

Holiday Living 4-Piece Decorative Gift Box Set: Instruction Manual

Model: 88B1598A

Introduction

The Holiday Living 4-Piece Decorative Gift Box Set is designed to enhance your indoor or outdoor holiday decor. This set features four distinct metal boxes, each adorned with a "Merry Christmas" message and a unique holiday phrase: JOY, NOEL, PEACE, and BELIEVE. The boxes are designed for easy assembly, versatile display, and compact storage.

Package Contents

- 1 x Large Decorative Gift Box (13" x 13") - "BELIEVE"
- 1 x Medium-Large Decorative Gift Box (10" x 10") - "PEACE"
- 1 x Medium-Small Decorative Gift Box (8" x 8") - "NOEL"
- 1 x Small Decorative Gift Box (6" x 6") - "JOY"
- Burlap ribbon/bows (pre-attached or included for assembly)




Image: Product packaging displaying the four nested gift boxes and their respective dimensions.

Setup and Assembly

1. **Unpack Components:** Carefully remove all four gift boxes and any associated packaging materials from the shipping carton.
2. **Prepare for Display:** The boxes are designed to nest within each other for compact storage. To set up, gently separate each box.
3. **Arrange Boxes:** Arrange the boxes in your desired configuration. They can be stacked vertically from largest to smallest, or displayed individually. The burlap accents are typically pre-attached or can be positioned as desired to simulate gift bows.



Image: The four decorative gift boxes stacked in descending size, ready for display.

Operating Instructions (Display)

This decorative set is suitable for both indoor and outdoor use. Ensure the chosen display location is stable and will not allow the boxes to be easily knocked over, especially if stacked.

- **Indoor Placement:** Ideal for entryways, under Christmas trees, or as part of a festive centerpiece.
- **Outdoor Placement:** Suitable for porches, patios, or garden areas. While designed for outdoor use, prolonged exposure to extreme weather conditions may affect appearance over time.



Image: The decorative gift boxes arranged in an outdoor holiday scene, demonstrating typical usage.

Maintenance and Care

- **Cleaning:** Wipe the metal surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage

the finish or painted details.

- **Inspection:** Periodically check the boxes for any signs of wear or damage, especially if used outdoors.
- **Weather Protection:** For extended outdoor use, consider placing the boxes in a sheltered area to minimize exposure to heavy rain or snow, which can help preserve their appearance.

Storage

The Holiday Living Gift Box Set is designed for convenient, compact storage.

1. **Disassembly:** If stacked, carefully unstack the boxes.
2. **Nesting:** Place the smallest box ("JOY") inside the next largest box ("NOEL"), then place both inside the "PEACE" box, and finally nest all three inside the largest "BELIEVE" box. This allows the entire set to occupy the space of the largest box.
3. **Storage Location:** Store the nested boxes in a dry, cool place away from direct sunlight to prevent any potential fading or material degradation.

Troubleshooting

This product is a decorative item and typically does not require complex troubleshooting. If you encounter any issues:

- **Stability Issues:** Ensure boxes are placed on a flat, level surface. If stacking, ensure each box is centered on the one below it.
- **Minor Scratches/Dents:** As a decorative item, minor imperfections may occur. These often add to the rustic aesthetic of the metal finish.

Specifications

Brand	Holiday Living
Model Number	88B1598A
ASIN	B07MDHG8VZ
Material	Metal
Color	Silver/Red
Overall Dimensions (Stacked)	21"L x 22"W x 63"H (approx. 53.34 cm L x 55.88 cm W x 160.02 cm H)
Individual Box Dimensions	**BELIEVE:** 13" x 13" (approx. 33.02 cm x 33.02 cm) **PEACE:** 10" x 10" (approx. 25.4 cm x 25.4 cm) **NOEL:** 8" x 8" (approx. 20.32 cm x 20.32 cm) **JOY:** 6" x 6" (approx. 15.24 cm x 15.24 cm)
Item Weight	9.43 pounds (approx. 4.28 kg)
Use	Indoor or Outdoor

Warranty and Support

For information regarding warranty coverage, product support, or replacement parts, please refer to the retailer's return policy or contact Holiday Living customer service directly. Contact details are typically available on the product packaging or the brand's official website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07MDHG8VZ

More documents and user manuals: **https://manuals.plus/**