

[Manuals.plus](#) /

> [Toyota](#) /

> Toyota 2019 Corolla Owner's Manual

Toyota Corolla

2019 Toyota Corolla Owner's Manual

Comprehensive guide for your 2019 Toyota Corolla vehicle.

INTRODUCTION

This owner's manual provides detailed information regarding the operation, maintenance, and safety features of your 2019 Toyota Corolla. Familiarizing yourself with this manual will help ensure safe and optimal performance of your vehicle. Please read it thoroughly and keep it in your vehicle for future reference.




Image Description: The image displays the front cover of the 2019 Toyota Corolla Owner's Manual. The top left features the red Toyota logo. Below it, "COROLLA" is printed in large letters, with "2019" underneath. The right side of the cover shows a blurred night-time city street scene with streaks of red and yellow light from vehicle headlights and taillights, indicating motion. The words "OWNER'S MANUAL" are visible in the lower right quadrant, and a smaller Toyota logo is at the bottom right corner. The manual appears to be shrink-wrapped.

SETUP AND INITIAL FAMILIARIZATION

Upon acquiring your 2019 Toyota Corolla, it is recommended to perform an initial setup and familiarization process. This includes:

- **Adjusting Seating and Mirrors:** Ensure proper driving posture and visibility.
- **Understanding Dashboard Indicators:** Familiarize yourself with warning lights and gauges.
- **Setting Up Infotainment System:** Configure radio, Bluetooth, and navigation (if equipped).
- **Locating Safety Equipment:** Identify the location of airbags, seatbelt adjusters, and child seat anchors.
- **Reviewing Key Fob Functions:** Understand remote locking, unlocking, and trunk release.

Refer to specific sections within this manual for detailed instructions on each component.

OPERATING YOUR VEHICLE

This section covers the fundamental aspects of operating your 2019 Toyota Corolla safely and efficiently.

Starting and Stopping the Engine

- **Key Ignition:** Insert the key and turn to the "START" position. Release once the engine starts.
- **Push Button Start (if equipped):** With the brake pedal pressed, press the ENGINE START/STOP button.
- **Stopping:** Shift to "P" (Park) and turn the key to "LOCK" or press the ENGINE START/STOP button.

Driving Controls

- **Transmission:** Understand the functions of Park (P), Reverse (R), Neutral (N), Drive (D), and Low gears (L or S mode).
- **Braking System:** Information on the foot brake, parking brake, and Anti-lock Braking System (ABS).
- **Steering Wheel Controls:** Operation of audio, cruise control, and multi-information display buttons.

Safety Features

Your Corolla is equipped with various safety systems:

- **Toyota Safety Sense™ P (TSS-P):** Includes Pre-Collision System with Pedestrian Detection, Lane Departure Alert with Steering Assist, Automatic High Beams, and Dynamic Radar Cruise Control.
- **Airbag System:** Location and function of front, side, curtain, and knee airbags.
- **Seatbelts:** Proper use and adjustment for all occupants.

MAINTENANCE SCHEDULE AND PROCEDURES

Regular maintenance is crucial for the longevity and safe operation of your Toyota Corolla. Adhere to the recommended service intervals.

Scheduled Maintenance

Consult the maintenance schedule provided in this manual for specific intervals for:

- Oil and filter changes
- Tire rotation and inspection
- Brake inspection
- Fluid level checks (coolant, brake fluid, power steering fluid, washer fluid)
- Air filter replacement

Owner Performed Maintenance

Some basic checks can be performed by the owner:

- Checking tire pressure
- Inspecting wiper blades
- Checking exterior lights
- Adding washer fluid

Warning: Always refer to the manual for detailed instructions and safety precautions before performing any maintenance. Incorrect procedures can lead to injury or vehicle damage.

TROUBLESHOOTING COMMON ISSUES

This section addresses common operational issues and provides guidance for resolution.

Warning Lights

- **Check Engine Light:** Indicates a potential issue with the engine or emissions system. Consult a qualified technician.
- **Low Tire Pressure Warning:** Check and adjust tire pressure immediately.
- **Battery Warning Light:** May indicate a charging system problem. Seek professional inspection.

Operational Problems

- **Engine Not Starting:** Check battery terminals, fuel level, and ensure the vehicle is in Park or Neutral.
- **Unusual Noises:** Investigate the source of any new or abnormal sounds.
- **Brake Performance Issues:** If brakes feel spongy or less effective, have them inspected immediately.

For complex issues or persistent problems, it is always recommended to contact an authorized Toyota service center.

SPECIFICATIONS

Key specifications for the 2019 Toyota Corolla are outlined below. For a complete list, refer to the detailed specifications section of this manual.

Feature	Detail
---------	--------

Feature	Detail
Model Year	2019
Brand	Toyota
Model	Corolla
Language	English
Print Length	560 pages
Item Weight	1.05 pounds
Publisher	Toyota Motor Company
Publication Date	January 1, 2019

WARRANTY INFORMATION

For detailed information regarding your 2019 Toyota Corolla's warranty coverage, please refer to the separate Warranty and Maintenance Guide provided with your vehicle. This guide outlines the terms, conditions, and duration of various warranties, including:

- New Vehicle Limited Warranty
- Powertrain Warranty
- Corrosion Perforation Warranty
- Emissions Warranty

It is important to understand your warranty coverage and maintain proper service records to ensure eligibility for warranty claims.

CUSTOMER SUPPORT

Should you require further assistance or have questions not covered in this manual, please utilize the following resources:

- **Authorized Toyota Dealership:** Your local dealership is equipped to provide expert service and answer specific questions about your vehicle.
- **Toyota Customer Experience Center:** Contact information can typically be found on the official Toyota website or in your vehicle's documentation.
- **Official Toyota Website:** www.toyota.com (for general information, service schedules, and dealer locator).

When contacting support, please have your Vehicle Identification Number (VIN) readily available.

© 2019 Toyota Motor Corporation. All rights reserved.

This manual is intended for informational purposes only and does not supersede any local laws or regulations.