Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SHW OD-41L-E

SHW L-Shaped Office Computer Corner Table, Espresso (Model: OD-41L-E) Instruction Manual

Introduction

This manual provides instructions for the assembly, operation, and maintenance of the SHW L-Shaped Office Computer Corner Table, Model OD-41L-E. This desk is designed to optimize space for various uses, including office work and gaming setups.

Setup

The SHW L-Shaped Office Computer Corner Table requires assembly. Step-by-step instructions and all necessary hardware are included. It is recommended that two people assemble the desk for ease and safety. The assembly process is designed to be straightforward, with clearly labeled parts.



Image showing the dimensions of the SHW L-Shaped Office Computer Corner Table: 51 inches (129.5 cm) wide on each side, 19 inches (48.3 cm) deep, and 28.5 inches (72.4 cm) high. The overall depth from the corner to the front edge is 44 inches (111.8 cm).



Image of the assembled SHW L-Shaped Office Computer Corner Table in an office setting, demonstrating its L-shape and space-saving design. A laptop and office chair are shown with the desk.

Operating

The SHW L-Shaped Office Computer Corner Table is designed for versatile use in home offices, dorm rooms, or gaming setups. Its L-shape provides ample surface area for multiple monitors, peripherals, and work materials. For user comfort, the desk includes a footrest bar. Adjustable glides are integrated into the desk legs to ensure stability on uneven floor surfaces.



Image showing the SHW L-Shaped Office Computer Corner Table from a front-side angle, with a laptop, lamp, and plant on its surface, illustrating typical use.



Close-up image of an adjustable glide on the desk leg, used for leveling the desk on uneven floors.

Maintenance

To maintain the SHW L-Shaped Office Computer Corner Table, follow these guidelines:

- For surfaces made of engineered wood, wipe with a damp cloth.
- Regularly dust metal and wooden parts to keep them clean.
- Avoid using harsh chemicals or abrasive cleaners that may damage the finish.

Troubleshooting

This section addresses common concerns and safety information for the SHW L-Shaped Office Computer Corner Table.

- **Stability Issues:** If the desk wobbles, adjust the integrated glides on the bottom of the legs to stabilize the desk on uneven floors.
- **Tipping Prevention:** Ensure the desk is properly positioned and stable to prevent accidental tipping.
- **Weight Limit:** Do not exceed the recommended weight limit for the desk to ensure structural integrity and safety. Overloading the desk can lead to damage or instability.

Specifications

The following are the technical specifications for the SHW L-Shaped Office Computer Corner Table, Model OD-41L-E.

Feature	Detail
Brand	SHW
Model Number	OD-41L-E
Shape	L-Shape
Desk Design	Computer Desk
Product Dimensions (D x W x H)	129.5D x 129.5W x 72.4H Centimetres (51" W x 19" D x 28.5" H)
Colour	Espresso
Style	Modern
Base Material	Metal (Alloy Steel)
Top Material Type	Engineered Wood
Finish Type	Powder Coated
Special Features	Adjustable Glides, Footrest
Item Weight	16 Kilograms
Assembly Required	Yes
Recommended People for Assembly	2
Product Care Instructions	Wipe with Damp Cloth for Surfaces, Dust Metal and Wooden Parts Regularly

Warranty

The SHW L-Shaped Office Computer Corner Table comes with a**1-year warranty** against manufacturer defects. This warranty is provided by the exclusive seller, EP Family Direct.

Support

For product support or inquiries, please contact the manufacturer:

SHW
Santa Fe Springs, CA 90670, US

Additional information and products can be found at the official SHW Store:SHW Store on Amazon.ca

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07MFC32XC

More documents and user manuals: **https://manuals.plus/**