

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [IKEA](#) /
- › [IKEA VATTENTÄT Whistling Kettle User Manual](#)

IKEA 202.395.95

IKEA VATTENTÄT Whistling Kettle User Manual

Model: 202.395.95

PRODUCT OVERVIEW

The IKEA VATTENTÄT Whistling Kettle is designed for efficient water boiling on various stovetops. It features a whistling function to indicate when water has reached boiling point and is constructed from durable, easy-to-clean stainless steel.



Image: Front view of the IKEA VATTENTÄT Whistling Kettle, showcasing its stainless steel body and black handle.

SETUP

1. **Unpack:** Carefully remove the kettle and all packaging materials from the box.
2. **Initial Cleaning:** Before first use, wash the inside of the kettle with warm water and a mild detergent. Rinse thoroughly with clean water.
3. **First Boil:** Fill the kettle with fresh water to the maximum fill line. Bring the water to a boil, then discard it. Repeat this process 2-3 times to ensure cleanliness and remove any manufacturing residues.
4. **Placement:** Place the kettle on a stable, flat surface on your stovetop. Ensure the handle is positioned away from direct heat sources.

OPERATING INSTRUCTIONS

1. **Filling the Kettle:** Open the lid and fill the kettle with fresh water. Do not fill above the maximum fill line indicated inside the kettle to prevent overflow during boiling.



Image: A hand is shown adding tea leaves into the kettle, demonstrating the wide opening for filling.

2. **Placing on Stovetop:** Place the kettle on a suitable heat source (gas, induction, glass ceramic, or electric hob). Ensure the kettle is centered on the burner.
3. **Heating:** Turn on the heat. The kettle will emit a whistling sound when the water has reached boiling point.



Image: A close-up view of the kettle's spout, highlighting the integrated whistling mechanism.

4. **Pouring:** Carefully remove the kettle from the heat source. Use oven mitts or a cloth as the kettle body and handle may be hot. To pour, lift the spout cap.



Image: A person is shown pouring hot water from the kettle into a white mug, demonstrating the pouring action.

5. **Safety Note:** Always handle the hot kettle with care. Keep out of reach of children.

MAINTENANCE

- **Daily Cleaning:** After each use, rinse the inside of the kettle with warm water. Wipe the exterior with a damp cloth. Dry thoroughly to prevent water spots.
- **Deep Cleaning:** For stubborn stains or mineral deposits, use a mixture of water and white vinegar (1:1 ratio). Fill the kettle with the mixture, bring to a boil, and let it sit for 15-30 minutes before discarding. Rinse thoroughly multiple times.
- **Descaling:** Regular descaling is recommended, especially in hard water areas, to maintain efficiency and prolong the kettle's lifespan. Use a commercial descaling solution suitable for stainless steel kettles, following the product's instructions.
- **Storage:** Store the kettle in a dry place when not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Kettle not whistling.	Spout cap not fully closed or damaged. Insufficient water level.	Ensure the spout cap is securely closed. Check water level; ensure it's above the minimum but below the maximum.
Water takes too long to boil.	Kettle needs descaling. Incorrect hob size/heat setting.	Descal the kettle as per maintenance instructions. Ensure the hob size matches the kettle's base and use an appropriate heat setting.
Water tastes metallic or unusual.	New kettle residue. Mineral deposits.	Perform initial cleaning and boil-and-discard steps again. Descal the kettle.

SPECIFICATIONS

Brand	IKEA
Model Number	202.395.95
Color	Stainless Steel, Black
Dimensions (Packaging)	22.9 x 22.3 x 18.9 cm
Capacity	1.3 Liters
Material	Stainless Steel, Melamine
Item Weight	649 g
Compatible Hobs	Gas, Induction, Glass Ceramic, Electric

WARRANTY AND SUPPORT

Specific warranty information for the IKEA VATTENTÄT Whistling Kettle (Model 202.395.95) is not provided in this manual.

For detailed warranty terms, product support, or to inquire about replacement parts, please refer to the official IKEA website or contact IKEA customer service directly.

You can find more information at: www.ikea.com