



[Manuals.plus](#) /

› [Casaria](#) /

› Casaria Set of 3 Poly Rattan Planters - Instruction Manual

**Casaria 106644**

# Casaria Set of 3 Poly Rattan Planters - Instruction Manual

Model: 106644

## INTRODUCTION

---

Thank you for choosing the Casaria Set of 3 Poly Rattan Planters. This manual provides essential information for the proper assembly, use, and care of your new planters. Please read these instructions carefully before use and retain them for future reference.

These versatile planters are designed for both indoor and outdoor use, offering a stylish solution for your plants. They are constructed from high-quality, weather-resistant poly rattan, ensuring durability and longevity.



Image: The Casaria Set of 3 Poly Rattan Planters, showcasing their elegant design and suitability for outdoor environments.

## SETUP

---

Your Casaria planter set includes three different sized poly rattan frames and three corresponding inner pots. Follow these steps for initial setup:

- 1. Unpack Components:** Carefully remove all parts from the packaging. Ensure you have three poly rattan outer frames and three black inner pots.
- 2. Insert Inner Pots:** Place each black inner pot into its corresponding poly rattan outer frame. The inner pots are designed to fit snugly within the frames.
- 3. Drainage Hole Preparation:** Each inner pot features a closable drainage hole at the bottom.
  - For *outdoor use*, it is recommended to open the drainage hole to prevent waterlogging. Remove the rubber stopper from the bottom of the inner pot.
  - For *indoor use*, keep the drainage hole closed to prevent water leakage. Ensure the rubber stopper is securely in place.

4. **Add Stability (Optional for Outdoor Use):** For enhanced stability, especially in windy conditions, you may fill the bottom of the poly rattan outer frames with stones or gravel before inserting the inner pots. This adds weight to the planters.
5. **Planting:** Fill the inner pots with appropriate potting soil and plant your desired flowers or greenery.



Image: The removable inner pot, demonstrating how it fits within the poly rattan outer frame.



Image: The three black plastic inner pots, ready for planting.



Image: Detail of the drainage hole and its removable stopper for water management.

## OPERATING INSTRUCTIONS

---

These planters are designed for straightforward use. Once set up, their operation primarily involves plant care.

- **Watering:** Water your plants as needed. If the drainage hole is open (for outdoor use), excess water will drain out. If closed (for indoor use), monitor water levels to prevent overwatering and root rot.
- **Placement:** Position the planters in your desired location. Their lightweight construction allows for easy repositioning. Consider sunlight requirements for your plants when choosing a location.
- **Versatility:** The set includes three planters of varying sizes (80x30x30 cm, 61x25x25 cm, 41x21x21 cm) with inner pot capacities of 15 L, 8 L, and 5 L respectively. Arrange them individually or as a group to create decorative accents or room dividers.



Image: The set of three planters, illustrating their different sizes and potential for arrangement.




Image: Dimensional overview of the three planters, providing exact measurements.

## MAINTENANCE

To ensure the longevity and appearance of your Casaria planters, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the poly rattan frames and inner pots with a damp cloth. For stubborn dirt, a mild soap solution can be used. Rinse thoroughly and dry. Avoid abrasive cleaners or harsh chemicals, as these can damage the material.
- **Weather Resistance:** The planters are weather-resistant and designed for outdoor use. However, during extreme weather conditions (e.g., heavy snow, prolonged freezing temperatures), consider moving them to a sheltered area to extend their lifespan.
- **Inspection:** Periodically inspect the planters for any signs of wear or damage. Although made from durable plastic, prompt attention to any issues can prevent further deterioration.

## TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
<b>Waterlogging in inner pot (indoor use)</b>	Drainage hole is closed, or overwatering.	Ensure the drainage hole stopper is securely in place for indoor use. Reduce watering frequency. Consider adding a layer of gravel at the bottom of the inner pot before soil for better drainage.
<b>Planter instability (outdoor use)</b>	Insufficient weight, especially in windy conditions.	Fill the bottom of the poly rattan outer frames with stones or gravel before inserting the inner pots to add weight and stability.
<b>Dirt accumulation on rattan</b>	Exposure to outdoor elements.	Clean with a damp cloth and mild soap solution. Rinse thoroughly.

## SPECIFICATIONS

<b>Brand</b>	Casaria
<b>Model Number</b>	106644
<b>Material</b>	Poly Rattan (outer frame), Plastic (inner pots)
<b>Color</b>	Black
<b>Dimensions (L x W x H)</b>	Large: 30 x 30 x 80 cm Medium: 25 x 25 x 61 cm Small: 21 x 21 x 41 cm
<b>Inner Pot Capacity</b>	Large: 15 Liters Medium: 8 Liters Small: 5 Liters
<b>Total Weight</b>	7.05 Kilograms (for the set)
<b>Special Features</b>	Weather-resistant, UV-resistant, Removable inner pots, Closable drainage holes, Lightweight
<b>Usage</b>	Indoor / Outdoor

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to your purchase documentation or contact Casaria customer service directly. Contact details can typically be found on the retailer's website or on the product packaging. Please have your model number (**106644**) and proof of purchase ready when contacting support.