

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [HORI](#) /

› [HORI PlayStation 4 TAC Pro Type M2 Programmable KeyPad and Mouse Controller User Manual](#)

HORI PS4-119U

HORI PlayStation 4 TAC Pro Type M2 Programmable KeyPad and Mouse Controller

USER MANUAL

Introduction

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your HORI PlayStation 4 TAC Pro Type M2 Programmable KeyPad and Mouse Controller. Designed for First-Person Shooter (FPS) games, this device offers PC-style control on PlayStation 4, PlayStation 3, and PC platforms. Please read this manual thoroughly before use to ensure proper functionality and to maximize your gaming experience.

Safety Information

- Do not expose the device to extreme temperatures, humidity, or direct sunlight.
- Avoid dropping or subjecting the device to strong impacts.
- Keep the device away from liquids and moisture.
- Do not attempt to disassemble or modify the device. This will void the warranty.
- Use only the provided cables and accessories.

Package Contents

Verify that all items are present in the package:

- HORI TAC Pro Type M2 KeyPad
- HORI Gaming Mouse
- USB Connection Cable
- Instruction Manual (this document)



Image: The HORI TAC Pro Type M2 product box, showing the keypad and mouse inside.

Product Overview

The HORI TAC Pro Type M2 consists of a programmable keypad and a high-performance gaming mouse, designed to provide precise control for FPS games.



Image: The Hori TAC Pro Type M2 KeyPad and Mouse, connected via cable. The keypad features red LED-backlit mechanical keys and an adjustable palm rest. The mouse is black with red accents.

KeyPad Features:

- **Mechanical Key Switches:** Durable and responsive keys with LED backlighting.
- **Adjustable Palm Rest:** Ergonomically designed for comfort during extended use.
- **Analog Thumb Stick:** Provides movement control, configurable as WASD keys.
- **Touch Pad:** Fully-featured touch pad for additional input.
- **Headset Input:** For connecting a gaming headset.
- **Special Buttons:** Includes Snipe, Quick, ADS Lock, and Walk buttons for enhanced gameplay.



Image: A detailed view of the Hori TAC Pro Type M2 KeyPad, highlighting the red LED-backlit mechanical keys, the analog thumb stick, and the integrated touch pad. The adjustable palm rest is also visible.

Mouse Features:

- **High-End Gaming Mouse:** Designed for precision and responsiveness.
- **Adjustable DPI:** Allows for on-the-fly sensitivity adjustments.

- **Ergonomic Design:** Comfortable grip for various hand sizes.



Image: A top-down view of the HORI Gaming Mouse, showcasing its ergonomic shape, scroll wheel, and two programmable buttons on the side. The TAC logo is visible at the base.

Setup

1. Connect the Device:

Connect the USB cable from the HORI TAC Pro Type M2 KeyPad to an available USB port on your PlayStation 4, PlayStation 3, or PC. Ensure the mouse is connected to the keypad's dedicated mouse port.

2. Select Platform Mode:

Locate the platform switch on the underside of the keypad. Set it to the appropriate position for PS4, PS3, or PC.

3. Install HORI Device Manager App:

For advanced customization and profile management, download the "HORI Device Manager App" from the App Store (iOS) or Google Play Store (Android) on your mobile device.

4. Pair with App (Bluetooth):

Once the app is installed, enable Bluetooth on your mobile device. Follow the in-app instructions to pair your HORI TAC Pro Type M2 with the app. This allows for wireless adjustment of settings.



Image: The Hori TAC Pro Type M2 KeyPad and Mouse are shown connected, with a smartphone displaying the Hori Device Manager App interface. This illustrates the wireless connectivity for configuration.

5. Initial Configuration:

Upon first connection, it is recommended to use the Hori Device Manager App to set up your preferred key layouts, mouse sensitivity (DPI), and dead zone settings. You can save multiple profiles for different games.

Operating Instructions

KeyPad Functions:

- **Standard Input:** The mechanical keys emulate standard controller buttons (e.g., X, O, Square, Triangle, L1, R1, L2, R2) and directional input.
- **Analog Thumb Stick:** Functions as the left analog stick of a standard controller. It can be configured via the app to act as WASD keys for movement.
- **Snipe Button:** Reduces mouse sensitivity instantly for precise aiming. Press and hold for activation.
- **Quick Button:** Increases mouse sensitivity temporarily for rapid turns or quick movements. Press and hold for activation.
- **ADS Lock:** Locks the Aim Down Sights (ADS) function, allowing you to maintain ADS without holding the button.
- **Walk Button:** Reduces movement speed for stealth or precise positioning.
- **Touch Pad:** Functions as the PlayStation controller's touch pad.
- **Headset Jack:** Connect your compatible gaming headset for audio and microphone functionality.

Mouse Functions:

- **Right Analog Stick Emulation:** The mouse emulates the right analog stick of a standard controller, providing precise aiming control.
- **DPI Adjustment:** Use the dedicated DPI buttons on the mouse (if present) or the Hori Device Manager App to adjust mouse sensitivity on the fly. Higher DPI means faster cursor movement.

Using the Hori Device Manager App:

The app provides extensive customization options:

- **Key Re-mapping:** Assign any controller button function to any key on the keypad.
- **Sensitivity Settings:** Fine-tune mouse sensitivity, acceleration, and dead zone settings.
- **Profile Management:** Create and save multiple profiles for different games or play styles. Switch between profiles quickly using the app or dedicated buttons on the keypad.
- **Firmware Updates:** The app facilitates firmware updates for the TAC Pro Type M2, ensuring optimal performance and compatibility.

Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe down the keypad and mouse. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the device. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, store the device in a clean, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or twisting the USB cable excessively to prevent damage.

Troubleshooting

• Device Not Recognized:

Ensure the USB cable is securely connected to both the keypad and the console/PC. Verify that the platform switch on the keypad is set to the correct position (PS4, PS3, or PC). Try a different USB port.

• Mouse Movement Feels Off/Laggy:

The TAC Pro Type M2 emulates a controller's analog stick, which can feel different from native PC mouse input. Adjust mouse sensitivity (DPI) using the buttons on the mouse or the Hori Device Manager App. Also, check in-game sensitivity settings; often, turning in-game sensitivity to maximum and then fine-tuning with the TAC Pro's settings yields better results. Ensure "uniform aiming" and "controller acceleration" settings in-game are adjusted or

turned off as per preference.

- **Headset Audio/Mic Not Working:**

Ensure your headset is fully plugged into the keypad's headset jack. Check console/PC audio settings to ensure the TAC Pro Type M2 is selected as the input/output device. Test with another headset if possible.

- **Keys Not Responding:**

Check if the keypad is properly connected and powered on. If using custom profiles, ensure the correct profile is active. Try resetting the device to default settings via the HORI Device Manager App.

- **App Connectivity Issues:**

Ensure Bluetooth is enabled on your mobile device and the keypad. Restart both the app and the keypad. If issues persist, try re-pairing the device through the app.

Specifications

Model Number	PS4-119U
Compatibility	PlayStation 4, PlayStation 3, PC
Connectivity	Wired USB (device to console/PC), Bluetooth (device to mobile app)
Keypad Features	Mechanical key switches, LED backlighting, adjustable palm rest, analog thumb stick, touch pad, headset input
Mouse Features	High-end gaming mouse, adjustable DPI
Dimensions (Package)	12 x 7.5 x 3.56 inches
Weight (Item)	1.91 pounds
Manufacturer	HORI
Release Date	March 11, 2019

Warranty Information

Please refer to the manufacturer's official website or the product packaging for detailed warranty information regarding your HORI TAC Pro Type M2. Warranty terms and conditions may vary by region and retailer.

Support

For further assistance, frequently asked questions, or to download the latest firmware and app updates, please visit the official HORI support website:

[HORI Official Website](#)