

Steam and Go 857267008238

Steam & Go All-in-One Garment Steamer and Iron User Manual

Model: 857267008238

[Overview](#) [Safety](#) [Contents](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#)
[Specifications](#) [Support](#)

1. PRODUCT OVERVIEW

The Steam & Go All-in-One Garment Steamer and Iron is designed to provide efficient wrinkle removal and fabric care. This versatile appliance combines the functions of a garment steamer and a traditional iron, featuring an integrated ironing board and clothing hanger for convenience.

Key features include:

- **Integrated Ironing Board:** A built-in board for both steaming and ironing tasks.
- **Clothing Hanger:** Includes garment clips for easy steaming of hanging items.
- **Powerful Steam Output:** 1500W of power for effective wrinkle and crease removal.
- **Cool Touch Hose:** Patented design to protect users from scalding.
- **Adjustable Steam Intensity:** Thermostat control for varying steam levels.
- **High-Capacity Water Tank:** A 1-liter tank provides approximately 30 minutes of continuous steam.
- **Compact and Portable:** Telescopic aluminum bars fold for easy storage.



Figure 1.1: The Steam & Go All-in-One Garment Steamer and Iron with its main components.

2. IMPORTANT SAFETY INSTRUCTIONS

Before using your Steam & Go Garment Steamer and Iron, please read and understand all safety instructions to prevent injury or damage.

- Always ensure the appliance is unplugged before filling with water, cleaning, or performing maintenance.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Use only distilled or demineralized water in the tank to prevent mineral buildup and extend product life.
- Keep the steam hose and iron head away from your body, other people, and pets during operation. Steam is hot and can cause burns.
- The patented "cool touch" hose is designed to reduce heat transfer, but caution should still be exercised.
- Do not leave the appliance unattended while it is plugged in or operating.
- Place the appliance on a stable, level surface during use.
- Do not operate the appliance with a damaged cord or plug, or if it has been dropped or damaged. Contact customer support for assistance.

- This appliance is for household use only. Do not use outdoors.
- Keep out of reach of children.

3. PACKAGE CONTENTS

Verify that all components are present in the package before assembly.



Figure 3.1: Exploded view of all components included with the Steam & Go All-in-One Garment Steamer and Iron.

1. Base Unit
2. Pressurized Steam Iron
3. Adjustable Telescopic Poles (2)
4. Ironing Board
5. Hanger Mount
6. Clothing Hanger
7. Mounting Board
8. Mounting Screws
9. Funnel

10. Measuring Cup
11. Iron Holder
12. Nylon Brush Attachment

4. ASSEMBLY AND SETUP

Follow these steps to assemble your Steam & Go Garment Steamer and Iron:

1. **Attach Telescopic Poles:** Insert the two adjustable telescopic poles into the designated slots on the base unit. Ensure they are securely locked in place.
2. **Install Hanger Mount:** Slide the hanger mount onto the top of the telescopic poles.
3. **Attach Clothing Hanger:** Secure the clothing hanger to the hanger mount.
4. **Mount Ironing Board:** Attach the ironing board to the telescopic poles using the provided mounting board and screws. Ensure it is stable and level.
5. **Place Iron Holder:** Position the iron holder on the side of the unit for convenient storage of the steam iron.
6. **Connect Steam Iron:** Connect the steam iron hose to the steam outlet on the base unit. Ensure a tight connection.

5. OPERATING YOUR GARMENT STEAMER AND IRON

5.1 Filling the Water Tank

1. Ensure the appliance is unplugged and cool.
2. Remove the water tank cap from the base unit.
3. Using the provided measuring cup and funnel, carefully fill the 1-liter water tank with distilled or demineralized water. Do not overfill.
4. Securely replace the water tank cap.



Say goodbye to frequent refills & hello to efficiency. Enjoy longer steaming sessions to tackle all your garments with ease.

High Capacity Tank System

- 
Thermostat Control
- 
1 Liter Tank Capacity
- 
30mins Continuous Use

Figure 5.1: The steamer's base, showing the water tank and controls.

5.2 Steaming Garments

1. Hang the garment on the clothing hanger or place it on the ironing board.
2. Plug the appliance into a suitable power outlet.
3. Press the ON/OFF foot pedal to power on the unit. The indicator light will illuminate.
4. Allow the unit to heat up until steam is consistently produced (approximately 45 seconds).
5. Adjust the thermostat control on the iron handle to your desired steam intensity.
6. Hold the steam iron head a few inches from the fabric and move it in a downward motion. For stubborn wrinkles, gently press the iron head against the fabric.
7. Use the nylon brush attachment for thicker fabrics or to remove lint.

All-in-One Steamer & Iron

Effortless refresh your wardrobe and
revitalize your garments with the
ultimate convenience of
Steam & Go.



Figure 5.2: Demonstrating the use of the garment steamer on a hanging shirt.



Powerful Steam Iron

Designed with powerful parallel steam technology, our steam iron easily smooths out stubborn wrinkles and creases, leaving your clothes fresh, crisp, and ready to wear in no time.

Figure 5.3: A close-up view of the steam iron head in operation, showing steam output.

5.3 Ironing Garments

1. Place the garment flat on the integrated ironing board.
2. Ensure the unit is powered on and heated.
3. Use the steam iron as you would a traditional iron, pressing it against the fabric on the ironing board.
4. Adjust steam intensity as needed using the thermostat control.

The Ultimate Garment Care Solution



Figure 5.4: Illustrating the use of the iron on a garment placed on the integrated ironing board.

5.4 Fabric Compatibility

The Steam & Go All-in-One Garment Steamer and Iron is suitable for a wide range of fabrics and household items, including:


- Drapes
- Sheets
- Clothing (various types)
- Furniture upholstery

Works Well with a Variety of Fabrics

Simplify your laundry routine with Steam & Go, tackling all garments with ease!



Drapes



Sheets



Clothing



Furniture



Figure 5.5: The versatility of the steamer for different fabrics and household items.

6. CARE AND MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your appliance.

- **Empty Water Tank:** After each use, unplug the unit and allow it to cool completely. Empty any remaining water from the tank.
- **Cleaning:** Wipe the exterior of the unit and the steam iron head with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Descaling:** If you notice reduced steam output or mineral residue, descale the unit. Consult the manufacturer's website or customer support for specific descaling instructions. Generally, this involves running a solution of white vinegar and water through the system.
- **Storage:** The telescopic poles can be folded for compact storage. Ensure the unit is cool and dry before storing. Store in a cool, dry place away from direct sunlight.

7. TROUBLESHOOTING GUIDE

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
No steam or low steam output	Water tank empty; unit not heated sufficiently; mineral buildup.	Refill water tank; allow adequate heating time (approx. 45 seconds); descale the unit.
Water leaking or spilling from iron head	Overfilled water tank; unit not fully heated; condensation in hose.	Do not overfill the water tank; allow unit to fully heat before use; hold iron head upright to allow condensation to drain back into the tank.
Unit does not turn on	Not plugged in; power outlet malfunction; ON/OFF foot pedal not pressed.	Ensure power cord is securely plugged in; test outlet with another appliance; press the foot pedal firmly.
Ironing board feels unstable	Mounting screws loose; poles not fully extended/locked.	Tighten all mounting screws; ensure telescopic poles are fully extended and locked into position.

8. PRODUCT SPECIFICATIONS

- **Brand:** Steam and Go
- **Model Number:** 857267008238
- **Color:** Black/Grey
- **Product Dimensions:** 63"L x 63"H (assembled)
- **Item Weight:** 18 Pounds
- **Wattage:** 1500 watts
- **Voltage:** 230 Volts (AC)
- **Water Tank Capacity:** 1 Liter
- **UPC:** 857267008238
- **First Available Date:** February 10, 2019

9. WARRANTY AND CUSTOMER SUPPORT

For warranty information, product registration, or technical assistance, please contact Steam and Go customer support. Keep your purchase receipt as proof of purchase.

You can visit the official Steam and Go store for more information and support resources: [Steam and Go Store](#)