



[Manuals.plus](#) /

> [DACOM](#) /

> DACOM GF7 TWS V4.2 Bluetooth Earbuds User Manual

DACOM GF7 TWS V4.2

DACOM GF7 TWS V4.2 Bluetooth Earbuds User Manual

Model: GF7 TWS V4.2

[Introduction](#)

[Package Contents](#)

[Product Overview](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Safety](#)

[Warranty & Support](#)

1. INTRODUCTION

Thank you for purchasing the DACOM GF7 TWS V4.2 Bluetooth Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before using the product and retain it for future reference.



Image 1.1: DACOM GF7 TWS V4.2 Bluetooth Earbuds in their charging case.

2. PACKAGE CONTENTS

Please check the package contents upon unboxing. If any items are missing or damaged, contact your retailer.

- DACOM GF7 TWS V4.2 Bluetooth Earbuds (Left and Right)
- Portable Charging Case
- USB Charging Cable
- Ear Cushions (various sizes)
- User Manual (this document)

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your DACOM GF7 TWS V4.2 Earbuds and charging case.



Image 3.1: Detailed diagram showing the Multifunction Button (MFB), Indicator Light, Microphone (Mic), Air Gate, DC5V Charge Jack Cover, Headphone Charging Indicator Light, USB Charging Input Port, and the Charging Indicator Light of the bottom on the DACOM GF7 TWS V4.2 Earbuds and Charging Case.

- **Multifunction Button (MFB):** Used for power, playback, call management, and voice assistant activation.
- **Indicator Light:** Displays pairing status, charging status, and power status.
- **Mic:** Built-in microphone for calls and voice commands.
- **Air Gate:** Acoustic vent for sound performance.
- **DC5V Charge Jack Cover:** Protects the charging port on the earbuds.
- **Headphone Charging Indicator Light:** Shows charging status of individual earbuds within the case.
- **USB Charging Input Port:** For charging the portable charging case.
- **Charging Indicator Light of the bottom:** Shows charging status of the case.

4. SETUP

4.1. Charging the Earbuds and Charging Case

1. **Charging the Case:** Connect the USB charging cable to the USB Charging Input Port on the charging case and the other end to a 5V USB power adapter (not included). The Charging Indicator Light at the bottom of the case will illuminate to indicate charging. Once fully charged, the indicator light may change color or turn off.
2. **Charging the Earbuds:** Place the earbuds into their respective slots in the charging case. Ensure the earbuds are properly seated. The Headphone Charging Indicator Light on the case will show the charging status of the earbuds. The earbuds' indicator lights will also show charging status (e.g., red while charging, off when fully charged).

3. For first-time use, fully charge both the earbuds and the charging case.

4.2. Bluetooth Pairing

1. **Power On:** Take both earbuds out of the charging case. They will automatically power on and attempt to pair with each other. You will hear an audible prompt indicating they are connected to each other.
2. **Pairing Mode:** Once the earbuds are paired with each other, one earbud's indicator light will flash red and blue alternately, indicating it is in pairing mode and ready to connect to your device.
3. **Connect to Device:** On your smartphone or Bluetooth-enabled device, go to the Bluetooth settings and search for available devices. Select "DACOM GF7 TWS" (or similar name) from the list.
4. **Successful Connection:** Once connected, the earbud's indicator light will stop flashing, and you will hear a confirmation sound.
5. **Automatic Reconnection:** After initial pairing, the earbuds will automatically connect to the last paired device when taken out of the charging case, provided Bluetooth is enabled on your device.

5. OPERATING INSTRUCTIONS

The DACOM GF7 TWS V4.2 Earbuds feature a Multifunction Button (MFB) for various controls.

5.1. Power On/Off

- **Power On:** Take the earbuds out of the charging case. They will power on automatically. Alternatively, press and hold the MFB on both earbuds for approximately 3 seconds until you hear a power-on prompt.
- **Power Off:** Place the earbuds back into the charging case. They will power off automatically. Alternatively, press and hold the MFB on both earbuds for approximately 5 seconds until you hear a power-off prompt.

5.2. Music Playback

- **Play/Pause:** Single press the MFB on either earbud.
- **Next Track:** Double press the MFB on the right earbud.
- **Previous Track:** Double press the MFB on the left earbud.

5.3. Call Management

- **Answer/End Call:** Single press the MFB on either earbud.
- **Reject Call:** Press and hold the MFB on either earbud for approximately 2 seconds.

5.4. Voice Assistant

- **Activate Voice Assistant:** Triple press the MFB on either earbud to activate your device's voice assistant (e.g., Siri, Google Assistant).

5.5. Noise Cancellation

- The DACOM GF7 TWS V4.2 features active noise cancellation. Specific activation methods may vary. Refer to the product's quick start guide or manufacturer's website for precise instructions if not detailed here. Typically, a long press or specific tap sequence on an MFB or dedicated button activates/deactivates ANC.

6. MAINTENANCE

Proper maintenance ensures the longevity and performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Ear Tips:** Remove and clean the ear tips periodically with a damp cloth and mild soap, then rinse and dry thoroughly before reattaching.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Avoid Moisture:** Keep the earbuds and charging case away from water, excessive humidity, and extreme temperatures.

7. TROUBLESHOOTING

If you encounter issues with your earbuds, refer to the following common problems and solutions.

Problem	Solution
Earbuds not pairing with each other.	<ul style="list-style-type: none"> • Ensure both earbuds are charged. • Place both earbuds back into the charging case, then take them out again. • Try resetting the earbuds (refer to manufacturer's website for specific reset procedure if needed).
Earbuds not connecting to device.	<ul style="list-style-type: none"> • Ensure Bluetooth is enabled on your device. • Make sure the earbuds are in pairing mode (indicator light flashing red/blue). • Forget/delete "DACOM GF7 TWS" from your device's Bluetooth list and try pairing again. • Ensure earbuds are within range of your device.
No sound from earbuds.	<ul style="list-style-type: none"> • Check the volume level on both your device and the earbuds. • Ensure the earbuds are properly connected to your device. • Try playing different audio sources.
Charging case or earbuds not charging.	<ul style="list-style-type: none"> • Verify the charging cable is securely connected to both the case/earbuds and the power source. • Try a different USB cable or power adapter. • Ensure the charging contacts on the earbuds and in the case are clean and free of debris.

8. SPECIFICATIONS

Brand Name	DACOM
Model Name	GF7 TWS
Model Number	7TWS
Color	White

Headphones Form Factor	In-Ear
Noise Control	Active Noise Cancellation
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth V4.2 (inferred from title)
Included Components	Ear Cushions
Special Features	Noise Cancellation, Microphone Included
Control Method	Touch
Compatible Devices	All devices
Material	PU Metal Eraser (likely referring to ear tip material or casing finish)

9. SAFETY INFORMATION

Please read and follow these safety guidelines to prevent injury or damage to your device.

- Do not disassemble, repair, or modify the product. This may cause fire, electric shock, or complete damage to the product.
- Keep the product away from extreme temperatures (hot or cold), direct sunlight, and sources of heat.
- Avoid exposing the product to water or other liquids.
- Do not use the product at high volume for extended periods to prevent hearing damage.
- Use only the provided or recommended charging cables and adapters.
- Keep out of reach of children and pets. Small parts may pose a choking hazard.
- Be aware of your surroundings when using the earbuds, especially in traffic or other potentially dangerous situations.

10. WARRANTY AND SUPPORT

DACOM products are designed and manufactured to the highest quality standards. For detailed warranty information, please refer to the warranty card included with your purchase or visit the official DACOM website.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact DACOM customer service through their official website or the contact information provided in your product packaging.

- **Online Support:** Visit the official DACOM website for FAQs, support articles, and contact forms.
- **Email Support:** Refer to your product packaging for customer service email addresses.

