

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ellia](#) /
- › [Ellia Ascend Ultrasonic Aroma Diffuser ARM-535TWT User Manual](#)

Ellia ARM-535TWT

Ellia Ascend Ultrasonic Aroma Diffuser ARM-535TWT User Manual

Model: ARM-535TWT

INTRODUCTION

The Ellia Ascend Ultrasonic Aroma Diffuser is designed to enhance your environment by gently dispersing your favorite essential oil aromas. Utilizing ultrasonic technology, it converts water and essential oil into a fine mist, providing soothing humidity and a subtle fragrance. This manual provides instructions for safe and effective use of your diffuser.

IMPORTANT SAFETY INFORMATION

Please read all instructions and warnings before using this product. Failure to follow these instructions may result in electric shock, fire, or injury.

- Avoid direct skin contact with undiluted essential oils.
- Keep out of reach of children and pets.
- Ensure proper ventilation during use.
- Do not place the diffuser near heat sources or in direct sunlight.
- Use only the provided AC adapter.
- Do not immerse the unit in water or other liquids.

PACKAGE CONTENTS

- Outer ceramic cover
- Inner plastic cover
- Diffuser base
- AC adapter

SETUP AND OPERATION

Step 1: Prepare the Diffuser

Place the diffuser on a flat, stable surface. Remove the outer ceramic cover, then remove the inner plastic cover.



Image: The Ellia Ascend diffuser with its outer ceramic cover and inner plastic cover removed, revealing the water reservoir and internal components.

Step 2: Fill the Water Reservoir

Pour clean tap water into the reservoir until it reaches the maximum fill line. Do not overfill.

Pour water into the reservoir to the max fill line and add 5-7 drops of essential oil to the water. Depending on your personal preference, you may add more or fewer drops of essential oil.



Image: A hand holding an essential oil bottle, adding drops into the water-filled reservoir of the diffuser.

Step 3: Add Essential Oils

Add 5-7 drops of your preferred essential oil directly into the water. You may adjust the number of drops based on your personal preference for aroma intensity.

Step 4: Reassemble and Power On

Place the inner plastic cover back on, followed by the outer ceramic cover. Ensure both covers are securely in place. Plug the AC adapter into the diffuser, then plug the adapter into a standard electrical outlet.



Choose your mist and glow options for maximum enjoyment. When the reservoir is empty, the unit shuts off automatically -- helping you relax even more.

Image: A close-up view of the diffuser's base, showing the power button (left) and light control button (right).

Step 5: Select Mist and Glow Options

Use the control buttons on the base to select your desired mist mode (continuous or intermittent) and light glow settings. The unit will automatically shut off when the reservoir is empty.

The Ascend diffuser uses ultrasonic technology to convert water and essential oil into a fine mist to alleviate dry air for a subtle yet satisfying effect throughout your home, workspace, or any environment.



Image: The Ellia Ascend diffuser in operation, placed on a dark table next to a notebook and pen, emitting a gentle mist.

MAINTENANCE AND CLEANING

Regular cleaning helps ensure optimal performance and longevity of your diffuser.

- **Exterior Cleaning:** Use a clean, damp, soft cloth to wipe the surface of your diffuser as needed.
- **Reservoir Cleaning:** We recommend wiping out the water reservoir at least once every 2 weeks. Use a soft cloth and mild soap if necessary, then rinse thoroughly.
- **Ultrasonic Membrane Cleaning:** Clean the ultrasonic membrane once every 2-3 weeks, depending on usage. Use a cotton swab dipped in white vinegar to gently wipe the membrane, then rinse with clean water. Do not scrub or use abrasive materials.
- **Storage:** If storing the diffuser for an extended period, ensure it is clean and completely dry.

TROUBLESHOOTING

If your diffuser is not operating as expected, please review the following common issues:

- **No Mist:** Ensure the water level is between the minimum and maximum fill lines. Check that the power adapter is securely plugged into both the diffuser and the outlet. Clean the ultrasonic membrane as described in the Maintenance section.
- **Weak Mist:** The water level might be too low or too high. Ensure the membrane is clean.
- **Unit Not Turning On:** Verify the power adapter is correctly connected and the outlet is functional.
- **No Aroma:** Ensure you have added enough essential oil. The intensity of aroma can vary based on oil quality and room size.

If problems persist, please refer to the Warranty and Support section.

SPECIFICATIONS

Feature	Detail
Model Number	ARM-535TWT
Product Dimensions	5.53 x 5.53 x 4.85 inches
Weight	1.39 Pounds
Runtime	Up to 6 hours continuous or 12 hours intermittent
Material	Ceramic, Wood
Special Feature	Corded, Gentle Glow



Image: The Ellia Ascend diffuser shown next to an iPhone X for scale, with dimensions labeled: 5.53 inches width, 4.85 inches height.

WARRANTY AND SUPPORT

This Ellia Ascend Ultrasonic Aroma Diffuser comes with a **1-year limited warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical support, warranty information, or other inquiries, please contact the manufacturer, Homedics, or refer to the official Ellia website for customer service contact details.