

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [YEEBAY](#) /

› [YEEBAY Interactive Pop-Up Animals Toy User Manual](#)

## YEEBAY YB-01

# YEEBAY Interactive Pop-Up Animals Toy Instruction Manual

Model: YB-01 | Brand: YEEBAY

## INTRODUCTION

---

The YEEBAY Interactive Pop-Up Animals Toy is designed as an early learning toy for toddlers, focusing on developing motor skills and understanding cause-and-effect relationships. This toy features colorful animals that pop up when various mechanisms are activated, accompanied by sounds or music.



Figure 1: YEEBAY Interactive Pop-Up Animals Toy

## KEY FEATURES

- **Multi-development Toy:** Designed to teach children about buttons, knobs, pushing, and pulling, aiding in the development of fine motor skills and understanding cause and effect.
- **Two Play Modes:**
  - **Animal Sound/Music Mode:** Animals play relevant animal sounds or music upon popping up.
  - **Game/Music&Light Mode:** Children pop up the correct animal when a light stops on it.
- **Durable & Portable:** Constructed for durability and includes an easy-carry handle for on-the-go play.
- **Educational Benefits:** Inspires exploration, encourages natural curiosity, and improves hand-eye coordination.

## 3 PLAY MODES



### Sound & Music

When the animal pops up, it will play the relevant animal sound or music.



### Game/Music & Light

Pop up the correct animal, when the light stops.



### OFF

The animal pops up when the button is activated by pushing, turning, toggling or pressing.

Figure 2: Overview of the three play modes including Sound & Music, Game/Music & Light, and Off.

## SETUP

### Battery Installation

The YEEBAY Interactive Pop-Up Animals Toy requires batteries for operation (batteries not included). To install or replace batteries:

1. Locate the battery compartment on the underside of the toy.
2. Using a screwdriver, open the battery compartment cover.
3. Insert the required batteries, ensuring correct polarity (+/-).
4. Securely close the battery compartment cover with the screwdriver.

## OPERATING INSTRUCTIONS

The toy features four distinct mechanisms to activate the pop-up animals, each designed to engage different motor skills.

- **Push Mechanism:** Press the purple button to make the blue hippo pop up.
- **Twist Mechanism:** Rotate the yellow flower-shaped knob to make the orange bear pop up.

- **Slide Mechanism:** Slide the blue lever to make the purple elephant pop up.
- **Press Mechanism:** Press the orange circular button to make the yellow giraffe pop up.

### Play Modes Selection

Use the switch on the side of the toy to select between the two play modes:

- **Animal Sound/Music Mode:** When an animal pops up, it will play its corresponding animal sound or a musical tune.
- **Game/Music&Light Mode:** The toy will light up one of the animal compartments. Pop up the animal in the lit compartment to continue the game.



Figure 3: The toy's controls are designed for easy manipulation by little hands, promoting cause and effect learning.

Improve Hand-eye Coordination  
Build Fine Motor Skills.



Figure 4: Engaging with the toy helps improve hand-eye coordination and build fine motor skills.

## Introduce Kids to Shapes & Animals Rewards Discovery with Colorful Critters



Figure 5: The toy introduces children to various shapes and animals, rewarding discovery with colorful characters.

Your browser does not support the video tag.

Video 1: Official demonstration of the YEEBAY Interactive Pop-Up Animals Toy, highlighting its features and interactive play for young children.

## MAINTENANCE

- **Cleaning:** Wipe the toy with a soft, damp cloth. Do not immerse in water. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the toy in a cool, dry place away from direct sunlight when not in use.
- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent leakage.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Toy does not turn on or make sounds.	Batteries are low, incorrectly installed, or missing.	Check battery installation and replace with fresh batteries if needed. Ensure the power switch is ON.

Problem	Possible Cause	Solution
Animals do not pop up.	Mechanism is stuck or toy is in OFF mode.	Ensure the toy is in one of the play modes. Gently check if any debris is obstructing the pop-up mechanism.
Lights are not working.	Toy is not in Game/Music&Light Mode or batteries are low.	Switch to Game/Music&Light Mode. Replace batteries if necessary.

## SPECIFICATIONS

---

Attribute	Detail
Product Dimensions	6 x 4 x 0.2 inches
Item Weight	1.43 pounds
Model Number	YB-01
Manufacturer Recommended Age	12 months and up
Manufacturer	YEEBAY



Figure 6: Detailed dimensions of the YEEBAY Pop-Up Animals Toy.

## WARRANTY AND SUPPORT

YEEBAY is committed to providing high-quality products. For any issues encountered with your Interactive Pop-Up Animals Toy, please contact the seller or manufacturer directly for support. Please refer to your purchase documentation for specific warranty details.