

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Fiskars](#) /

› [Fiskars Watering Hose 13mm \(1/2"\) 20M Q4 User Manual](#)

Fiskars 1027104

Fiskars Watering Hose 13mm (1/2") 20M Q4

INSTRUCTION MANUAL

Introduction


This manual provides essential information for the proper setup, operation, and maintenance of your Fiskars Watering Hose 13mm (1/2") 20M Q4. Please read these instructions carefully before use to ensure safe and efficient performance of the product.

Safety Information

- Always turn off the water supply before connecting or disconnecting the hose or accessories.
- Do not drink water from the hose unless it is specifically rated for potable water. This hose is intended for irrigation purposes.
- Avoid leaving the hose under high pressure for extended periods when not in use.
- Store the hose away from direct sunlight and extreme temperatures to prolong its lifespan.
- Keep out of reach of children when not supervised.

Setup

- Uncoiling the Hose:** Carefully uncoil the entire length of the hose before use to prevent kinks and ensure even water flow.
- Connecting to Water Source:** Attach one end of the hose to a standard outdoor faucet. Ensure the connection is tight to prevent leaks. Hand-tightening is usually sufficient.
- Attaching Accessories:** Connect your desired watering accessory (e.g., nozzle, sprinkler) to the other end of the hose. The Fiskars hose features universal fittings compatible with most standard watering tools.



The Fiskars Watering Hose connected to a standard faucet, demonstrating its universal fit.




Close-up of two hose connectors being joined, illustrating the secure connection mechanism.

Operating

- **Turning On Water:** Slowly turn on the water supply at the faucet. This prevents sudden pressure surges that could damage the hose or fittings.
- **Watering:** Direct the water flow as needed for your gardening tasks. Adjust the nozzle or sprinkler settings for desired spray patterns.
- **Turning Off Water:** After use, turn off the water supply at the faucet.
- **Relieving Pressure:** Disconnect any attached accessories and allow residual water to drain from the hose to relieve pressure.

Maintenance

- **Cleaning:** Periodically rinse the hose with clean water to remove dirt, mud, or debris.
- **Storage:** For optimal longevity, store the hose coiled in a cool, dry place away from direct sunlight. The hose is UV-protected and frost-protected, but proper storage further extends its life.
- **Winterization:** Before freezing temperatures, ensure all water is drained from the hose and store it indoors to prevent ice damage.
- **Inspecting for Damage:** Regularly inspect the hose for any cuts, punctures, or wear. Replace if significant damage is found to prevent leaks.



The Fiskars Watering Hose, coiled for storage or transport.


Troubleshooting

- **Low Water Pressure:** Check if the faucet is fully open. Ensure there are no kinks in the hose. Verify that any attached accessories are not clogged.
- **Leaks at Connections:** Tighten all connections by hand. If leaks persist, check the rubber washers inside the fittings for damage or proper seating. Replace washers if necessary.
- **Hose Kinks:** Uncoil the hose completely before use. Avoid sharp bends during operation. The Fiskars hose is designed for twist resistance, but extreme bending can still cause kinks.


Specifications

Feature	Specification
Brand	Fiskars
Model Number	1027104

Feature	Specification
Material	Plastic
Color	Standard (Black/Blue)
Item Weight	2.8 Kilograms (6.16 pounds)
Nominal Wall Thickness	13 millimeters
Outside Diameter	13 Millimeters (1/2 inch)
Item Length	20 Meters



Detail showing the hose diameter (13mm or 1/2 inch) and length (20 meters).



Detail of a hose connector, indicating compatibility with 13-15mm (1/2-5/8 inch) hose sizes.


Warranty Information

Fiskars products are designed for durability and performance. For specific warranty details regarding your watering hose, please refer to the warranty information provided at the point of purchase or visit the official Fiskars website. Keep your proof of purchase for any warranty claims.

Support

Should you require further assistance, have questions about your Fiskars Watering Hose, or need to report an issue, please contact Fiskars customer support. Contact information can typically be found on the product packaging or the official Fiskars website.

Related Documents - 1027104

	<p>Waterwheel XL & Waterwheel XL, with wheels Manual</p> <p>User manual for the Fiskars Waterwheel XL and Waterwheel XL with wheels, providing instructions for setup, use, and maintenance in multiple languages.</p>
	<p>Fiskars 9240 Extendable Pruning Stik Head Replacement Instructions</p> <p>Detailed, step-by-step guide for replacing the head assembly on the Fiskars 9240 Extendable Pruning Stik. Includes required tools, safety precautions, and clear instructions with text descriptions of visuals.</p>
	<p>Fiskars Pruning Saw Blade Replacement Guide</p> <p>Instructions for replacing the saw blade on Fiskars pruning saw models, featuring WoodZig blade technology for efficient cutting.</p>
	<p>Fiskars Pro Replacement Blade Instructions for Hedge Shears, Pruner, Saw, and Lopper</p> <p>Step-by-step instructions for replacing dull blades on Fiskars Pro Hedge Shears, Pruners, Saws, and Loppers, including necessary tools and safety precautions.</p>
	<p>Fiskars Extendable Tree Pruning Stik Pruner User Manual and Re-Threading Instructions</p> <p>User manual and re-threading instructions for the Fiskars 7.9-12 Foot Extendable Tree Pruning Stik Pruner (model 92406935K), including details for various Fiskars pruner series.</p>
	<p>Fiskars Gardening Catalog 2023: Tools for Every Garden Task</p> <p>Explore the comprehensive Fiskars 2023 gardening catalog, featuring high-quality tools for pruning, cutting, planting, and maintenance. Discover innovative designs and durable solutions for every gardening enthusiast.</p>