

Easytry123 RG57OB/BGE-OS RG57B/BGE-OS

Instruction Manual for Easytry123 Replacement Remote Control

Model: RG57OB/BGE-OS, RG57B/BGE-OS

INTRODUCTION

This manual provides essential information for the proper use and maintenance of your Easytry123 replacement remote control for Olimpia Splendid Air Conditioners. Please read this manual carefully before use to ensure correct operation and to avoid any issues.

IMPORTANT COMPATIBILITY NOTE

This replacement remote control is specifically designed for Olimpia Splendid Air Conditioner models RG57OB/BGE-OS and RG57B/BGE-OS. It is crucial that your air conditioner model exactly matches one of these listed models for the remote to function correctly. If your model number is not listed, this remote control may not be compatible.

SETUP

1. Battery Installation

The remote control requires **2 AAA batteries** (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Rear view of the remote control with the battery cover removed, illustrating the battery compartment for AAA batteries.

Note: Remove batteries if the remote control will not be used for an extended period to prevent leakage and damage.

OPERATING THE REMOTE CONTROL

This remote control operates your air conditioner via infrared signals. Ensure there is a clear line of sight between the remote control and the air conditioner's receiver.



Image: Front view of the Easytry123 replacement remote control, displaying its buttons and LCD screen.

Basic Functions:

- **ON/OFF Button:** Press to turn the air conditioner on or off. (Typically a prominent yellow button)
- **MODE Button:** Cycles through operating modes such as Cool, Heat, Fan, Dry, Auto.
- **FAN Button:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **TEMP ▲/▼ Buttons:** Increases or decreases the desired temperature setting.
- **TIMER ON/OFF Buttons:** Sets a timer for the air conditioner to turn on or off automatically.
- **SWING Button:** Controls the vertical swing of the air conditioner's louvers.
- **SLEEP Button:** Activates sleep mode for comfortable overnight operation.
- **LED Button:** Toggles the display light on the air conditioner unit.
- **SHORT CUT Button:** Recalls preferred settings.
- **FOLLOW ME Button:** Activates a feature where the remote acts as a thermostat, sensing temperature at its location.

Note: The exact functionality of some buttons may vary slightly depending on the specific air conditioner model and the remote control version received. Refer to your air conditioner's original manual for detailed function descriptions.

TROUBLESHOOTING

If your remote control is not functioning as expected, consider the following common issues:

- **Remote not responding:**
 - Check if the batteries are inserted correctly with the correct polarity (+/-).
 - Replace old or depleted batteries with new AAA batteries.
 - Ensure there are no obstructions between the remote control and the air conditioner's infrared receiver.
 - Verify that the remote control is pointed directly at the air conditioner.
- **Limited range:**
 - Ensure batteries are fresh.
 - Reduce the distance between the remote and the air conditioner.
 - Remove any objects that might be blocking the signal path.
- **Specific functions not working:**
 - Confirm that your air conditioner model is indeed RG57OB/BGE-OS or RG57B/BGE-OS. This remote is a replacement and may not support all functions of other models.
 - Some advanced functions might require specific settings on the air conditioner unit itself.

SPECIFICATIONS

Feature	Detail
Brand	Easytry123
Compatible Models	Olimpia Splendid RG57OB/BGE-OS, RG57B/BGE-OS Air Conditioner

Connectivity Technology	Infrared
Controller Type	Button Control
Maximum Range	10 Meters (approx. 33 feet)
Batteries Required	2 x AAA (not included)
Special Feature	Fahrenheit display, random shipment of button layouts (ensure model compatibility)

WARRANTY AND SUPPORT

As a replacement part, this product typically does not come with a separate manufacturer's warranty or dedicated support manual. For any issues or questions regarding your purchase, please contact the seller directly through the platform where you purchased the remote control. Refer to the platform's return and refund policies for applicable terms.

For detailed operation of your Olimpia Splendid Air Conditioner, please consult the original user manual provided with your air conditioning unit.

© 2024 Easytry123. All rights reserved.