

[Manuals.plus](#) /

> [Verbatim](#) /

> Verbatim Wireless Mini Bluetooth Speaker (Model 70228) Instruction Manual

Verbatim 70228

Verbatim Wireless Mini Bluetooth Speaker (Model 70228) Instruction Manual

Brand: Verbatim | Model: 70228

INTRODUCTION

The Verbatim Wireless Mini Bluetooth Speaker delivers powerful sound in a compact, travel-friendly design. It supports True Wireless Stereo (TWS) for pairing with a second speaker, and includes a built-in microphone for hands-free calling. This manual provides detailed instructions to help you get the most out of your speaker.

PACKAGE CONTENTS

- Verbatim Wireless Mini Bluetooth Speaker
- Charging Cable
- Instruction Manual (this document)



PRODUCT OVERVIEW



Image: Top view of the speaker, highlighting the control buttons.

- 1. Power Button:** Press and hold to power on/off. Short press to play/pause music or answer/end calls.
- 2. Volume Up (+):** Short press to increase volume. Long press for next track.
- 3. Volume Down (-):** Short press to decrease volume. Long press for previous track.
- 4. Microphone:** Built-in for hands-free calling.
- 5. Charging Port:** Micro-USB port for charging.
- 6. LED Indicator:** Displays power, charging, and Bluetooth status.
- 7. Carrying Strap:** For portability.



Image: Close-up of the Micro-USB charging port located on the side of the speaker.

SETUP

1. Charging the Speaker

1. Connect the provided charging cable to the speaker's Micro-USB port.
2. Connect the other end of the cable to a USB power source (e.g., computer, USB wall adapter).
3. The LED indicator will illuminate during charging and turn off when fully charged.
4. A full charge provides up to 4 hours of continuous playtime.

2. Bluetooth Pairing (Single Speaker)

1. Ensure the speaker is fully charged.
2. Press and hold the Power Button until you hear an audible prompt and the LED indicator flashes blue, indicating it's in pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "Verbatim Speaker" (or similar name) from the list.

5. Once connected, the LED indicator will stop flashing and remain solid blue, and you will hear a confirmation tone.

3. True Wireless Stereo (TWS) Pairing (Optional)

To experience enhanced stereo sound, you can pair two Verbatim Wireless Mini Bluetooth Speakers together.

1. Ensure both speakers are charged and powered off.
2. Power on both speakers simultaneously. They will automatically attempt to pair with each other.
3. Once successfully paired in TWS mode, you will hear a confirmation tone from both speakers.
4. Now, connect your device to one of the speakers via Bluetooth as described in step 2. Both speakers will play audio in stereo.
5. **Note:** Keep the two speakers within 1 meter distance for optimal TWS connection. Turning off one speaker will power off both when in TWS mode.

OPERATING INSTRUCTIONS

1. Power On/Off

- **Power On:** Press and hold the Power Button for approximately 3 seconds.
- **Power Off:** Press and hold the Power Button for approximately 3 seconds.

2. Music Playback

- **Play/Pause:** Short press the Power Button.
- **Volume Up:** Short press the '+' button.
- **Volume Down:** Short press the '-' button.
- **Next Track:** Long press the '+' button.
- **Previous Track:** Long press the '-' button.



Image: The speaker positioned on a desk, playing music from a connected smartphone.

3. Hands-Free Calling

- **Answer Call:** Short press the Power Button when a call comes in.
- **End Call:** Short press the Power Button during a call.
- **Reject Call:** Long press the Power Button when a call comes in.

MAINTENANCE

- Keep the speaker dry and away from moisture. This product is NOT waterproof.
- Clean the speaker with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Avoid extreme temperatures.
- Store the speaker in a cool, dry place when not in use for extended periods.
- Do not attempt to disassemble or repair the speaker yourself. This will void the warranty.

TROUBLESHOOTING

Problem	Solution
Speaker does not power on.	Ensure the battery is charged. Connect to a power source using the charging cable.
Cannot pair with Bluetooth device.	<ul style="list-style-type: none">• Ensure the speaker is in pairing mode (flashing blue LED).• Make sure Bluetooth is enabled on your device.• Move the speaker closer to your device.• Forget the device on your phone's Bluetooth settings and try pairing again.
No sound or low volume.	<ul style="list-style-type: none">• Increase the volume on both the speaker and your connected device.• Ensure the speaker is properly connected via Bluetooth.
TWS pairing fails.	<ul style="list-style-type: none">• Ensure both speakers are powered off before attempting TWS pairing.• Keep speakers within 1 meter of each other during pairing.• Disconnect any other Bluetooth devices from the speakers before TWS pairing.

SPECIFICATIONS

Feature	Detail
Brand	Verbatim
Model Number	70228
Wireless Communication Technology	Bluetooth
Bluetooth Range	Up to 10 meters (33 feet)
Speaker Type	Speaker System
Audio Output Mode	Stereo (with TWS)
Special Feature	Built-in Microphone for Hands-Free Calling
Output Power	3W
Frequency Response	100Hz-20KHz
Operating Time	Up to 4 hours (on a single charge)
Power Source	Battery Powered (1 Lithium Ion battery included)
Control Method	Touch Buttons
Dimensions (L x D x H)	1.57" x 1.57" x 1.69"
Weight	0.1 Pounds (1.6 ounces)

Feature	Detail
Color	Black
Waterproof	No

WARRANTY AND SUPPORT

The Verbatim Wireless Mini Bluetooth Speaker is backed by a **1-Year Limited Warranty** from Verbatim Americas, LLC.

For technical support or warranty claims, please contact Verbatim customer service. Refer to the official Verbatim website or product packaging for the most current contact information.



Image: Official Verbatim 1-Year Limited Warranty badge.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07MK77VYF>

More documents and user manuals: <https://manuals.plus/>