Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bosch MGM8842MIN

Bosch Pro 1000W Mixer Grinder MGM8842MIN

User Manual

Model: MGM8842MIN | Brand: Bosch

Introduction

Thank you for choosing the Bosch Pro 1000W Mixer Grinder MGM8842MIN. This appliance is designed for efficient and versatile kitchen tasks, including wet grinding, dry grinding, chutney grinding, and blending. With its powerful 1000W motor and specialized blades, it ensures optimal performance and authentic results. Please read this manual carefully before first use to ensure safe and proper operation, and retain it for future reference.



Image: The Bosch Pro 1000W Mixer Grinder unit shown with its various stainless steel jars and a plastic blender jar, highlighting its comprehensive capabilities for different kitchen needs.

Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using the appliance.
- Do not immerse the motor unit in water or any other liquid. Clean only with a damp cloth.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Always unplug the appliance from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Keep hands and utensils out of the jar while operating to prevent injury and damage to the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The appliance is equipped with an **overload protector** for safe operations. If the motor stops due to overload, switch off the appliance, remove some ingredients, and wait for a few minutes before restarting.
- Do not use attachments not recommended or sold by the manufacturer.
- This appliance is for household use only. Do not use outdoors.
- Exercise extreme caution when handling sharp blades. Always handle blades by their base.
- Ensure jars are properly locked onto the motor unit before starting.

Product Overview

The Bosch Pro 1000W Mixer Grinder MGM8842MIN consists of a robust motor unit and multiple specialized jars designed for various grinding and blending tasks.



Image: A clear front view of the Bosch Pro 1000W Mixer Grinder, showcasing its sleek black and silver design and the control knob.

Key Components:

- **Motor Unit:** The main power unit with a 1000W motor and control knob. Features strong suction feet for stability during operation.
- **Plastic Blender Jar (1500ml):** Ideal for blending liquids, making smoothies, milkshakes, and purees. Includes a fruit filter.
- **Dry Grinding Jar (1000ml):** Designed for grinding dry spices, grains, and other hard ingredients.
- **Chutney Grinding Jar (400ml):** Perfect for preparing small quantities of chutneys, pastes, and dips.
- **Blades:** Specialized stainless steel blades for different grinding and blending needs, including the unique PoundingBlade.
- **Lid-locks:** Unique lid-locks on jars for completely hands-free operation.

BOSCH
Invented for life

Know Your TrueMixx Mixer Grinder

LESS THAN 750W

CHOOSE
< 750
WATTS FOR
REGULAR
GRINDING



Dips & Chutneys



Purees & Soups



Smoothies
& Milkshakes

MORE THAN 750W

CHOOSE
> 750
WATTS FOR
TOUGH
GRINDING



Dry Masala



Ginger, Cocunut
& Turmeric Paste



Rice & Lentils
Dosa/Idli Batter



BURNING SMELL DURING FIRST
few runs due to evaporating varnish



80-90dB OPERATING NOISE
levels similar to that of a hair dryer

DECIBEL LEVEL COMPARISION CHART



*Mixer grinder model for representative purpose only.

Image: An infographic detailing the capabilities of the Bosch TrueMixx Mixer Grinder, including recommended wattage for different tasks (less than 750W for regular grinding, more than 750W for tough grinding) and a decibel level comparison chart, indicating typical operating noise levels.

Setup and Assembly

Before first use, ensure all packaging materials are removed and components are clean.

1. Place the motor unit on a stable, flat, and dry surface. Ensure the suction feet are firmly attached to the surface for stability.
2. Select the appropriate jar for your task (blending, dry grinding, or chutney grinding).
3. Ensure the correct blade assembly is securely fitted inside the jar.
4. Add your ingredients to the jar. Do not overfill; ensure ingredients are below the maximum fill line.
5. Securely place the lid on the jar and engage the lid-locks to ensure a hands-free operation.
6. Place the assembled jar onto the motor unit, aligning the grooves and twisting clockwise until it locks into place.
7. Plug the power cord into a suitable electrical outlet.

Operating Instructions

The Bosch Pro 1000W Mixer Grinder offers various speed settings and a pulse function for precise control.

General Operation:

- Turn the control knob to the desired speed setting (1-3) or use the 'Pulse' function for short bursts of power.
- The appliance has a 30-minute motor rating (5 minutes ON, 2 minutes OFF, maximum 6 cycles). Do not operate continuously for more than 5 minutes. Allow the motor to cool down between cycles.
- Always ensure the lid is securely locked before starting the appliance.

Dry Grinding (using Dry Grinding Jar):

Use this jar for grinding dry spices, coffee beans, rice, and other hard ingredients. The unique **PoundingBlade** is designed to replicate a pounding effect for authentic texture and taste.



Image: Close-up of the PoundingBlade with thick edges, designed to mimic traditional pounding for dry ingredients, shown next to a bowl of ground spices and dried chilies.



Image: A detailed view of the dry grinding blade, suitable for processing various dry ingredients into fine powders, shown next to turmeric powder and whole turmeric roots.

- Ensure ingredients are completely dry.
- Start with a lower speed and gradually increase to achieve desired consistency.
- Use the pulse function for coarse grinding or to break down larger pieces.

Wet Grinding (using Dry Grinding Jar or Plastic Blender Jar):

Ideal for preparing batters for dosa, idli, purees, and gravies.



Image: A close-up of the wet grinding blade, designed for smooth and consistent wet pastes and batters, shown next to idlis, chutney, and sambar.

- Add water or other liquids as required for desired consistency.
- For best results, soak grains or lentils before grinding.
- Start at a low speed and increase gradually.

Chutney Grinding (using Chutney Grinding Jar):

Perfect for small quantities of chutneys, pastes, and spice mixes.




Image: A detailed view of the chutney grinding blade, optimized for fine grinding of small quantities, shown next to a bowl of coconut chutney and coconut pieces.

- Add ingredients and a small amount of liquid if necessary.
- Use the pulse function for controlled grinding to achieve desired texture.

Blending/Juicing (using Plastic Blender Jar):

Ideal for making smoothies, milkshakes, and extracting juices with the fruit filter.



Image: The plastic blender jar with its internal components, including the fruit filter, designed for smooth blending and juicing, shown next to a glass of banana milkshake and bananas.



Image: A top-down view inside the blender jar, illustrating the vortex created during blending, ensuring thorough mixing of ingredients.

- For juicing, place the fruit filter inside the blender jar before adding ingredients.
- Add fruits, vegetables, and liquids.
- Start at a low speed and gradually increase to blend until smooth.

Care and Maintenance

Proper cleaning and maintenance will extend the life of your mixer grinder.

- Always unplug the appliance before cleaning.
- **Motor Unit:** Wipe the motor unit with a soft, damp cloth. Do not immerse it in water or rinse under running water.
- **Jars and Lids:** Wash jars, lids, and blades with warm soapy water immediately after use. Rinse thoroughly and dry completely. The jars are made of high-grade stainless steel.
- **Blades:** Handle blades with extreme care as they are sharp. Use a brush for cleaning hard-to-reach areas.
- **Dishwasher Safe:** The jars and lids are dishwasher safe, making cleaning convenient.
- **Storage:** Store the mixer grinder and its accessories in a clean, dry place. Cable management is provided for easy handling and storage of the power cord.

Troubleshooting

If you encounter any issues with your Bosch Pro 1000W Mixer Grinder, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Appliance does not start.	Not plugged in; Jar not properly locked; Overload protector activated.	Check power connection; Ensure jar is securely locked onto the motor unit; If overloaded, switch off, remove some ingredients, and wait a few minutes before restarting.
Burning smell during initial use.	New motor varnish evaporating.	This is normal for the first few uses and will dissipate. Ensure proper ventilation.
Excessive noise during operation.	High-power motor operation; Unstable placement; Jar not properly seated.	A 1000W motor will produce some noise (around 80-90 dB, similar to a hairdryer). Ensure the unit is on a flat, stable surface and the jar is securely locked.
Ingredients not grinding properly.	Insufficient liquid (for wet grinding); Overfilling; Incorrect blade for task.	Add more liquid if needed; Do not overfill the jar; Ensure the correct blade is used for the type of grinding.
Lid not sealing properly.	Lid-locks not engaged; Gasket misplaced or damaged.	Ensure lid-locks are fully engaged; Check if the gasket is correctly seated or needs replacement.

Technical Specifications

Feature	Specification
Brand	Bosch
Model Name	True Mixx (MGM8842MIN)
Power	1000 Watts
Colour	Black
Product Dimensions	21D x 49.5W x 21.9H Centimeters
Item Weight	5.2 kg (5200 Grams)
Blade Material	Stainless Steel
Special Feature	Overload Protection
Container Material	Stainless Steel (Jars), Plastic (Blender Jar)
Included Components	Mixer Grinder, 1 x Plastic blender jar 1500ml, fruit filter, 1 x Dry grinding jar 1000ml, 1 x Chutney grinding jar 400ml
Country of Origin	India
Is Dishwasher Safe	Yes (Jars and Lids)

Warranty and Customer Support

Bosch products are manufactured to high quality standards. This product comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official Bosch India website.

For any product-related queries, service requests, or to purchase spare parts, please contact Bosch customer support. You may find contact details on the official Bosch website or on your product packaging.

Manufacturer: Bosch, BSH Household Appliances Manufacturing Pvt. Ltd.

Importer: Bosch

For more information, you can visit the Bosch Store on Amazon.in.

© 2024 Bosch. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07MKMFKPG

More documents and user manuals: **https://manuals.plus/**